

OPERATOR'S MANUAL

DOPPLER SONAR CURRENT INDICATOR

Model

CI-68

FURUNO ELECTRIC CO., LTD.

www.furuno.com

FURUNO ELECTRIC CO., LTD.

9-52 Ashihara-cho, Nishinomiya, 662-8580, JAPAN • FURUNO Authorized Distributor/Dealer

All rights reserved. Printed in Japan

Pub. No. 0ME-72520-F1

(TEHI) CI-68



0 0 0 1 4 8 0 2 2 1 5

IMPORTANT NOTICES

General

- This manual has been authored with simplified grammar, to meet the needs of international users.
- The operator of this equipment must read and follow the instructions in this manual. Wrong operation or maintenance can void the warranty or cause injury.
- Do not copy any part of this manual without written permission from FURUNO.
- If this manual is lost or worn, contact your dealer about replacement.
- The contents of this manual and the equipment specifications can change without notice.
- The example screens (or illustrations) shown in this manual can be different from the screens you see on your display. The screens you see depend on your system configuration and equipment settings.
- Save this manual for future reference.
- Any modification of the equipment (including software) by persons not authorized by FURUNO will void the warranty.
- The following concern acts as our importer in Europe, as defined in DECISION No 768/2008/EC.
 Name: FURUNO EUROPE B.V.
 - Address: Siriusstraat 86, 5015 BT, Tilburg, The Netherlands
- The following concern acts as our importer in UK, as defined in SI 2016/1025 as amended SI 2019/ 470.
 - Name: FURUNO (UK) LTD.
 - Address: West Building Penner Road Havant Hampshire PO9 1QY, U.K.
- All brand, product names, trademarks, registered trademarks, and service marks belong to their respective holders.

How to discard this product

Discard this product according to local regulations for the disposal of industrial waste. For disposal in the USA, see the homepage of the Electronics Industries Alliance (http://www.eiae.org/) for the correct method of disposal.

How to discard a used battery

Some FURUNO products have a battery(ies). To see if your product has a battery, see the chapter on Maintenance. If a battery is used, tape the + and - terminals of the battery before disposal to prevent fire, heat generation caused by short circuit.

In the European Union

The crossed-out trash can symbol indicates that all types of batteries must not be discarded in standard trash, or at a trash site. Take the used batteries to a battery collection site according to your national legislation and the Batteries Directive 2006/66/EU.

In the USA

The Mobius loop symbol (three chasing arrows) indicates that Ni-Cd and lead-acid rechargeable batteries must be recycled. Take the used batteries to a battery collection site according to local laws.

In the other countries

There are no international standards for the battery recycle symbol. The number of symbols can increase when the other countries make their own recycle symbols in the future.



▲ SAFETY INSTRUCTIONS

Read these safety instructions before you operate the equipment.



Check the zinc plate (anticorrosion measure) regularly for corrosion and replace it when the ship is drydocked.

Corrosion may occur. As a result the transducer may fall out, allowing water to leak inside the vessel.

Do not use the equipment for other than its intended purpose.

Damage to the equipment or bodily injury may result if the equipment is misused.

Do not transmit with the transducer out of water, when drydocked, etc.

The transducer may become damaged.

Turn off the power at the switchboard immediately whenever you feel the equipment is abnormal.

Turn off the equipment at the switchboard if it becomes warm or is making strange noises. Contact your dealer at your earliest convenience.

WARNING LABEL

A warning label is attached to the transceiver and monitor units. Do not remove the labels. If a label is missing or damaged, contact a FURUNO agent or dealer about replacement.



Transceiver Unit Name: Warning Label (1) Type: 86-003-1011-1 Code No.: 100-236-231

Monitor Unit Name: Warning Label (2) Type: 03-129-1001-1 Code No.: 100-236-741

TFT LCD -

The high quality TFT LCD displays 99.99% of its pixels. The remaining 0.01% of pixels may light or dropout, however this is not an indication of malfuction; it is a characteristic of the LCD.

TABLE OF CONTENTS

SYSTEM CONFIGURATION viii DISPLAY EXAMPLE ix 1. OPERATIONAL OVERVIEW 1.1 1.1 Controls. 1.1 1.1 Controls. 1.2 1.3 How to Turn the Power On/Off. 1.2 1.3 How to dujust the LCD Brilliance and Panel Dimmer. 1.3 1.4 How to Choose a Display 1.4 1.4.1 Tide vector display. 1.4 1.4.3 Graph display. 1.5 1.4.4 Course plot display. 1.6 1.4.5 Text display. 1.6 1.4.6 Echo level display. 1.7 1.5 How to Stet the Measuring Depth 1.7 1.6 How to Choose Speed Tracking Mode 1.7 1.8 How to Set the Ship's Heading 1.10 2.1 Tide Vector Display. 2.1 2.2 Ship's Speed Display. 2.5 2.3 Graph Display. 2.5 2.3 Graph Display. 2.70 2.4 To the Vector Display. 2.71 2.5 Text Display. 2.71 2.6 Echo Level Display. 2.71 2.7 Terr Display 2.71 3.1 MENU OPERATION. 3.1 3.1 (MENU 3] sub menu. 3.2 <th>FO</th> <th>REW</th> <th>/ORD</th> <th>vi</th>	FO	REW	/ORD	vi
DISPLAY EXAMPLE ix 1. OPERATIONAL OVERVIEW 1.1 1.1 Controls 1.2 1.3 How to adjust the LCD Brilliance and Panel Dimmer 1.3 1.4 How to Choose a Display 1.4 1.4.1 Tide vector display 1.4 1.4.2 Ship's speed display 1.6 1.4.3 Graph display 1.6 1.4.4 Course plot display 1.6 1.4.5 Ecto level display 1.6 1.4.6 Ecto level display 1.7 1.6 How to Choose Speed Tracking Mode 1.8 1.7 How to choose the Range 1.9 1.8 How to Set the Ship's Heading 1.10 2. INTERPRETING THE DISPLAYS 2.1 2.1 Tide Vector Display 2.5 2.3 Graph Display 2.70 2.4 Course Piot Display 2.71 2.7 Eror Display 2.11 2.7 Eror Display 2.11 3.1 How to Operate Menu Window 3.1 <t< th=""><th>SY</th><th>STE</th><th>M CONFIGURATION</th><th>viii</th></t<>	SY	STE	M CONFIGURATION	viii
1. OPERATIONAL OVERVIEW 1-1 1.1 Controls 1-1 1.2 How to Turn the Power On/Off 1-2 1.3 How to adjust the LCD Billiance and Panel Dimmer 1-3 1.4 How to Choose a Display 1-4 1.4.1 Tide vector display 1-4 1.4.2 Ship's speed display 1-5 1.4.3 Graph display 1-6 1.4.4 Course plot display 1-6 1.4.5 Text display 1-6 1.4.6 Echo level display 1-7 1.6 How to Schoes Speed Tracking Mode 1-8 1.7 How to Set the Measuring Depth 1-7 1.6 How to Choose Speed Tracking Mode 1-8 1.7 How to Set the Range 1-9 1.8 How to Set the Baip's Heading 1-10 2.1 Tide Vector Display 2-1 2.2 Ship's Speed Display 2-7 2.4 Course Flot Display 2-7 2.5 Text Display 2-7 2.4 Course Flot Display 2-11 2.7 Error Display 2-11 2.8 MENU OPERATION 3-1 3.1 How to Operate Menu Window 3-1 3.2 [MENU 1] menu 3-2 3.2 [MENU 1] menu <th>DIS</th> <th>PLA</th> <th>Y EXAMPLE</th> <th>ix</th>	DIS	PLA	Y EXAMPLE	ix
1.1 Controls 1-1 1.2 How to Turn the Power On/Off 1-2 1.3 How to dajust the LCD Brilliance and Panel Dimmer 1-3 1.4 How to Choose a Display 1-4 1.4.1 Tide vector display 1-4 1.4.2 Ship's speed display 1-5 1.4.3 Graph display 1-5 1.4.4 Course plot display 1-6 1.4.5 Text display 1-6 1.4.6 Echo level display 1-7 1.6 How to Choose Speed Tracking Mode 1-7 1.6 How to Choose Speed Tracking Mode 1-8 1.7 How to choose the Range 1-9 1.8 How to Set the Ship's Heading 1-10 2. INTERPRETING THE DISPLAYS 2-1 2.3 Graph Display 2-7 2.4 Course Plot Display 2-6 2.3 Graph Display 2-70 2.4 Course Plot Display 2-10 2.6 Echo Level Display 2-10 2.6 Echo Level Display 2-11 3.1 How to Operate Menu Window 3-1 3.2 Function Key 3-2 3.3.1 [MENU 1] menu 3-2 3.3.2 [MENU 1]	4			1 1
1.1 How to Turn the Power On/Off 1-2 1.3 How to Ajust the LCD Brilliance and Panel Dimmer 1-3 1.4 How to Choose a Display. 1-4 1.4.1 Tide vector display 1-4 1.4.1 Tide vector display 1-5 1.4.3 Graph display 1-5 1.4.4 Course plot display 1-6 1.4.5 Text display 1-6 1.4.5 Text display 1-6 1.4.6 Echo level display 1-7 1.5 How to Set the Measuring Depth 1-7 1.6 How to Choose Speed Tracking Mode 1-8 1.7 How to Set the Ship's Heading 1-10 2. Intro to choose the Range 2-1 1.8 How to Set the Ship's Heading 2-1 2.1 Tide Vector Display 2-1 2.2 Ship's Speed Display 2-5 2.3 Graph Display 2-1 2.4 Course Plot Display 2-10 2.5 Text Display 2-10 2.6 Echo Level Display 2-2 3.1 <th>1.</th> <th></th> <th>Controlo</th> <th>۱-۱</th>	1.		Controlo	۱-۱
1.2 How to full the LCD Brilliance and Panel Dimmer 1-3 1.4 How to Adjust the LCD Brilliance and Panel Dimmer 1-3 1.4 How to Adjust the LCD Brilliance and Panel Dimmer 1-3 1.4 How to Choose a Display 1-4 1.4.1 Tide vector display 1-4 1.4.2 Ship's speed display 1-5 1.4.3 Graph display 1-6 1.4.4 Course plot display 1-6 1.4.5 Text display 1-7 1.5 How to Set the Measuring Depth 1-7 1.6 How to Choose Speed Tracking Mode 1-8 1.7 How to Set the Ship's Heading 1-10 1.8 How to Set the Ship's Heading 1-10 2.1 Titide Vector Display 2-1 2.1 Titide Vector Display 2-5 2.3 Graph Display 2-1 2.4 Course Plot Display 2-10 2.5 Text Display 2-10 2.6 Echo Level Display 2-11 3. MENU OPERATION 3-1 3.1 How to Operate Menu Window		1.1	Low to Turp the Dower Op/Off	ו-ו 1 ס
1.3 How to Choose a Display. 1.4 1.4.1 Tide vector display. 1.4 1.4.2 Ship's speed display. 1.5 1.4.3 Graph display 1.6 1.4.4 Course plot display. 1.6 1.4.5 Text display 1.6 1.4.6 Echo level display. 1.6 1.4.6 Echo level display. 1.7 1.5 How to Set the Measuring Depth 1.7 1.6 How to Choose Speed Tracking Mode 1.8 1.7 How to Set the Ship's Heading 1.10 2. INTERPRETING THE DISPLAYS 2.1 2.1 Tide Vector Display 2.7 2.4 Course Plot Display 2.7 2.5 Text Display 2.11 2.6 Echo Level Display. 2.11 2.7 Error Display		1.2	How to rull the Power On/On	۲-۱
1.4 How to choose a Lisplay		1.3	How to adjust the LCD Brilliance and Panel Dimmer	1-3
1.4.1 Tide Vector display 1-4 1.4.2 Ship's speed display 1-5 1.4.3 Graph display 1-5 1.4.4 Course plot display 1-6 1.4.5 Text display 1-6 1.4.5 Text display 1-6 1.4.6 Echo level display 1-7 1.5 How to Set the Measuring Depth 1-7 1.6 How to Choose Speed Tracking Mode 1-8 1.7 How to choose the Range 1-9 1.8 How to Set the Ship's Heading 1-10 2.1 Tide Vector Display 2-1 2.2 Ship's Speed Display 2-5 2.3 Graph Display 2-7 2.4 Course Plot Display 2-7 2.4 Course Plot Display 2-11 2.7 Error Display 2-11 2.6 Echo Level Display 2-11 2.7 Error Display 2-11 3.7 MENU OPERATION 3-1 3.1 How to Operate Menu Window 3-1 3.2 JMENU 1] menu 3-2		1.4	How to Choose a Display.	
1.4.2 Ship is speed display			1.4.1 Lide vector display	
1.4.3 Graph display. 1-5 1.4.4 Course plot display. 1-6 1.4.5 Text display. 1-6 1.4.6 Echo level display. 1-7 1.5 How to Set the Measuring Depth. 1-7 1.6 How to Choose Speed Tracking Mode 1-8 1.7 How to Choose the Range. 1-9 1.8 How to Set the Ship's Heading 1-10 2.1 Tide Vector Display. 2-1 2.2 Ship's Speed Display. 2-7 2.4 Course Plot Display. 2-8 2.5 Text Display. 2-7 2.4 Course Plot Display. 2-8 2.5 Text Display. 2-11 2.6 Echo Level Display. 2-11 2.7 Ext Display. 2-11 2.7 Error Display. 2-11 2.7 Error Display. 2-11 2.7 Error Display. 2-11 3.1 How to Operate Menu Window 3-1 3.2 [MENU 1] menu. 3-2 3.3.1 [MENU 2] menu. 3-2			1.4.2 Ship's speed display	
1.4.4 Course piot display			1.4.3 Graph display	
1.4.5 Text display 1-6 1.4.6 Echo level display 1-7 1.5 How to Choose Speed Tracking Mode 1-7 1.6 How to Choose Speed Tracking Mode 1-8 1.7 How to choose the Range 1-9 1.8 How to set the Ship's Heading 1-10 2. INTERPRETING THE DISPLAYS 2-1 2.1 Tide Vector Display 2-5 2.3 Graph Display 2-7 2.4 Course Plot Display 2-7 2.4 Course Plot Display 2-10 2.6 Echo Level Display 2-11 2.7 Ext Display 2-11 2.6 Echo Level Display 2-11 2.7 Ext Display 2-11 3.7 Firor Display 2-11 3.7 Function Key 3-2 3.3.1 IMENU OPERATION 3-1 3.2 [MENU 1] menu 3-2 3.3.3.4 [MENU 2] menu 3-2 3.3.4 [MENU 3] sub menu 3-3 3.4.1 [MODE] sub menu 3-5			1.4.4 Course plot display	
1.4.6 Echo level display 1-7 1.5 How to Set the Measuring Depth 1-7 1.6 How to Choose Speed Tracking Mode 1-8 1.7 How to choose the Range 1-9 1.8 How to Set the Ship's Heading 1-10 2. INTERPRETING THE DISPLAYS 2-1 2.1 Tide Vector Display 2-1 2.2 Ship's Speed Display 2-5 2.3 Graph Display 2-7 2.4 Course Plot Display 2-7 2.4 Course Plot Display 2-8 2.5 Text Display 2-11 2.6 Echo Level Display 2-11 2.7 Error Display 2-11 2.6 Echo Level Display 2-11 2.7 Error Display 2-11 3.7 HenU OPERATION 3-1 3.1 How to Operate Menu Window 3-1 3.2 JMENU 1] menu 3-2 3.3.1 IMENU 2] menu 3-2 3.3.2 JMENU 2] use menu 3-5 3.4.1 IMODEI sub menu 3-5 <			1.4.5 Text display	
1.5 How to Set the Measuring Depth 1-7 1.6 How to Choose Speed Tracking Mode 1-8 1.7 How to choose the Range 1-9 1.8 How to Set the Ship's Heading 1-10 2. INTERPRETING THE DISPLAYS 2-1 2.1 Tide Vector Display 2-1 2.2 Ship's Speed Display 2-5 2.3 Graph Display 2-7 2.4 Course Plot Display 2-7 2.5 Text Display 2-10 2.6 Echo Level Display 2-10 2.6 Echo Level Display 2-11 2.7 Error Display 2-11 3.7 MENU OPERATION 3-1 3.1 How to Operate Menu Window 3-1 3.2 JUNENU 4] sub menu 3-2 3.3.1 [MENU 3] sub menu 3-2 3.3.2 [MENU 4] sub menu 3-2 3.3.3.4 [MENU 2] menu 3-5 3.4.1 [MODE] sub menu 3-5 3.4.2 [DISP 1] sub menu 3-6 3.4.3 [DISP 1] sub menu 3-6			1.4.6 Echo level display	
1.6 How to Choose Speed Tracking Mode 1-8 1.7 How to choose the Range 1-9 1.8 How to Set the Ship's Heading 1-10 2. INTERPRETING THE DISPLAYS 2-1 2.1 Tide Vector Display 2-5 2.3 Graph Display 2-5 2.3 Graph Display 2-7 2.4 Course Plot Display 2-7 2.4 Course Plot Display 2-10 2.5 Text Display 2-11 2.6 Echo Level Display 2-11 2.7 Echo Level Display 2-11 2.6 Echo Level Display 2-11 2.7 Error Display 2-11 3.7 Henu OPERATION 3-1 3.1 How to Operate Menu Window 3-1 3.2 Function Key 3-2 3.3.1 [MENU 0] menu 3-2 3.3.2 [MENU 3] sub menu 3-2 3.3.4 [MENU 2] menu 3-5 3.4.1 [MODE] sub menu 3-5 3.4.2 [DISP 2] sub menu 3-5		1.5	How to Set the Measuring Depth	1-7
1.7 How to choose the Range		1.6	How to Choose Speed Tracking Mode	1-8
1.8 How to Set the Ship's Heading 1-10 2. INTERPRETING THE DISPLAYS 2-1 2.1 Tide Vector Display 2-1 2.2 Ship's Speed Display 2-5 2.3 Graph Display 2-7 2.4 Course Plot Display 2-8 2.5 Text Display 2-10 2.6 Echo Level Display 2-11 2.7 Error Display 2-11 2.6 Echo Level Display 2-11 2.7 Error Display 2-11 3.7 Error Display 2-11 3.7 Error Display 2-11 3.7 IMENU OPERATION 3-1 3.1 How to Operate Menu Window 3-1 3.2 IMENU 1] menu 3-2 3.3.1 [MENU 3] sub menu 3-2 3.3.2 [MENU 4] sub menu 3-2 3.3.3 [MENU 2] menu 3-5 3.4.1 [MOSD 2] sub menu 3-5 3.4.2 [DISP 1] sub menu 3-6 3.4.3 [DISP 2] sub menu 3-9 3.5		1.7	How to choose the Range	1-9
2. INTERPRETING THE DISPLAYS. 2-1 2.1 Tide Vector Display 2-1 2.2 Ship's Speed Display 2-5 2.3 Graph Display 2-7 2.4 Course Plot Display 2-8 2.5 Text Display 2-10 2.6 Echo Level Display 2-11 2.7 Erver Display 2-11 2.6 Echo Level Display 2-11 2.7 Error Display 2-11 3. MENU OPERATION 3-1 3.1 How to Operate Menu Window 3-1 3.2 Function Key 3-2 3.3 [MENU 1] menu 3-2 3.3.1 [MENU 3] sub menu 3-2 3.3.2 [MENU 4] sub menu 3-3 3.4.1 [MODE] sub menu 3-5 3.4.2 [DISP 1] sub menu 3-6 3.4.3 [DISP 2] sub menu 3-7 3.4.4 [MODE] sub menu 3-10 3.5.1 Alarm types 3-10 3.5.2 How to set tide, tide differential and ship's speed alarms 3-11		1.8	How to Set the Ship's Heading	1-10
2. INITERFORCETING THE DISPLATS 2-1 2.1 Tide Vector Display 2-1 2.2 Ship's Speed Display 2-5 2.3 Graph Display 2-7 2.4 Course Plot Display 2-8 2.5 Text Display 2-10 2.6 Echo Level Display 2-11 2.7 Error Display 2-11 3.7 Error Display 2-11 3.7 Error Display 2-11 3.1 How to Operate Menu Window 3-1 3.2 Function Key 3-2 3.3 [MENU 0] menu 3-2 3.3.1 [MENU 3] sub menu 3-2 3.3.2 [MENU 4] sub menu 3-3 3.4.1 [MODE] sub menu 3-5 3.4.1 [MODE] sub menu 3-5 3.4.2 [DISP 1] sub menu 3-6 3.4.3 [DISP 2] sub menu 3-7 3.5.4 How to set tide, tide differential and ship's speed alarms 3-11 3.5.1 Alarm types 3-10 3.5.2 How to acancel an alarm 3-13	n			2.4
2.1 Tide Vector Display 2-1 2.2 Ship's Speed Display 2-7 2.4 Course Plot Display 2-8 2.5 Text Display 2-10 2.6 Echo Level Display 2-11 2.7 Error Display 2-11 2.7 Error Display 2-11 2.7 Error Display 2-11 3.7 Error Display 3-1 3.7 Error Display 3-1 3.7 IMENU 3 Sub menu 3-2 3.8 IMENU 2 Imenu 3-5	Ζ.		ERPRETING THE DISPLATS	2-1
2.2 Snip S Speed Display 2-7 2.3 Graph Display 2-7 2.4 Course Plot Display 2-8 2.5 Text Display 2-10 2.6 Echo Level Display 2-11 2.7 Error Display 2-11 2.7 Error Display 2-11 2.6 Echo Level Display 2-11 2.7 Error Display 2-11 3.7 Error Display 3-1 3.1 IMENU 3 Imenu 3-2 3.3.1 IMENU 3 sub menu 3-2 3.3.2 IMENU 4 sub menu 3-5 3.4.1 IMODE] sub menu 3-5 3.4.2 IDISP 1		2.1	lide vector Display	
2.3 Graph Display 2-7 2.4 Course Plot Display 2-10 2.5 Text Display 2-10 2.6 Echo Level Display 2-11 2.7 Error Display 2-11 3.7 Error Display 2-11 3.7 Error Display 2-11 3.7 Error Display 2-11 3.7 Function Key 3-1 3.1 How to Operate Menu Window 3-1 3.2 Function Key 3-2 3.3.1 IMENU 3] sub menu 3-2 3.3.2 IMENU 4] sub menu 3-3 3.4 IMENU 2] menu 3-3 3.4.1 IMODE] sub menu 3-5 3.4.2 [DISP 1] sub menu 3-6 3.4.3 [DISP 2] sub menu 3-7 3.4.4 [DISP 3] sub menu 3-9 3.5 [ALARM] menu 3-10 3.5.1 Alarm types 3-10 3.5.2 How to set tide, tide differential and ship's speed alarms 3-110 3.5.4 How to set tide, tide alarm 3-13		2.2	Ship's Speed Display	
2.4 Course Plot Display 2-8 2.5 Text Display 2-10 2.6 Echo Level Display 2-11 2.7 Error Display 2-11 3.7 Error Display 2-11 3.1 How to Operate Menu Window 3-1 3.2 Function Key 3-2 3.3 [MENU 1] menu 3-2 3.3.1 [MENU 3] sub menu 3-2 3.3.2 [MENU 4] sub menu 3-2 3.3.2 [MENU 2] menu 3-3 3.4.1 [MODE] sub menu 3-5 3.4.2 [DISP 1] sub menu 3-5 3.4.3 [DISP 2] sub menu 3-6 3.4.4 [DISP 3] sub menu 3-9 3.5 [ALARM] menu 3-10 3.5.2 How to set tide, tide differential and ship's speed alarms 3-11 3.5.3 How to disable/enable the audible alarm 3-14 3.5.5 How to cancel an alarm 3-15 4. MAINTENANCE & TROUBLESHOOTING 4-1 4.1 Maintenance 4-1 4.2 Troubleshooting		2.3	Graph Display	
2.5 Text Display 2-10 2.6 Echo Level Display 2-11 2.7 Error Display 2-11 2.7 Error Display 2-11 3.7 Error Display 2-11 3.1 How to Operate Menu Window 3-1 3.2 Function Key 3-2 3.3 [MENU 1] menu 3-2 3.3.1 [MENU 3] sub menu 3-2 3.3.2 [MENU 4] sub menu 3-3 3.4 [MENU 2] menu 3-5 3.4.1 [MODE] sub menu 3-5 3.4.2 [DISP 1] sub menu 3-6 3.4.3 [DISP 2] sub menu 3-6 3.4.4 [DISP 3] sub menu 3-6 3.5.1 Alarm types 3-10 3.5.2 How to set tide, tide differential and ship's speed alarms 3-10 3.5.2 How to set tide, tide differential and ship's speed alarms 3-11 3.5.3 How to set the trip alarm 3-13 3.5.4 How to disable/enable the audible alarm 3-15 4. MAINTENANCE & TROUBLESHOOTING 4-1 <t< td=""><td></td><td>2.4</td><td>Course Plot Display</td><td></td></t<>		2.4	Course Plot Display	
2.6 Echo Level Display. 2-11 2.7 Error Display 2-11 3. MENU OPERATION. 3-1 3.1 How to Operate Menu Window 3-1 3.2 Function Key 3-2 3.3 [MENU 1] menu. 3-2 3.3.1 [MENU 3] sub menu 3-2 3.3.2 [MENU 4] sub menu 3-3 3.4 [MENU 2] menu. 3-5 3.4.1 [MODE] sub menu 3-5 3.4.2 [DISP 1] sub menu 3-6 3.4.3 [DISP 2] sub menu 3-6 3.4.4 [DISP 3] sub menu 3-7 3.5.4 How to set tide, tide differential and ship's speed alarms 3-10 3.5.2 How to set the trip alarm 3-13 3.5.4 How to disable/enable the audible alarm 3-14 3.5.5 How to cancel an alarm 3-15 4. MAINTENANCE & TROUBLESHOOTING 4-1 4.1 Maintenance 4-1 4.2 Troubleshooting 4-2 4.3 Diagnostics 4-3		2.5	Text Display	2-10
2.7 Error Display 2-11 3. MENU OPERATION 3-1 3.1 How to Operate Menu Window 3-1 3.2 Function Key 3-2 3.3 [MENU 1] menu 3-2 3.3.1 [MENU 3] sub menu 3-2 3.3.2 [MENU 4] sub menu 3-3 3.4 [MENU 2] menu 3-3 3.4.1 [MODE] sub menu 3-5 3.4.2 [DISP 1] sub menu 3-6 3.4.3 [DISP 2] sub menu 3-6 3.4.4 [DISP 3] sub menu 3-7 3.5.1 Alarm types 3-10 3.5.2 How to set tide, tide differential and ship's speed alarms 3-11 3.5.2 How to set the trip alarm 3-13 3.5.4 How to disable/enable the audible alarm 3-15 4. MAINTENANCE & TROUBLESHOOTING 4-1 4.1 Maintenance 4-1 4.2 Troubleshooting 4-2 4.3 Diagnostics 4-3		2.6	Echo Level Display	2-11
3. MENU OPERATION		2.7	Error Display	2-11
3.1 How to Operate Menu Window 3-1 3.2 Function Key 3-2 3.3 [MENU 1] menu 3-2 3.3.1 [MENU 3] sub menu 3-2 3.3.2 [MENU 4] sub menu 3-3 3.4 [MENU 2] menu 3-3 3.4 [MENU 2] menu 3-5 3.4.1 [MODE] sub menu 3-5 3.4.2 [DISP 1] sub menu 3-6 3.4.3 [DISP 2] sub menu 3-6 3.4.4 [DISP 3] sub menu 3-7 3.5.1 Alarm types 3-10 3.5.2 How to set tide, tide differential and ship's speed alarms 3-11 3.5.3 How to set the trip alarm 3-13 3.5.4 How to cancel an alarm 3-15 4. MAINTENANCE & TROUBLESHOOTING 4-1 4.1 Maintenance 4-1 4.2 Troubleshooting 4-2 4.3 Diagnostics 4-3	3	MFI		3-1
3.1 Function Key 3-2 3.2 [MENU 1] menu 3-2 3.3.1 [MENU 3] sub menu 3-2 3.3.2 [MENU 4] sub menu 3-3 3.4 [MENU 2] menu 3-5 3.4.1 [MODE] sub menu 3-5 3.4.2 [DISP 1] sub menu 3-6 3.4.3 [DISP 2] sub menu 3-6 3.4.4 [DISP 3] sub menu 3-7 3.5.1 Alarm types 3-10 3.5.2 How to set tide, tide differential and ship's speed alarms 3-10 3.5.2 How to set tide, tide differential and ship's speed alarms 3-11 3.5.3 How to set tide, tide differential and ship's speed alarms 3-13 3.5.4 How to disable/enable the audible alarm 3-14 3.5.5 How to cancel an alarm 3-15 4. MAINTENANCE & TROUBLESHOOTING 4-1 4.1 Maintenance 4-1 4.2 Troubleshooting 4-2 4.3 Diagnostics 4-3	0.	3 1	How to Operate Menu Window	3_1
3.3 [MENU 1] menu		3.2	Function Key	3_2
3.3.1 [MENU 3] sub menu 3-2 3.3.2 [MENU 4] sub menu 3-3 3.4 [MENU 2] menu 3-5 3.4.1 [MODE] sub menu 3-5 3.4.2 [DISP 1] sub menu 3-6 3.4.3 [DISP 2] sub menu 3-6 3.4.4 [DISP 3] sub menu 3-7 3.5.1 Alarm types 3-10 3.5.2 How to set tide, tide differential and ship's speed alarms 3-11 3.5.3 How to set the trip alarm 3-13 3.5.4 How to disable/enable the audible alarm 3-14 3.5.5 How to cancel an alarm 3-15 4. MAINTENANCE & TROUBLESHOOTING 4-1 4.1 Maintenance 4-1 4.2 Troubleshooting 4-2 4.3 Diagnostics 4-3		3.Z	IMENUL 11 menu	3_2
3.3.1 [MENU 4] sub menu		0.0	3 3 1 [MENU 3] sub menu	
3.4 [MENU 2] menu			3.3.2 [MENU /] sub menu	
3.4 [MDR0 2] menu 3-5 3.4.1 [MODE] sub menu 3-5 3.4.2 [DISP 1] sub menu 3-6 3.4.3 [DISP 2] sub menu 3-7 3.4.4 [DISP 3] sub menu 3-9 3.5 [ALARM] menu 3-10 3.5.1 Alarm types 3-10 3.5.2 How to set tide, tide differential and ship's speed alarms 3-11 3.5.3 How to set the trip alarm 3-13 3.5.4 How to disable/enable the audible alarm 3-14 3.5.5 How to cancel an alarm 3-15 4. MAINTENANCE & TROUBLESHOOTING 4-1 4.1 Maintenance 4-1 4.2 Troubleshooting 4-2 4.3 Diagnostics 4-3		3 /	IMENUL 21 menu	
3.4.1 [MODE] sub menu		5.4		
3.4.2 [DISP 1] sub menu 3-0 3.4.3 [DISP 2] sub menu 3-7 3.4.4 [DISP 3] sub menu 3-9 3.5 [ALARM] menu 3-10 3.5.1 Alarm types 3-10 3.5.2 How to set tide, tide differential and ship's speed alarms 3-11 3.5.3 How to set the trip alarm 3-13 3.5.4 How to disable/enable the audible alarm 3-14 3.5.5 How to cancel an alarm 3-15 4. MAINTENANCE & TROUBLESHOOTING 4-1 4.1 Maintenance 4-1 4.2 Troubleshooting 4-2 4.3 Diagnostics 4-3			2.4.2 [DISD 1] sub monu	
3.4.3 [DISP 2] sub menu 3-7 3.4.4 [DISP 3] sub menu 3-9 3.5 [ALARM] menu 3-10 3.5.1 Alarm types 3-10 3.5.2 How to set tide, tide differential and ship's speed alarms 3-11 3.5.2 How to set the trip alarm 3-13 3.5.4 How to disable/enable the audible alarm 3-13 3.5.5 How to cancel an alarm 3-15 4. MAINTENANCE & TROUBLESHOOTING 4-1 4.1 Maintenance 4-1 4.2 Troubleshooting 4-2 4.3 Diagnostics 4-3			2.4.2 [DISP 1] Sub menu	
3.4.4 [DISP 3] sub menu			3.4.3 [DISP 2] sub menu	
3.5 [ALARM] menu		<u>о г</u>		
3.5.1 Alarm types 3-10 3.5.2 How to set tide, tide differential and ship's speed alarms 3-11 3.5.3 How to set the trip alarm 3-13 3.5.4 How to disable/enable the audible alarm 3-14 3.5.5 How to cancel an alarm 3-15 4. MAINTENANCE & TROUBLESHOOTING 4-1 4.1 Maintenance 4-1 4.2 Troubleshooting 4-2 4.3 Diagnostics 4-3		3.5		3-10
3.5.2 How to set tide, tide differential and ship's speed alarms 3-11 3.5.3 How to set the trip alarm 3-13 3.5.4 How to disable/enable the audible alarm 3-14 3.5.5 How to cancel an alarm 3-15 4. MAINTENANCE & TROUBLESHOOTING 4-1 4.1 Maintenance 4-1 4.2 Troubleshooting 4-2 4.3 Diagnostics 4-3			3.5.1 Alarm types	3-10
3.5.3 How to set the trip alarm 3-13 3.5.4 How to disable/enable the audible alarm 3-14 3.5.5 How to cancel an alarm 3-15 4. MAINTENANCE & TROUBLESHOOTING 4-1 4.1 Maintenance 4-1 4.2 Troubleshooting 4-2 4.3 Diagnostics 4-3			3.5.2 How to set tide, tide differential and ship's speed alarms	3-11
3.5.4 How to disable/enable the audible alarm 3-14 3.5.5 How to cancel an alarm 3-15 4. MAINTENANCE & TROUBLESHOOTING 4-1 4.1 Maintenance 4-1 4.2 Troubleshooting 4-2 4.3 Diagnostics 4-3			3.5.3 How to set the trip alarm	3-13
3.5.5 How to cancel an alarm			3.5.4 How to disable/enable the audible alarm	3-14
4. MAINTENANCE & TROUBLESHOOTING 4-1 4.1 Maintenance 4-1 4.2 Troubleshooting 4-2 4.3 Diagnostics 4-3			3.5.5 How to cancel an alarm	3-15
4.1 Maintenance	4	MΔ	INTENANCE & TROUBLESHOOTING	<u></u> 1
4.2 Troubleshooting	••	4.1	Maintenance	
4.3 Diagnostics		4.2	Troubleshooting	
		4.3	Diagnostics	4-3

4.3.1	General test	4-3
4.3.2	Panel test	4-5
4.3.3	Test pattern	4-6
4.4 Error	Messages and Alerts	4-6
		٨٩.1
		AF-1
SPECIFICATI	ONS	SP-1
		INI_1

FOREWORD

A Word to the Owner of the CI-68

Congratulations on your choice of the FURUNO CI-68 Doppler Sonar Current Indicator. We are confident you will see why FURUNO has become synonymous with quality and reliability.

Since 1948, FURUNO Electric Company has enjoyed an enviable reputation for innovative and dependable marine electronics equipment. This dedication to excellence is furthered by our extensive global network of agents and dealers.

Your current indicator is designed and constructed to meet the rigorous demands of the marine environment. However, no machine can perform its intended function unless installed, operated and maintained properly. Please carefully read and follow the recommended procedures for operation and maintenance.

Thank you for considering and purchasing FURUNO equipment.

Features

- With heading data from a gyrocompass, satellite compass, etc., the absolute movements of tide measuring layers is displayed, in colors.
- When ground (bottom) reference is not available acoustically; namely, ship is in deep water, this equipment provides absolute movements of measuring layers by receiving position (or speed) data from a GPS navigator and heading data from a gyrocompass or satellite compass.
- Single-mold transducer plus compact monitor unit, control unit, transceiver unit and junction box (option) permit installation on small vessels.
- Data is displayed on a bright, non-fading 10.4 inch TFT LCD. Background color is selectable from three colors.
- Commercially available monitor may be used in lieu of the LCD monitor.
- Six display modes to discern tide movement from a variety of angles.
- Logical keyboard layout and menu structure for intuitive operation. Function key provides shortcut menu operation.
- Triple-beam system for automatic error compensation against pitching and rolling.
- Echo level continuously displayed on the screen, for monitoring signal conditions on three sounding beams.
- Bottom echo can be found using external depth data. Further, the bottom echo can be acquired manually by monitoring the echo level display. This is useful when in deep seas, air bubbles block reception of the bottom echo, or a thick layer of plankton or a large fish school is mistakenly tracked as the bottom echo.
- Various alarms: tide, tide differential, speed, trip, etc. Audible and visual alerts are released if alarm condition is violated.
- Graph display shows past current data.
- Water temperature graph helps locate current rip. (Temperature sensor required.)

CE/UKCA declaration

With regards to CE/UKCA declarations, please refer to our website (www.furuno.com), for further information about RoHS conformity declarations.

Disclosure of Information about China RoHS

With regards to China RoHS information for our products, please refer to our website (www.furuno.com).

SYSTEM CONFIGURATION



DISPLAY EXAMPLE



Tide vector display

Solid line: The speed and direction of the tide

- Tide vector for Layer 1 (LYR1) : Yellow
- Tide vector for Layer 2 (LYR2) : Purple
- Tide vector for Layer 3 (LYR3) : Blue
- Tide vector for Layer 4 (LYR4) : Green
- Tide vector for Layer 5 (LYR5) : Grey (Black when the setting for [BACKGROUND CLR] is white.)

Two-color line: The speed and direction of the differential tide

Dashed line (White or Black): Heading

Dashed line (Green): Ship's speed and course

This page is intentionally left blank.

1. OPERATIONAL OVERVIEW

1.1 Controls



Control unit

Control	Function				
POWER	Turns power on or off.				
F1	Function key (menu shortcut keys)				
LYR1 – LYR5	Set tide measuring depths for respective layers.				
Setting Knob	Sets measuring depth and range.				
RANGE	Sets range. The range which can be set depends on mode.				
TRACK MODE	Chooses tracking mode among ground, water (or nav) and auto.				
DISP MODE	Chooses a display mode.				
BRILL	Adjusts brilliance of LCD.				
MENU	Opens and closes the menu.				
CursorPad	Chooses menu items and options.				
	 Increases or decreases numerical setting on menus and pop-up windows. Silences audible alarm. 				

1.2 How to Turn the Power On/Off

Power ON

Press the **POWER** switch at the left hand side of the control unit to turn the power on. A beep sounds, the equipment turns on, and the lamp above the switch lights. The equipment conducts the diagnostic test to check for proper operation between the transceiver unit and the control unit and displays the results. After the diagnostic test is completed the last-used display appears.

CI-68 CI-6888 Starter. 6653000-xx.xx Booter1. 6653001-xx.xx Booter2. 6653001-xx.xx VOL. 6653002-xx.xx FPGA. 6653004-xx.xx MEM. 1 2 3 4 OK
CI-6810 VOL. 6651202-xx.xx TBL. MEM. 1 2 3 4 5 6 7 8 OK ANA. 12V;12.03V BV;110.0V TRM. +25.02 deg. DSW. 00 00 00 01 DSW 00 00 01

XX: Program Version No.

Diagnostic test

Note: The example screens shown in this manual may not match the screens you see on your display. The screen you see depends on your system configuration and equipment settings.

Power Off

To turn the power off, press the **POWER** switch again.

Note: The NAV mode measures tides in deep waters where ground tracking is not available. To use this function effectively, accurate heading data (from a gyrocompass, satellite compass) is necessary. For further details, see section 1.8.

1.3 How to adjust the LCD Brilliance and Panel Dimmer

LCD Brilliance

You can adjust the brilliance of the FURUNO-supplied monitor (MU-100C/MU-100C-CI) as below. When you adjust the brilliance of a commercial monitor, the **BRILL** key is not available.

1. Press the **BRILL** key to open the brilliance adjustment window.



Note: Execute the next step within five seconds after displaying the brilliance adjustment window. Otherwise the window is erased.

Press ► or ▲ to raise the brilliance; ◄ or ▼ to lower it. The brilliance may also be adjusted by pressing the BRILL key. In this case, brilliance is adjusted cyclically (8 steps): 0 → 1 → ... → 7 → 7 → 6 ... 0 →.

Panel Dimmer

You can adjust the backlighting for the control panel with [PANEL DIMMER] on the [MENU 4] sub menu. See subsection 3.3.2.

1.4 How to Choose a Display

This current indicator has six main displays: tide vector display, ship's speed display, course plot display, text display, echo level display and graph display. For the details for each display, see chapter 2.

You may choose a display by pressing the **DISP MODE** key. The display, which is selected [ON] on [MODE] sub menu, is shown on the screen. See subsection 3.4.1

1.4.1 Tide vector display

The tide vector display mainly shows tide speed and direction for five layers with a vector.



*: Sensor required.

1.4.2 Ship's speed display

The ship's speed display shows ship's fore-aft and port-starboard speeds in analog and digital form.



*: See subsection 1.4.1

1.4.3 Graph display

The graph display plots water temperature and depth data in graph form.



1.4.4 Course plot display

The course plot display plots ship's track along with tide vectors.



1.4.5 Text display

The text display provides various nav data in digital format.

HEADING MODE 45.0° GT SPEED/COURSE 12.3 ^{kn} 150°	6T SPEED 0RIFT 9.9 ^{kn}	 Port-Starboard Speed Drift Angle
TIDE SPEED/VECTOR ¹¹ 2 ⁿ 1.1 ^{kn} 130° ²¹ 2 ⁿ 1.2 ^{kn} 202°	^{TIDE DIFF} ^{1→2} 1.6 ^{kn} 160° ^{1→5} 1.7 ^{kn} 100°	— Tide Differential
 3 1.3^{kn} 27⁴ 4 1.4^{kn} 346° 5 1.5^{kn} 58° 	DEPTH(INTERNAL) 150.6 M TEMPERATURE 13.0 °C TRIP 16058.13 M	 Depth Water Temperature** Trip Distance
Text Window*)	

Fore-Aft Speed

*: See subsection 1.4.1. **: Sensor required.

1.4.6 Echo level display

The echo level display shows the strength of the echoes captured by three sounding beams. Note that [ECHO LEVEL] in the [MODE] sub menu must be set to [ON] to show the echo level display.



*: See subsection 1.4.1.

1.5 How to Set the Measuring Depth

Set the depths at which you wish to measure tide speed and direction as below.

Note: The layer 5 cannot be set when [BTM TIDE TRACK] in the [MENU 4] sub menu is set to [ON] (see subsection 3.3.2).

 Press the LYR1, LYR2, LYR3, LYR4, or LYR5 key as appropriate to show the depth setting window shown right. Note: This window disappears when there is no operation for five seconds.



2. Operate the Setting Knob or the CursorPad to set depth of measurement. The setting range is 2-400 (meters).

Setting Knob: Rotate clockwise to raise the range; counterclockwise to lower the range.

CursorPad: Press \blacktriangleright or \blacktriangle to raise the range; \blacktriangleleft or \triangledown to lower the range.

1.6 How to Choose Speed Tracking Mode

The tracking mode is available in ground tracking, water tracking, NAV and Auto/External.

Tracking mode		Contents
GT (Ground tracking)	Absolute ship and tide move- ments based on ground and current (tide display (bottom echo must be present).	Ship's movement based on ground Tide of layer Bottom
WT (Water tracking)	Ship and tide movements rela- tive to near-surface water and tide differential between tide layers. (The pulse length in this mode must be [NORMAL] and depth greater than 40 m, or LONG pulse length and depth greater than 70 m.)	Ship's movement relative to surface water Tide of layer relative to surface water Layer
NAV	Ship's movement as mea- sured by a navigation device and tide movements based on nav speed data. Note: The accuracy of tide measurement in the NAV mode depends heavily on gy- rocompass accuracy.	Ship's movement measured by using satellites (Based on ground) GPS Satellites Tide of layer Layer
AUTO/EXT* (Exter- nal)	Uses ground tracking mode wh water tracking mode (or [NAV] r echo is continuously sought, an restored. *: [EXT] appears in the tracking SOURCE] in the [OTHER] su shown based on the water de are detected, the currents wil	en bottom echo is available and switches to mode) when bottom echo is lost. The bottom ad if re-acquired the ground tracking mode is mode window (top left corner) when [DEPTH ub menu. When set to [EXT], currents are epth entered. However, if no bottom echoes Il not be shown.

Overview of Tracking Mode

To choose the tracking mode, press the **TRACK MODE** key. The tracking mode changes according to the setting ([OFF] or [ON]) of [NAV MODE] in the [MENU 4] sub menu. The current tracking mode appears at the top left-hand corner on the screen.

In case of [OFF] of [NAV MODE]

The tracking mode changes cyclically in the sequence of ground tracking, water tracking and auto (or external).

In case of [ON] of [NAV MODE]

The tracking mode changes cyclically in the sequence of ground tracking, nav and auto (or external).

1.7 How to choose the Range

You may choose the speed range by pressing the **RANGE** key. Also, you can change the range setting on the menu.

 Press the **RANGE** key to show the range setting window. The window shown right appears (ex. range setting window for tide vector display).
 Note: This window disappears when there is no operation for five seconds.



- 2. Operate the Setting Knob or the CursorPad to set the range.
 - Setting Knob: Rotate clockwise to raise the range; counterclockwise to lower the range.
 - CursorPad: Press \blacktriangleright or \blacktriangle to raise the range; \blacktriangleleft or \triangledown to lower the range.

Display	Range	Menu operation
Tide vector	Tide speed range setting window appears. Set tide/tide differen- tial range (radius of vector display ring) appropriately.	[TIDE RANGE] (subsection 3.4.1)
	Setting range: 0.5 kn, 1.0 kn, 1.5 kn, 2.0 kn, 3.0 kn, 5.0 kn, 10.0 kn	()
Ship's speed	The ship's speed range setting window shown depends on whether [SCALE SYNC] in the [DISP 2] sub menu is set to [ON] or [OFF]. [ON]: Port-starboard and fore-aft speeds are synchronized. The ship's speed range setting window appears. Set speed appropri- ately. [OFF]: The ship's speed range setting window appears. Set fore- aft speed appropriately. Setting range: 0.5 kn, 1.0 kn, 2.0 kn, 3.0 kn, 5.0 kn, 10.0 kn, 20.0 kn, 30.0 kn	[SCALE SYNC] [DRIFT SCALE] [SCALE] (subsection 3.4.3)
Graph	The speed range setting window shown depends on the setting of [MODE] in the [DISP 2] sub menu. See subsection 3.4.4. [TIDE], [TIDE DIF]: The tide speed range setting window ap- pears. Set tide speed range (port-starboard of tide speed/tide dif- ferential graph) appropriately. Setting range: 0.5 kn, 1.0 kn, 1.5 kn, 2.0 kn, 3.0 kn, 5.0 kn, 10.0 kn [SHIP SPD]: The ship's speed range setting window appears. Set ship's speed range (fore-aft of ship's speed graph) appropriately. Setting range: 0.5 kn, 1.0 kn, 2.0 kn, 3.0 kn, 5.0 kn, 10.0 kn, 20.0 kn, 30.0 kn	[TIDE RANGE] (subsection 3.4.1)
Course plot	The display scale setting window appears. Set display scale as appropriate. Setting range: 1:10,000, 1:20,000, 1:50,000, 1:100,000	[SCALE] (subsection 3.4.3)
Echo level	Tide speed range setting window appears. Set tide and tide dif- ferential range (radius of vector display ring) appropriately. Setting range: 0.5 kn, 1.0 kn, 1.5 kn, 2.0 kn, 3.0 kn, 5.0 kn, 10.0 kn	[TIDE RANGE] (subsection 3.4.1)

Display and range to set

Note: The RANGE key is not available on the Text display.

1.8 How to Set the Ship's Heading

The current indicator has a NAV mode which measures tides in deep waters where ground tracking is not available. To achieve reliable measurements, however, you must feed accurate heading (gyro) data and ship's position (or speed and course) data to the current indicator.

- 1. Confirm that the gyro has settled and all necessary compensations (latitude compensation, weather compensation, etc.) have been made correctly.
- 2. Adjust the AD Converter to show the same reading shown on the master gyrocompass. Do not make the adjustment while the ship is turning.



If the gyro reading is accurate, the current indicator will provide accurate tide information. If gyro data is wrong, the following symptoms will appear.

 The drift angle in the ground tracking mode is not the same as that in the nav mode or is shown in the direction reverse of the actual direction.
 Drift angle in ground tracking mode: Difference between ground speed and course and gyro heading.
 Drift angle in pay mode: Difference between pay equipation and gyro heading.

Drift angle in nav mode: Difference between nav course and gyro heading.

• Tide speed and direction in the ground mode is not the same as that in the nav mode. And the tide correlation (relative angle, size) between layers is different.



If you encounter such symptoms calibrate the current indicator as shown in the installation manual.

2. INTERPRETING THE DISPLAYS

2.1 Tide Vector Display



- Solid line: The speed and direction of the tide.
 - (LYR1: yellow, LYR2: purple, LYR3: blue, LYR4: green,
 - LYR5: grey**)
- Two-color line: The speed and direction of the differential tide.
- Dashed line (white or black): Heading



<u>Heading</u>

Ship's heading fed from a heading sensor.

<u>Mode</u>

Shows current tracking mode, as selected with the **TRACK MODE** key. See section 1.6.

Mode marker

Shows tracking mode and echo availability for last three minutes, scrolling from right to left. The color represents tracking mode as shown right.



Green: Ground tracking mode Blue: Water tracking mode, Nav mode Back ground: Speed error



Speed/course

Speed made good and true course are shown. The displayable range is 0.0 to 40.0 kn for speed and 0° to 359° for course.



Tide speed and direction

Tide speed and direction is shown for five layers (measuring depths). The displayable range is 0.0 to 9.9 kn for speed and 0° to 359° for course. The depth of each layer is shown at the right or lower-right of the layer number. The figure shown right is an example of the tide vector display. Data shown depends on the measuring mode as follows;



- **Ground tracking mode**: Speed and direction values of measuring layers represent movement of layer relative to ground.
- Water tracking mode: Speed and direction values of measuring layers represent movement of layer relative to near-surface water.
- Nav mode: Speed and direction values represent movement of measuring layers relative to pseudo ground. Required the ship's speed data from an external equipment.

Tide differential

Tide speed and direction differential are shown between basic layer and the reference layer. The displayable range is 0.0 to 9.9 kn for speed and 0° to 359° for course. The basic layer and the reference layer are selected with [REF TIDE DIFF] and [TIDE DIFF1 (2)] on the [MENU 3] sub menu. For example, if the basic layer is layer 1 and the reference ones are layer 4/layer 5, the tide differential between layer 1 and layer 4/layer 5 will be displayed.



Water temperature

Water temperature is shown if a water temperature sensor is connected to the current indicator. The display range is -5.00 to 99.99 (°C).

Water temperature graph

Water temperature over the latest 15 minutes is displayed with a blue line, the data scrolling from right to left. The range of the temperature scale is 5°C and the range of the time scale is 15 minutes.



Heading line

The heading line is a dashed line (white) which shows ship's heading. It extends from ship's position (center of vector display) to the edge of the vector display. When the back color of the display is set "WHITE", the heading line is shown in black, see "BACKGROUND CLR" on page 3-5. You can hide the heading line, see "HEADING LINE" on page 3-6.

Note: If the heading line overlap on the ship's speed vector, ship's speed vector has higher priority so the heading line is hidden.

Tide/Tide differential vector

Tide speed and direction for five layers are shown in the tide vector circle. Also, the two tide differential are shown. You can hide their vector, see "TIDE VECTOR (LAYER 1 to LAYER 5)" on page 3-6.

Note 1: if vectors overlap, the vector of the highest layer is shown.

Note 2: The basic layer



and reference layer are set on the [MENU 3] sub menu, see subsection 3.4.2.



*: Black when the setting for [BACKGROUND CLR] is white. See "BACKGROUND CLR" on page 3-5.

Ship's speed vector

The ship's speed vector may be shown in green dashed line on the vector display. You can hide this vector, see "SHIP SPD VCTR" on page 3-6.

<u>Range</u>

The maximum range for the tide vector circle is shown. You may set with [TIDE RANGE] on the [DISP 1] sub menu, or **RANGE** key.

Drift data

The drift angle and the fore-aft/port-starboard speed are shown. The port-starboard speed is also shown as a graph. The unit for the port-starboard speed graph is kn (knot). The maximum speed which the speed graph can show is 3 kn. Speeds over 3 kn are displayed as a full-graph bar, fixed at 3 kn.



Tide average setting

The average time for measuring the tide speed and direction is shown. You can set this setting with [TIDE AVERAGE] on the [MENU 3] sub menu.

Echo level*

The echo level display shows echo level for the three sounding beams in colors or graph depending on the setting of [DISP MODE] in the [DISP 2] sub menu.

Echo display range*

The echo is shown in this setting value. You can set the value with [ECHO RANGE] on the [MENU 4] sub menu.

*: You can turn this display on or off with [ECHO LEVEL] on the [DISP 2] sub menu.

2.2 Ship's Speed Display



Text window

The contents are same as ones for the tide vector display, see section 2.1.

Ship's speed* (In GT, WT) or Water tracking speed (In NAV mode)

Port-starboard and fore-aft speeds are synchronized when [SCALE SYNC] in the [DISP 2] menu is set to [ON]. The available speed setting range is 0.0 to 40.0 kn.

Fore-aft speed*

Speed in the fore-aft direction. The speed setting range is 0.0 to 9.9 kn. Fore speed is denoted with a yellow " \blacktriangle " above the speed readout and aft speed with a yellow " \blacktriangledown " below the speed readout.

Port-starboard speed*

Speed in the port-starboard direction. The speed setting range is 0.0 to 40.0 kn. Port speed is denoted with a red " \blacktriangleleft " to the left of the speed readout and starboard speed with a green " \blacktriangleright " to the right of the speed readout.

Drift angle*

The angle measured in degrees between ship's heading and the actual movement. When drift angle is to port, a red "◀" appears and when it is to starboard a green "▶" appears. In the NAV mode, drift in water tracking speed is shown.

<u>Trip</u>

Shows trip distance. The distance is referenced to the setting of [LOG PULSE OUT] in the [I/O] sub menu. See the installation manual for the details.

Own ship vector*

The own ship vector shows port-starboard speed on the x-axis and fore-aft speed on the y-axis. The synthesized speed vector (green) appears when [SCALE SYNC] on the [DISP 2] sub menu is set to [ON].

Fore-aft speed history graph

This graph shows fore-aft speed history over time, which is useful in trawling. [HISTO-RY] in the [DISP 2] sub menu sets the maximum range for the graph, and you can shift the range with [HISTORY SHIFT] in the [DISP 2] sub menu. The latest 60 seconds of fore-aft speed is shown, scrolling from right to left across the screen so the right edge of the graph displays the latest data.

Port-starboard history graph

This graph shows port-starboard speed history over time, which is useful in trawling. [DRIFT HISTORY] in the [DISP 2] sub menu sets the maximum range for the graph. The latest 60 seconds of port-starboard speed is shown, scrolling from top to bottom on the screen so the upper edge of the graph displays the latest data.

*: Speed used for calculation depends on setting of [SHIP SPD MODE] in the [DISP 1] sub menu. See "SHIP SPD MODE" on page 3-7.



2.3 Graph Display

Text window

The contents are same as ones for the tide vector display, see section 2.1. The text window may be turned on or off with [TEXT WINDOW] in the [DISP 2] sub menu. When the text window is turned off, 12 hours of graph data are shown.

Tide (or tide differential, speed) graph

The two graphs (speed and direction) are shown. You may choose the target data to display as graph among tide, tide differential and ship, see "MODE" on page 3-7.

For a tide graph, the five lines for each layer are shown in the each color; Layer1: Yellow, Layer 2: Purple, Layer 3: Blue, Layer 4: Green, Layer 5: Grey. For a tide differential graph, the two lines of the reference layers are shown. For example, when the reference layers are Layer 4 and Layer 5, the line colors are green and grey.

The maximum range for the speed (upper graph) is set with [TIDE RANGE] in the [DISP 1] sub menu. The display style for the direction (lower graph) is set with [TIDE GRAPH] in the [DISP 2] sub menu.

Note: The color for Layer is black when the setting for [BACKGROUND CLR] is white, See "BACKGROUND CLR" on page 3-5.

Water temperature graph

The scale of the water temperature graph is 5 °C width. You can hide this graph, see "TEMP GRAPH" on page 3-8.

2. INTERPRETING THE DISPLAYS

Mode marker

The mode marker shows by color which tracking mode is in use. This marker has longer history than the mode marker in the text window, see "Mode marker" on page 2-1.

Depth graph

The depth graph displays depth data in graph form. If, in the water tracking mode, the depth is greater than the depth range no depth data is displayed. To graph depth from an external source, set [DEPTH SOURCE] in the [OTHER] sub menu (sub menu in the installation menu) to [EXTERNAL], see installation manual for details.

Trip distance marker

The trip distance marker shows trip distance in one-mile increments, in green and background color alternately as shown below.



2.4 Course Plot Display



Text window

The contents are same as ones for the tide vector display, see section 2.1. The text window may be turned on or off with [TEXT WINDOW] in the [DISP 3] sub menu. When the text window is turned off, the amount of track displayed is greater.

Ship's track

Ship's track is drawn with a white solid line. Ship's track starts extending from the screen center and when own ship position reaches the edge of the screen it is brought back to the screen center. The ship's track history is saved in three laps display width. You can hide this track, see "SHIP TRACK" on page 3-9.

Tide vector

The five vectors for each layer are shown in each color. The interval to display the vectors depends on the setting for the tide display interval described below. You can hide each vector, see "TIDE VECTOR (LAYER 1 to LAYER 5)" on page 3-6.

North mark

The north mark points upward on the course plot display.

<u>Scale</u>

You may choose the scale with [SCALE] in the [DISP 3] sub menu.

<u>DIV</u>

Shows range per scale division.

Tide display interval

You may change the interval to display the tide vectors in the plot display. For example, if the this value is 2.0, the tide vectors are shown each two scales. Accordingly you can see the actual distance between the tide vectors by the value of [DIV], see "INTERVAL" on page 3-9.

Position

Position which is input from the plotter is shown in latitude and longitude.

2.5 Text Display



Text Window

*: Sensor required.

Text window, Water Temperature

The contents are same as ones for the tide vector display, see section 2.1.

Note: Shows tracking mode and echo availability for last seven and half minutes, scrolling from right to left.

Fore-Aft Speed, Port-starboard speed, Drift Angle, Tide Differential and Trip Distance

The contents are same as ones for the tide vector display, see section 2.2.

<u>Depth</u>

The depth is different according to the setting of [DEPTH SOURCE] in the [DISP 3] sub menu, "DEPTH SOURCE" on page 3-9.

[DEPTH (INTERNAL)]: THe depth value calculated in the current indicator [DEPTH (EXTERNAL)]: The depth value from the external equipment

2.6 Echo Level Display



Text Window, Tide Differential and Tide Vector

The contents are same as ones for the tide vector display, see section 2.1.

Echo Level

Echo status of beam 1 (fore), beam 2 (starboard) and beam 3 (port) is displayed in eight colors. The strongest echo is shown in reddish brown. For the setting of display color, see "TVG" and "GAIN" in subsection 3.3.2.

Echo Display Range

The echo is shown to a depth of this setting value. The echo display range can be set with [ECHO RANGE] in the [MENU 4] sub menu.

2.7 Error Display

An error display (small red square) is generated whenever display data or measured data is abnormal. When this occurs the corresponding data will be unreliable.

Speed and course (fore-aft, port-starboard, drift angle)

	For tide vector (Echo level is displayed), speed, graph and course plot displays	For tide vector (Echo level is not displayed), text and echo level displays
SPD/CSE	1) No data input from transceiver unit SPD/CSE kn WNW 12.3 333 2) Ship's speed error	1) No data input from transceiver unit SPD/CSE 12.3 333° 2) Ship's speed error



- 1) No data is being input from the transceiver unit to the display unit. If this occurs, call for a service.
- 2) This display appears when the ground tracking echo for ground tracking, reference layer for water tracking or GPS data from the GPS navigator is abnormal. In this case data is not reliable.

Tide for five layers/tide differential



- 1) Displayed when echo for a measuring layer is not present. The readout for the offending measuring layer is not reliable.
- Displayed when the depth setting for a measuring layer is improper. The readout for the offending measuring layer is not reliable. <u>Improper depth setting conditions</u>
 - Depth in ground tracking mode is less than 10 m.
 - Depth setting is more than 75% of actual depth.
 - Echo cannot be obtained because of air bubbles, etc.
 - Echo for set depth cannot be found because depth has become deeper than set depth.

2. INTERPRETING THE DISPLAYS

This page is intentionally left blank.

There are four menus, [MENU 1], [MENU 2], [ALARM] and [INSTALLATION], in main menu. Each main menu has some sub menus. For [INSTALLATION], see the installation manual.

3.1 How to Operate Menu Window

Please refer to all menu items on "MENUTREE" on page AP-1.

1. Press the **MENU** key to open the menu. The last-used menu appears.

Main menu title

MENU 1	MENU 2	ALAF	RM II	NSTALLATION
	MODE	DISP 1	DISP 2	DISP 3
TIDE VECTOR SHIP SPEED GRAPH COURSE PLOT TEXT ECHO LEVEL BACKGROUNE	: : : : : : : : : : : : : : : : : : :	OFF C OFF C OFF C OFF C OFF C OFF C LACK WHI	N N N N N TE BLU	E
MENU ON DIS	PLAY SET1	TINGS. HANGE, IME		
	MENU 1 TIDE VECTOR SHIP SPEED GRAPH COURSE PLOT TEXT ECHO LEVEL BACKGROUNE MENU ON DIS [▲/▼]:SELECT	MENU 1 MENU 2 MODE TIDE VECTOR : SHIP SPEED : GRAPH : COURSE PLOT : TEXT : ECHO LEVEL : BACKGROUND CLR : BACKGROUND CLR : BACKGROUND SETT [▲/▼]:SELECT, [◀/▶]: CI	MENU 1 MENU 2 ALAF MODE DISP 1 TIDE VECTOR : OFF C SHIP SPEED : OFF C GRAPH : OFF C COURSE PLOT : OFF C TEXT : OFF C BACKGROUND CLR : BLACK WHI MENU ON DISPLAY SETTINGS. [▲/▼]:SELECT, [◄/▶]: CHANGE, [ME	MENU 2 ALARM In MODE DISP 1 DISP 2 TIDE VECTOR : OFF ON SHIP SPEED : OFF ON GRAPH : OFF ON COURSE PLOT : OFF ON TEXT : OFF ON ECHO LEVEL : OFF ON BACKGROUND CLR : BLACK WHITE BLU MENU ON DISPLAY SETTINGS. : EXIT

- 2. Press \blacktriangle to place the cursor on the main menu title field.
- Press ◄ or ► to choose the main menu desired. Then, the sub menus change according to the main menu. To choose a sub menu, press ▼ to choose the sub menu title field and then press ◀ or ► to choose the setting desired.
 Note: The [INSTALLATION] menu is locked to prevent unintentional adjustment of its settings. When you move the cursor from [ALARM] to [INSTALLATION], the following message appears. To open the [INSTALLATION] menu, press the [F1] key.

PRESS FUNC KEY TO OPEN INSTALLATION MENU. PRESS [MENU] KEY TO OPEN ALARM MENU.

- 4. Press ▲ or ▼ to choose menu item desired. Selected item is displayed in reverse video and menu help appears in the box at the bottom of the menu.
- 5. Press ◀ or ► to choose menu option or change numerical value. To change numerical value, press ► to raise the value; ◀ to lower the value.
- 6. Press the [MENU] key to close the menu.

3.2 Function Key

The F1 key provides menu shortcut operation. You may program the key as follows:

How to use the function key

To press the **F1** key displays the setting window programmed. This function key is not programmed at the factory. If it contains no program when pressed, the message "NO FUNCTION ASSIGNED TO [F1] KEY." appears on the display for about five seconds.

Note: When there is no operation for five seconds, the setting window disappears automatically.

How to program the function key

- 1. Press the **MENU** key to display the main menu.
- 2. Press ▲ to place the cursor on the main menu title field.
- 3. Press ◀ or ► to choose a main menu desired. If needed, press ▼ and then ◀ or ► to choose a desired sub menu.
- 4. Press ▲ or ▼ to choose a menu item programmed (or changed).
- 5. Press and hold down for more than three seconds the **F1** key until you hear three beeps and the message "PROGRAMMED SELECTED ITEM TO [F1] KEY" is displayed (about five seconds).
- 6. Press the **MENU** key to close the menu.

Note: The menus which you can not program to the F1 key is shown below.

- [ALARM] menu [BOTTOM SEARCH] menu ([MENU 4] sub menu)
- [INSTALLATION] menu [RESET TRIP LOG] menu ([MENU 4] sub menu)
 - [TEST] menu ([MENU 4] sub menu)

3.3 [MENU 1] menu

This menu mainly provides items for adjustment of tide parameters.

3.3.1 [MENU 3] sub menu

MENU 1 ME	NU	J2 AL	ARM	INSTALLATION	١
MENU 3 MEN	U	4			
SHIP SPEED AVG	:	15 sec	30 sec	60 sec	90 sec
TIDE AVERAGE	:	2 min			
REF TIDE DIFF	:	LAYER 1			
TIDE DIFF 1	:	LAYER 2			
TIDE DIFF 2	:	LAYER 5			
BEARING MODE	:	32 CMPS	360 TRUE		

[MENU 3] sub menu

SHIP SPEED AVG

Choose the averaging time for the ship's speed display.

TIDE AVERAGE

Choose the averaging time for the tide display. If tide speed appears to be too slow, choose a higher setting.

REF TIDE DIFF

Choose the basic layer for tide differential measurements.

TIDE DIFF 1 (2)

Choose the reference layer for tide differential measurements. You can choose the same layers for [REF TIDE DIFF] and [TIDE DIFF 1 (2)]. If this case, the tide speed and directions are displayed "0".

BEARING MODE

You may show bearing in 32 compass points or 360 degrees.



360 TRUE



3.3.2 [MENU 4] sub menu



[MENU 4] sub menu

NAV MODE

Choose [ON] to use NAV mode instead of the water tracking mode. For further details, see section 1.6.

BOTTOM SEARCH

BOTTOM SEARCH enables requisition of temporarily lost ground echo, in the water tracking mode (see section 1.6). When the bottom echo is lost for a short while due to

air bubbles, or the equipment tends to track on false bottom, acquire the bottom echo manually as follows.

- 1. Press ► to set [YES] for [BOTTOM SEARCH]. Then the message "PRESS FUNCTION KEY TO EXCUTE" appears.
- 2. Press the **F1** key. The menu window disappears and the depth rectangle (green) appears along with the echo level display.
- 3. Press ▲ or ▼ to set the depth rectangle on the bottom echo.
- 4. Press the **MENU** key to finish.



BTM TIDE TRACK

Set [ON] to measure depth of layer 5 changes automatically with the bottom depth to track on near-bottom tide in the ground tracking mode,. In this case the layer 5 indications shows "BTTM" instead of the tide measurement depth.

ALM/KEY BEEP

A key beeps to confirm correct key input, input error or error message. You may turn this beep on or off as desired. The beep sounds when an alarm setting is violated regardless of whether this item is turned on or off (see section 3.5).

WT SPD DEPTH

Set the reference depth at which to measure ship's speed in the water tracking mode. Set the depth for which you want to know the water tracking speed in reference to a specific depth. The setting range is 2-400 (m).

RESET TRIP LOG

Set the trip distance to zero (0). Choose [YES] and then you are prompted "PRESS FUNCTION KEY TO EXECUTE." Press the **F1** key to reset the trip log to zero.

<u>TEST</u>

Choose the diagnostic test to execute: General (program no. display, memory check, etc.), panel or pattern. For further details, see section 4.3.

ECHO RANGE

Choose the maximum depth to display echoes, from among 50, 100, 150, 200, 250, 300, 350, 400, 450, 500 (m).

<u>TVG</u>

Turn echo TVG on or off.

<u>GAIN</u>

Adjust echo level display color. The higher the digit the nearer to the strongest color (reddish brown). This menu does not adjust the gain of the received signal; speed and tide values are not affected by this adjustment. The setting range is 1-40.

PANEL DIMMER

Adjust the backlighting for the control panel, from 0-7. The higher the value, the brighter the backlighting.

3.4 [MENU 2] menu

You can set the screen setting on the [MENU 2] menu. There are four sub menus; [MODE], [DISP 1], [DISP 2] and [DISP 3].

3.4.1 [MODE] sub menu

Note: The display which you set [OFF] on this sub menu, does not appear with the **DISP MODE** key. Also, you do not set [OFF] for all displays.

MENU 1	MENU 2			ALARM		INSTALL	ATION
	MOD		DIS	SP 1	DISP 2	DISF	o 3
TIDE VECTOR		:	OFF	ON			
SHIP SPEED		:	OFF	ON			
GRAPH		:	OFF	ON			
COURSE PLOT	Г	:	OFF	ON			
TEXT		:	OFF	ON			
ECHO LEVEL		:	OFF	ON			
BACKGROUNE	O CLR	: E	BLACK	WHITE	BLU	JE	

[MODE] sub menu

TIDE VECTOR

Enable or disable the tide vector display.

SHIP SPEED

Enable or disable the ship's speed display.

<u>GRAPH</u>

Enable or disable the tide graph display.

COURSE PLOT

Enable or disable the course plot display.

<u>TEXT</u>

Enable or disable the text display.

ECHO LEVEL

Enable or disable the echo level display.

BACKGROUND CLR

Choose the background color from among black, white and blue.

3.4.2 [DISP 1] sub menu

MENU 1	MENU	J 2	AL	ARM	INSTALLATION
	MOD	E	DISP 1	DISP 2	2 DISP 3
COMMON	SETTINGS				
TIDE RAN	GE	:	3.0kn		
SHIP SPD	VCTR	:	OFF	ON	
HEADING	LINE	:	OFF	ON	
TIDE VECT	OR				
LAYER 1		:	OFF	ON	
LAYER 2		:	OFF	ON	
LAYER 3		:	OFF	ON	
LAYER 4		:	OFF	ON	
LAYER 5		:	OFF	ON	
TIDE DIFI	=	:	OFF	ON	
DISPLAY M	ODE	: HEA		NORTH UP	
SHIP SPD I	NODE	: G	T/WT	WT	

[DISP 1] sub menu

TIDE RANGE

Set the tide range for the tide vector display, graph display and echo level display.

SHIP SPD VCTR

Turn the ship's speed vector on or off on the tide vector display and echo level display.

HEADING LINE

Turn the heading line on or off on the tide vector display and echo level display.

TIDE VECTOR (LAYER 1 to LAYER 5)

Turn the tide vector on or off for the respective layer on the tide vector display, course plot display and echo level display.

TIDE DIFF

Turn the tide vector on or off for the respective item on the tide vector display and echo level display.

DISPLAY MODE

Set display orientation for head-up or north-up. Heading device required for North-up.



SHIP SPD MODE

Choose the ship's speed to use to display drift angle, fore-aft speed and port-starboard speed on the ship's speed display and text display.

[GT/WT]: Displays the speed over ground in the ground tracking mode, the speed towards water in the water tracking mode.

[WT]: Displays the speed towards water regardless of the tracking mode.

MENU 1 MENU 2 ALARM INSTALLATION DISP 2 MODE DISP 1 DISP 3 GRAPH TIDE DIF SHIP SPD MODE TIDE 5 graph SOUTH **TIDE GRAPH** NORTH ÷ display settings **TEMP GRAPH** ÷ OFF ON TEXT WINDOW OFF ON ÷ TIDE VECTOR Tide vector ECHO LEVEL OFF ON ÷ display settings : SOUNDER **DISP MODE** GRAPH SHIP SPEED SCALE SYNC OFF ON ÷ DRIFT SCALE : 1.0 kn Ship's speed 10.0 kn SCALE : display settings **DRIFT HISTORY** 0.5 kn 5 1 kn 2 kn HISTORY 8 kn 16 kn 4 kn 32 kn **HISTORY SHIFT** 0 kn :

3.4.3 [DISP 2] sub menu

[DISP 2] sub menu

<u>MODE</u>

Choose the item to show on the graph display, among tide, tide differential and ship's speed.

3. MENU OPERATION

<u>TIDE GRAPH</u>

Choose how to draw the tide on the graph display. The choices are [NORTH] (N, E, S, W) and [SOUTH] (S, W, N, E). Normally, use [NORTH]. When the graph becomes difficult to read switch to [SOUTH].

TEMP GRAPH

Turn the water temperature graph on the graph display on or off.

TEXT WINDOW

Turn the text window on the graph display on or off.

ECHO LEVEL

Turn the echo level display on or off on the tide vector display.

DISP MODE

This menu is available when you set [ON] in the [ECHO LEVEL].

[SOUNDER]: Echo strength shown in eight colors. [GRAPH]: Echo strength shown by graph.



SCALE SYNC

Choose whether to interlock port-starboard speed range with fore-aft speed range or not.

DRIFT SCALE

Set the port-starboard speed range on the ship's speed display. This setting is available when you set [OFF] in the [SCALE SYNC].

<u>SCALE</u>

Set the fore-aft speed range on the ship's speed display. When you set [ON] in the [SCALE SYNC], this setting applies to the port-starboard speed range also.

DRIFT HISTORY

Set the range for the port-starboard speed history graph.

<u>HISTORY</u>

Set the range for the fore-aft speed history graph.

HISTORY SHIFT

Set the amount of shift for the fore-aft speed history graph.

3.4.4 [DISP 3] sub menu



[DISP 3] sub menu

SCALE

Choose the scale to use in the course plot display.

INTERVAL

Choose the display interval for the tide vector in the course plot display. The figures are scale on course plot display.

SHIP TRACK

Turn own ship's track display on or off.

VECTOR LENGTH

Choose the vector length from [LONG] or [SHORT]. For [LONG] 1 mm in length is equal to 0.1 kn.

TEXT WINDOW

Turn the text window in the course plot display on or off.

DEPTH SOURCE

Choose the depth to display.

[INTERNAL]: The depth which calculated in the current indicator is shown. [EXTERNAL]: The depth which is input from the external device. The basic line for depth measurement is automatically set according to the input sentence (NMEA or CIF).

3.5 [ALARM] menu

The ALARM menu sets the parameters for tide, tide differential, ship's speed and trip distance alarm. When an alarm setting is violated, the audible alarm sounds and a warning message (flashing) appears at the bottom of the display. To silence the audible alarm, press the CursorPad (\blacktriangle , \blacktriangledown , \triangleleft , or \triangleright). The alarm message remains on the screen until the cause for the corresponding alarm is eliminated or the alarm is disabled. When the alarm is again violated, the alarm message appears and the audible alarm is released. The audible alarm and alarm message may be enabled or disabled independently. Alarm messages appear in section 4.4.

The [ALARM] menu has two sub menus, [ALARM1] and [ALARM2].

Note: The [ALARM1] sub menu has priority to the [ALARM2] sub menu. In each sub menu, the menu shown in the higher position has the higher priority. When multiple alarms are violated, the audible and visual alarms are given to the alarm having the highest priority.

3.5.1 Alarm types

LAYER 1 to LAYER 5 (tide alarm)

You can set the alarms to activate Tide speed and direction alarms for respective tide layers.

SHALLOW T/D, DEEP T/D (tide differential alarm)

When the value becomes within the speed and direction you set for the tide differential alarm, the alarm function activates. There are two tide differentials so you can set each differential alarm. The shallower depth among two tide differential alarms is [SHALLOW T/D], the deeper one is [DEEP T/D]. For the selection of the basic/reference layer, see subsection 3.3.1.

[REF TIDE DIFF] (Basic layer)	[TIDE DIFF 1 (2)] (Reference layer)	Tide differential
LAYER 1	[TIDE DIFF 1]: LAYER 2 (depth: 20 m) [TIDE DIFF 2]: LAYER 4 (depth: 50 m)	[SHALLOW T/D]: tide differential be- tween LAYER 1 and LAYER 2 [DEEP T/D]: tide differential between LAYER 1 and LAYER 4
LAYER 1	[TIDE DIFF 1]: LAYER 2 (depth: 50 m) [TIDE DIFF 2]: LAYER 4 (depth: 20 m)	[SHALLOW T/D]: tide differential be- tween LAYER 1 and LAYER 4 [DEEP T/D]: tide differential between LAYER 1 and LAYER 2

Ex: Setting for tide differential alarms

SPD (Ship's speed)

Sets speed and course for speed alarm.

<u>trip</u>

Sets distance and time for trip alarm.

3.5.2 How to set tide, tide differential and ship's speed alarms

You can set the alarm items, [SPD] (speed), [DIR] (direction) and [CSE] (course), in the similar procedure.

As an example, for LAYER 1, set the tide speed alarm for 1-2 kn and tide direction alarm for 350° - 10° .

- 1. Press the **MENU** key to open the menu.
- 2. Press \blacktriangle to place the cursor on the main menu title field.
- 3. Press \blacktriangleleft or \blacktriangleright to choose [ALARM].
- 4. Press ▼ to place the cursor on the sub menu title field, and then press ◀ to choose [ALARM1]. The [ALARM1] sub menu appears. To set the tide differential alarm or ship's speed alarm, choose the [ALARM2] sub menu.

MENU 1	MENU 2	ALARM	INSTALLATION	M	ENU 1	MENU 2	ALARM	INSTALLATION
LAYER 1	: SF	PD		SH	HALLOW T/	D : 5	SPD	
	: DI	R				: 0	DIR	
LAYER 2	: SF	p d		DE	EEP T/D	: 5	SPD 🛋	
	: DI	R⊑∜≫				: 0	DIR ⊏{)»	
LAYER 3	: SF	PD		SF	HIP SPEED	: 5	SPD	
	: DI	R				: 0	CSE	
LAYER 4	: SF	PD		TF	RIP	: 0	DIST	
	: DI	R				: T	IME	
LAYER 5	: SF	PD						
	: DI	R						
MENU ON ALARM SETTINGS.		ME	ENU ON AL/	ARM SETTII	NGS.			
[▲/▼]:SELEC	CT, [◀/▶]: CH/	ANGE, [MEN	IU]: EXIT	[▲	√▼]:SELEC	T, [◀/▶]: Cŀ	HANGE, [MEN	IU]: EXIT

[ALARM1] sub menu

[ALARM2] sub menu

Alarm status is shown with the speaker icons.

Speaker icon	Contents
	Alarm ON (Audible alarm and alarm message: ON)
Ъ	Alarm OFF (Audible alarm: OFF, Alarm message: ON)

5. Press \blacktriangle or \triangledown to choose [LAYER1]-[SPD].

6. Press \blacktriangleright to open the alarm setting window.





Press ◀ or ► to set minimum speed; ▲ or ▼ to set maximum speed (0 kn to tide speed range). As you operate an arrow (◀, ►, ▲ or ▼) the radius of the inner or outer circle is increased or decreased accordingly. Your screen should now look something like the one shown below.



Alarm setting screen (tide speed set)

- 8. Press the F1 key to return to the [ALARM] menu. □())) appears to the right of [SPD] at [LAYER 1].
- 9. Press ▼ to choose [DIR] at [LAYER 1].

- 10. Press \blacktriangleright to open the alarm setting window.
- 11. Use ◀ or ► to set starting point; ▲ or ▼ to set ending point. For example, set the starting point at 350° and the ending point at 10°. Then, the screen should look something like the one at the top of the next page.



Tide direction alarm setting value

Alarm setting screen (tide direction set)

- 12. Press the F1 key to return to the [ALARM] menu. The icon □→) appears to the right of [DIR] at [LAYER 1].
- 13. Press the **MENU** key to close the menu.

3.5.3 How to set the trip alarm

Trip distance alarm

The trip distance alarm sounds when the vessel has traveled more than the preset distance.

- 1. Press the **MENU** key to open the menu.
- 2. Press \blacktriangle to place the cursor on the main menu title field.
- 3. Press \blacktriangleleft or \blacktriangleright to choose [ALARM].
- 4. Press ▼ to place the cursor on the sub menu title field, and then press ► to choose [ALARM2].
- 5. Press ▼ to choose [DIST] at [TRIP].
- 6. Press \blacktriangleright to show the trip distance setting screen.



Trip distance alarm setting screen

- 7. Press \blacktriangleleft or \triangleright to set distance (0.0 nm to 30.0 nm).
- 8. Press the **F1** key to quit and return to the [ALARM] menu. The icon □())) appears to the right of [DIST] at [TRIP]. When the vessel has traveled more than the preset distance, the audible alarm sounds and an alarm message appears.
- 9. Press the **MENU** key to close the menu.

Trip time alarm

The trip alarm sounds when the preset trip time has elapsed.

- 1. Press the **MENU** key to open the menu.
- 2. Press \blacktriangle to place the cursor on the main menu title field.
- 3. Press \blacktriangleleft or \blacktriangleright to choose [ALARM].
- 4. Press ▼ to place the cursor on the sub menu title field, and then press ► to choose [ALARM2].
- 5. Press ▲ or ▼ to choose [TIME] at [TRIP].
- 6. Press \blacktriangleright to show the trip time setting screen.



Trip time alarm setting screen

- 7. Press \blacktriangle or \triangledown to choose item to set.
- 8. Press \blacktriangleleft or \triangleright to set.
- 9. Press the **F1** key to quit and return to the [ALARM] menu. The icon □())) appears to the right of [TIME] at [TRIP]. When the alarm setting is violated the audible alarm sounds and an alarm message appears.
- 10. Press the **MENU** key to close the menu.

3.5.4 How to disable/enable the audible alarm

- 1. Press the **MENU** key to open the menu.
- 2. Press \blacktriangle to place the cursor on the main menu title field.
- 3. Press \blacktriangleleft or \blacktriangleright to choose [ALARM].
- 4. Press ▼ to place the cursor on the sub menu title field, and then press ◀ or ► to choose the sub menu required.
- 5. Press \blacktriangle or \triangledown to choose the alarm you want to process. An alarm where \square or \square)) appears.
- 6. Press \blacktriangleleft or \blacktriangleright to show \square or \square) as appropriate.
- 7. Press the **MENU** key to close the menu.

3.5.5 How to cancel an alarm

- 1. Press the **MENU** key to open the menu.
- 2. Press \blacktriangle to place the cursor on the main menu title field.
- 3. Press \blacktriangleleft or \blacktriangleright to choose [ALARM].
- 4. Press ▼ to place the cursor on the sub menu title field, and then press ◀ or ► to choose the sub menu required.
- 5. Press \blacktriangle or \triangledown to choose the alarm you want to disable.
- 6. Press the **F1** key, and the following window appears.



Alarm cancel confirmation message

- 7. Press ► to choose [YES].
- 8. Press the **F1** key to return to the [ALARM] menu. The speaker icon which you selected at step 5 is removed.
- 9. Press the **MENU** key to close the menu.

3. MENU OPERATION

This page is intentionally left blank.

4. MAINTENANCE & TROUBLE-SHOOTING

This chapter contains maintenance and troubleshooting instructions to be followed to obtain optimum performance and the longest possible life of the equipment. Before attempting any maintenance or troubleshooting procedure, please review the safety information below.

🖄 WARNING



ELECTRICAL SHOCK HAZARD Do not open the equipment.

Only qualified personnel should work inside the quipment.

NOTICE

Do not apply paint, anti-corrosive sealant or contact spray to coating or plastic parts of the equipment.

Those items contain organic solvents that can damage coating and plastic parts, especially plastic connectors.

4.1 Maintenance

Routine maintenance

Regular maintenance is important for good performance. Check the following on a regular basis to keep the equipment in good condition.

- Check that the connectors are tightly fastened.
- Check the ground wire and ground terminal for rust. Clean if necessary. Confirm that the ground wire is tightly fastened.
- Remove dust and dirt from the monitor unit with a dry, soft cloth. Do not use chemical cleaners to clean any part of the monitor unit. They can remove paint and markings.
- To remove dirt or salt deposits, use an LCD cleaner, wiping slowly with tissue paper so as to dissolve the dirt or salt. Change paper frequently so the salt or dirt will not scratch the LCD. Do not use solvents such as thinner, acetone or benzene for cleaning. Also, do not use degreaser or antifog solution, as they can strip the coating from the LCD.

<u>Transducer</u>

- Check the zinc plate attached to the transducer for corrosion regularly and replace it if it is corroded. It should be replaced when the ship is drydocked. If the plate is not replaced, corrosion may occur. This may allow the transducer to fall out from the hull, allowing water to leak inside the vessel.
- Do not paint the transducer face.
- When the vessel is drydocked, remove marine growth from the transducer. Marine life adhering to the transducer may cause a considerable drop in performance.

<u>Fuse</u>

The transceiver unit, monitor unit and control unit are equipped with a fuse which protects them from overvoltage and overcurrent. If a fuse blows, find the cause before replacing it. If it blows again after replacement, contact your dealer for advice. All fuses are located in-

\land WARNING

Use the proper fuse.

Use of a wrong fuse can result in damage to the equipment or cause fire.

side the units. Therefore, have a suitably qualified technician replace the fuses.

Unit	Туре	Code No.
Monitor Unit	FGMB 3A 125V	000-104-909
Control Unit	FGMB 2A 125V	000-103-165
Transceiver Unit	FGBO 3A AC250V	000-549-021
(100 VAC spec.)	FGBO 5A AC250V	000-549-022
Transceiver Unit (200 VAC spec.)	FGBO 3A AC250V	000-549-021

4.2 Troubleshooting

Below are simple troubleshooting procedures which the user may follow to try to restore normal operation. If normal operation cannot be restored, do not attempt to check inside any unit. Any repair work is best left to a qualified technician.

Case	Remedy		
Nothing appears on the screen when the power switch is pressed.	 Check that the power cable is firmly connected. The fuse may have blown. Request replacement of the fuse. Adjust brilliance. 		
Ship's track is not displayed.	Turn on [SHIP TRACK] in the [DISP 3] sub menu.		
Bottom echo is not shown on the echo level display.	 Check if the setting of [ECHO RANGE] in the [MENU 4] sub menu is too low. Bottom is deeper than measuring range. Check setting of [GAIN] in the [MENU 4] sub menu. 		
Echo display is interrupted.	 Suspect poor measuring conditions. Marine life may be adhering to the transducer. Bottom is covered with sludge or the like. 		
Tide data is unstable.	 Adjust [TIDE AVERAGE] in the [MENU 3] sub menu. 		
Interference is present.	 Check ground for corrosion. Check if the cables of other equipment are near the transducer cable. 		

4.3 Diagnostics

The current indicator is equipped with three test facilities to check it for proper operation. When you turn on the current indicator, the selftest starts automatically and then a normal operation. If you find the some error, do the following tests. When their result of the tests is NG, please contact the service technician.

4.3.1 General test

The general test mainly checks the ROM, RAM and voltages.

- 1. Press the **MENU** key to open the menu.
- 2. Press \blacktriangle to place the cursor on the main menu title field.
- 3. Press ◀ to choose [MENU 1].
- 4. Press $\mathbf{\nabla}$ to place the cursor on the sub menu title field.
- 5. Press ► to choose [MENU 4].

MENU 1 MENU 2	ALARN	INSTALLATION
MENU 3 MENU 4		
NAV MODE :	OFF	ON
BOTTOM SEARCH:	NO	YES
BTM TIDE TRACK :	OFF	ON
ALM/KEY BEEP :	OFF	ON
WT SPD DEPTH :	2 m	(2-400m)
RESET TRIP LOG :	NO	YES
TEST :	NO	GENERAL PANEL PATTERN
ECHO RANGE :	150 m	
TVG :	OFF	ON
GAIN :	5	(1-40)
PANEL DIMMER :	5	(0-7)

[MENU 4] sub menu

- 6. Press \blacktriangle or \blacktriangledown to choose [TEST].
- 7. Press ► to choose [GENERAL].

8. Press the **F1** key to start the test. The results of the test are shown on the screen.



XX: Program Version No.

Echo display for three beams

General test results

Description of control unit test results

- VOL: Program version no. of the OCK Board (66P3982).
- MEM: Check of 1: ROM, 2: SRAM, 3: EEPROM and 4: DRAM.If all memories are functioning properly, "OK" appears. "NG" (No Good) appears when a memory is abnormal and an asterisk is placed to the right of the abnormal memory.
- SIO: Communication test with the transmission / reception calculation unitIf it is normal, "OK" will be displayed.If it is defective, "NG" will be displayed.

Description of transceiver unit test result

- VOL: OCK board (66P3982) ROM program number.
- MEM: Checks memory ICs on the PCP Board. If all memory ICs are functioning properly, "OK" appears. "NG" (No Good) appears when an IC is abnormal and an asterisk is placed to the right of the abnormal IC.
- ANA: Displays voltage of 12 V and +B lines.
- TRM: Displays temperature inside transducer.
- DSW: Displays PCP DIP switch settings.
- DSW: Displays PCN DIP switch settings.
- 9. To quit the test, press the **MENU** key to return to the [MENU 4] sub menu.
- 10. Press the **MENU** key again to close the menu.

4.3.2 Panel test

The panel test checks the keys and setting knob on the control unit for proper operation.

- 1. Open the [MENU 4] sub menu and choose [PANEL] at [TEST]. The message "PRESS FUNCTION KEY TO EXCUTE." appears.
- 2. Press the **F1** key to start the test. A screen for testing the control unit appears on the display.



Panel test

- 3. Press each key (except **MENU** and **POWER**) one by one. A key's on-screen location should show "1" when the key is pressed and "0" when the key is released.
- 4. Operate the setting knob. The setting knob's on-screen indication should show appropriate setting value when the knob is operated.
- 5. To quit the test, press the **MENU** key to return to the [MENU 4] sub menu.
- 6. Press the **MENU** key again to close the menu.

4.3.3 Test pattern

The test pattern checks for proper display of colors.

- 1. Open the [MENU 4] sub menu and choose [PATTERN] at [TEST]. The message "PRESS FUNCTION KEY TO EXCEUTE." appears.
- 2. Press the **F1** key to start the test. The screen becomes the red gradation.
- 3. Press ► or ▲ to change the picture in the sequence shown above. You may reverse the order by pressing ◄ or ▼.



Note: When an external monitor is connected, it is 11 gradations instead of 16 gradations.

- 4. To quit the test, press the **MENU** key to return to the [MENU 4] sub menu.
- 5. Press the **MENU** key again to close the menu.

4.4 Error Messages and Alerts

The current indicator displays an error message and sounds the audible alarm when error is detected. To silence the alarm, press any arrow (\blacktriangleleft , \blacktriangle , \triangleright , or ∇) on the CursorPad for transceiver-related alarm or turn off the alarm in the [ALARM] menu in case of control unit-related alarm. In case of multiple errors, the error or alert having the highest priority is displayed. The table below shows all the error messages and alerts which may appear, in order of priority, from highest to lowest.

Error Message or Alert	Meaning
WARNING! OVERHEATED	Overheated transducer
TRANSDUCER [001]	
WARNING! ABNORMAL TX VOLT-	Abnormal Tx voltage
AGE [002]	
WARNING! CHARGING ERROR	Abnormal +B voltage
(+B) [003]	
WARNING! ABNORMAL INPUT	Abnormal Input voltage (12 V)
12V [009]	

Error I	messages	and	alerts

Error Message or Alert	Meaning
WARNING! NO POSITION DATA [100]	External position data is missing
WARNING! NO SPEED DATA [101]	External speed data is missing
WARNING! NO DEPTH DATA [103]	External depth data is missing
WARNING! NO HEADING DATA [104]	Position data is missing
WARNING! ABNORMAL COURSE DATA [105]	Abnormal course error angle
WARNING! NO TEMPERATURE DATA [106]	Water temperature data is missing
WARNING! ABNORMAL TEMP IN- PUT [201]	Abnormal water temperature sensor
WARNING! LAYER 1 TIDE SPEED	Layer 1 speed alarm has been violated.
WARNING! LAYER 1 TIDE DIREC- TION	Layer 1 tide direction alarm has been violated.
WARNING! LAYER 2 TIDE SPEED	Layer 2 speed alarm has been violated.
WARNING! LAYER 2 TIDE DIREC- TION	Layer 2 tide direction alarm has been violated.
WARNING! LAYER 3 TIDE SPEED	Layer 3 speed alarm has been violated.
WARNING! LAYER 3 TIDE DIREC- TION	Layer 3 tide direction alarm has been violated.
WARNING! LAYER 4 TIDE SPEED	Layer 4 speed alarm has been violated.
WARNING! LAYER 4 TIDE DIREC- TION	Layer 4 tide direction alarm has been violated.
WARNING! LAYER 5 TIDE SPEED	Layer 5 speed alarm has been violated.
WARNING! LAYER 5 TIDE DIREC- TION	Layer 5 tide direction alarm has been violated.
WARNING! SHALLOWER TIDE DIFF SPD	Shallow tide differential tide speed alarm has been violated.
WARNING! SHALLOWER TIDE DIFF DIR	Shallow tide differential tide direction alarm has been violat- ed.
WARNING! DEEPER TIDE DIFF SPD	Deep tide differential tide speed alarm has been violated.
WARNING! DEEPER TIDE DIFF DIR	Deep tide differential tide direction alarm has been violated.
WARNING! SHIP SPEED	Speed alarm has been violated.
WARNING! SHIP COURSE	Course alarm has been violated.
WARNING! TRIP DISTANCE	Trip distance alarm has been violated.
WARNING! TRIP TIME	Trip time alarm has been violated.

4. MAINTENANCE & TROUBLESHOOTING

This page is intentionally left blank.

APPX. 1 MENUTREE





FURUNO

CI-68

SPECIFICATIONS OF CURRENT INDICATOR CI-68

1 TRANSCEIVER

1.1	Frequency	244 kHz
1.2	Tracking mode	Ground tracking, Water tracking, Nav-aid, Automatic, External
1.3	Ship's speed	
	Measurement range	Fore-aft: -10.0 to 30 kn, Port-stbd: -9.9 to +9.9 kn
	Accuracy	Within ±1% or 0.1 kn, whichever is the greater
	Direction	All directions (360°) in one-degree steps
	Measurement depth	3-300 m (ground tracking mode), Actual depth depends on
		installation method and underwater conditions.
1.4	Tide	
	Speed	0.0-9.9 kn
	Accuracy	Within 0.2 kn
	Direction	All directions (360°) in one-degree steps
	Number of layers	5
	Measurement range	2-150 m
		Up to about 75% of depth. The depth must be greater than 22 m
		in the ground tracking mode and greater than 40 m in the water
		tracking mode using short pulse and greater than 70 m using long
		pulse. Actual range will vary depending on installation and
		underwater conditions.
1.5	Other functions	Bottom tide tracking, Alarm output, Interference rejecter,
		Demonstration mode
1.6	Adjustment	Ship's speed, Tide, Installation angle (bearing, trim, heel),
		Course error, Draft, External KP
2	DISPLAY UNIT	
2.1	Display	VGA (640x480 dot)
2.2	Contents	Ship's speed, Course, Drift angle, Tide (5 layers), Tide differential
		(2 layers), Setting depth, Heading, Position, Echo level, Water
		temperature
2.3	Display mode	Tide vector, Graph, Course plot, Ship's speed, Text, Echo monitor
3		
J 3 1	IEC 61162 NMEA	IEC 61162.1 Ed. 2. IEC 61162.2. NIMEA 0183. Ver.1.5/2/0/3.0
5.1		DRT DRT CCA CIL HDT HDM HDC MTM/ DMA DMC VTC
	mpul sentences	

	Output sentences	CUR, VBW, VDR, VHW, VLW, VTG
3.2	CIF	4800 bps, 7 bits, 2 parity, FURUNO original format



	Input sentences	System time, Measuring position, Heading, Depth,
		Water temperature
	Output sentences	Tide data for 1 st layer, tide-measured speed, depths for multi-layers
3.3	Current indicator data	RS-232C, 4800 bps, 7 bits, 2 parity
		Date and time, Position, Speed, Current indicator,
		Reverberation level, Speed calibration, Angle calibration,
		Alarm output, others

4 POWER SUPPLY

- 4.1 Transceiver unit 100/110/115-120/200/220/230/240VAC: 3-1.5A, 1 phase, 50/60 Hz
- 4.2 DC-AC inverter (TR-2451, option) 24VDC, 20A max.

5 ENVIRONMENTAL CONDITIONS

- 5.1 Ambient temperature Transducer -5°C to 35°C Other units -15°C to 55°C
 5.2 Relative humidity 95% or less (+40°C)
- 5.3 Degree of protection Transceiver/Monitor unit IPX0 Control unit IPX2 (panel), IPX0 (chassis) Junction box IPX4 Transducer IPX8

6 COATING COLOR

6.1 Control/ Monitor unit N3.0 (panel), 2.5GY5/1.5 (chassis)6.2 Transceiver unit 2.5GY5/1.5

INDEX

Α

ALARM menu	3-10
Alerts	4-6
ALM/KEY BEEP	3-4
Audible alarm	3-14
В	
BACKGROUND CLR	3-5
BEARING MODE	3-3
BOTTOM SEARCH	3-3
BTM TIDE TRACK	3-4
С	
Choosing a Display	1-4
	4.0

Onoosing a Display			1-4
Choosing a range			1-9
COURSE PLOT			3-5
Course plot display	1-6,	1-9,	2-8

D

3-10
2-10
2-8
3-9
4-3
4-5
4-6
3-6
3-7
3-9
3-8
3-6
2-9
2-6
2-4
3-8
3-8

Ε

Echo display range	
ECHO LEVEL	
Echo level	
Echo level display	. 1-7, 1-9, 2-11
ECHO RANGE	
Error display	2-11
Error messages	4-6
F	
Fore-aft speed	
Fore-aft speed history graph	2-6

2-0
3-2
3-4
3-5
2-7

Η

Π	
Heading	2-1
HEADING LINE	3-6
Heading line	2-3
	2-0
	3-9
HISTORY SHIFT	3-9
1	
INSTALLATION menu	3-1
INTER\/AI	3-0
	0-0
L	
LCD Brilliance	1-3
NA .	
Maintenance	
Fuse	4-2
Routine	4-1
Transducer	4-1
Measuring depth	1-7
MENU 1 menu	3-2
MENU 2 menu	3-5
MENU 3 sub menu	3-2
	3_3
	27
	3-1
	2-0
MODE sub menu	3-5
Ν	
	3-3
North marker	2-0
	2-3
0	
Own ship vector	2-6
D	
PANEL DIMMER1-3,	3-5
Port-starboard history graph	2-6
Position	2-9
Power On/off	1-2
D	
	~ 4
	2-4
	3-3
RESET SPD DEPTH	3-4
RESET TRIP LOG	3-4
S	
	20
5CALE	3-9
	2-9
SCALE SYNC	3-8
SHALLOW T/D 3	-10
SHIP SPD MODE	3-7
SHIP SPD VCTR	3-6
SHIP SPEED	3-5
SHIP SPEED AVG	3-3
SHIP TRACK	3-0
Shin's heading	_10
onip s neauniy I	-10

INDEX

Ship's speed	2-5
Ship's speed display	1-5, 1-9, 2-5
Ship's speed vector	2-4
Ship's track	2-9
Speed alarm	3-10
Speed graph	2-7
Speed/Cource	2-2

Зр **Т**

-	
TEMP GRAPH	3-8
TEST	3-4
TEXT	3-5
Text display	1-6, 2-10
TEXT WINDOW	3-8, 3-9
Text window	2-5, 2-7
Tide alarm	3-10
TIDE AVERAGE	3-3
Tide average setting	2-4
TIDE DIFF	3-6
TIDE DIFF 1 (2)	3-3
Tide differential	2-2
Tide differential graph	2-7
Tide differential vector	2-3
Tide display interval	2-9
TIDE GRAPH	3-8
Tide graph	2-7
TIDE RANGE	3-6
Tide speed/vector	2-2
TIDE VECTOR	3-5, 3-6
Tide vector	2-3, 2-9
Tide vector display1-4	, 1-9, 2-1
Tracking mode	1-8, 2-1
Trip	2-6
Trip alarm	3-10
Trip distance alarm	3-13
Trip distance marker	2-8
Trip time alarm	3-14
Troubleshooting	4-2
TVG	3-4
V	
VECTOR LENGTH	3-9
	0-0
W	
Water temperature	2-2
Water temperature graph	2-3, 2-7
Water tracking speed	2-5
WT SPD DEPTH	3-4