

Installation Manual

Electronic Chart Display and Information System (ECDIS)

FEA-2107/2107-BB/2807

SAFETY INSTRUCTIONS.....	i
EQUIPMENT LIST.....	ii
SYSTEM CONFIGURATIONS	iv
1. MOUNTING	1-1
1.1 Monitor Unit	1-1
1.2 Control Unit.....	1-5
1.3 Processor Unit.....	1-10
1.4 LAN Adapter/B Adapter.....	1-11
2. WIRING.....	2-1
2.1 Wiring	2-1
2.2 Processor Unit	2-5
2.3 LAN Adapter	2-7
2.4 B Adapter (EC-1000C-C-S/EC-1000C-CR only)	2-13
2.5 Radar Overlay (EC-1000C-R/EC-1000C-CR only).....	2-19
2.6 Connection of Digitizer and LCD Displays to Processor Unit	2-20
2.7 Power Cabling to ECDIS.....	2-20
2.8 Ethernet Cable Connection.....	2-21
3. ADJUSTMENTS	3-1
3.1 How to Set IP Address for ECDIS	3-1
3.2 Parameters	3-3
3.3 Adjustments for the Second LAN Adapter EC-1010	3-64
3.4 DIP Switches and Jumper Wires.....	3-71
3.5 Installation of Optional Furuno PP-510 Printer	3-76
3.6 Activation of CM-93/3	3-82
3.7 Reinstall of ECDIS Software	3-87
4. INPUT/OUTPUT SIGNALS	4-1
5. RADAR SWITCH (OPTIONS)	5-1
PACKING LISTS	A-1
OUTLINE DRAWINGS	D-1
INTERCONNECTION DIAGRAM	S-1





(Elemental Chlorine Free)

The paper used in this manual
is elemental chlorine free.

FURUNO ELECTRIC CO., LTD.

9-52 Ashihara-cho,
Nishinomiya, 662-8580, JAPAN

Telephone : +81-(0)798-65-2111

Fax : +81-(0)798-65-4200

• FURUNO Authorized Distributor/Dealer

All rights reserved.

Printed in Japan

Pub. No. IME-41220-F

(HIMA) FEA-2107/BB/2807

A : SEP . 2004

F : AUG . 19, 2009



* 0 0 0 1 4 9 7 7 5 1 5 *



SAFETY INSTRUCTIONS



WARNING



Do not open the equipment unless totally familiar with electrical circuits and service manual.

**ELECTRICAL
SHOCK
HAZARD**

Only qualified personnel should work inside the equipment.

Turn off the power at the mains switch-board before beginning the installation.

Fire, electrical shock or serious injury can result if the power is left on or is applied while the equipment is being installed.

Do not install the monitor unit, processor unit or control unit where they may get wet from rain or water splash.

Water in the units can result in fire, electrical shock, or damage the equipment.

Be sure that the power supply is compatible with the voltage rating of the equipment.

Connection of an incorrect power supply can cause fire or damage the equipment .

Use only the specified power cable.

Fire or damage to the equipment can result if a different cable is used.



WARNING

The PCI-951/PCG820 board is equipped with a lithium battery. The lithium battery should be replaced only in the factory.

There is a danger of explosion if the wrong type of battery is used for replacement.



CAUTION



Attach securely protection earth to the ship's body.

The protection earth (grounding) is required to the AC power supply to prevent electrical shock.

Observe the following compass safe distances to prevent deviation of a magnetic compass:

	Standard compass	Steering compass
Processor Unit (EC-1000C)	1.65 m	1.05 m
LAN Adapter (EC-1010)	1.05 m	0.70 m
B Adapter (EC-1020)	0.80 m	0.50 m
Control Unit (RCU-018)	0.30 m	0.30 m
Control Unit (RCU-015)	0.95 m	0.60 m
Control Unit (RCU-016)	0.65 m	0.45 m
Monitor Unit (MU-201CE-DV15)	2.25 m	1.40 m
Monitor Unit (MU-231CE-DV15)	2.55 m	1.55 m
Switching HUB (HUB-100)	1.00 m	0.60 m

EQUIPMENT LISTS

Standard Supply

Name	Type	Code No.	Qty	Remarks
Monitor Unit	MU-201CE-DVI5	-	1	For FEA-2107, w/DVI cable (5 m), SP03-14700, CP03-29020, FP03-09810
	MU-231CE-DV15	-		For For-2807, w/DVI cable (5 m), SP03-14700, CP03-29020, FP03-09810
Processor Unit	EC-1000C	-	1	Standard type: Processor unit (EC-1000C w/S-DONGLE)
	EC-1000C-R	-		Radar Overlay type: Processor unit (EC1000C w/ S-DONGLE and ROV board)
	EC-1000C-C	-		Conning type: Processor unit (EC-1000C, w/S-DONGLE and VIDEO board)
	EC-1000C-CR	-		Conning/Radar Overlay type: Processor unit (EC-1000C, w/S-DONGLE, ROV board and VIDEO board)
Control Unit	RCU-018-E	-	1	Full keyboard type, w/CP03-25604, FP03-09850
	RCU-015FEA-E	-	1	Trackball type, w/CP03-25604, FP03-09860
LAN Adapter	EC-1010	-	1	
B Adapter	EC-1020	-	1	For EC-1000C-C and EC-1000C-CR
Spare Parts	SP03-14800	000-083-570	1	Fuses
	SP03-14700	008-549-730	1	Fuses, for AC spec.
Accessories	FP03-10700	000-087-221	1	For processor unit
	FP03-09810	008-536-010	1	For Monitor unit
	FP03-09850	008-535-610	1	For Control unit RCU-018-E
	FP03-09860	008-535-690	1	For Control unit RCU-015FEA-E
Installation Materials	CP03-29020	000-082-651	1	For Monitor unit
	CP03-29100	000-087-219	1	For EC-1000C-R Processor unit
	CP03-25604	008-539-850	1	For Control unit RCU-015/018-E
	CP03-29110	000-083-624	1	For EC-1000C-C/CR Processor unit
	CP03-29500	000-083-501	1	For EC-1000C/C-R, D-SUB cable 5 m
	CP03-29510	000-083-502	1	For EC-1000C/C-R, D-SUB cable 10 m
	CP03-29600	000-083-507	1	For EC-1000C-C/CR, D-SUB 5 m
	CP03-29610	000-083-508	1	For EC-1000C-C/CR, D-SUB 10 m

Optional Supply

Name	Type	Code No.	Qty	Remarks
LAN Adapter	EC-1010	-	1	
B Adapter	EC-1020	-	1	
Remote Control Unit	RCU-016	-	1	Remote type, w/CP03-25604, FP03-09860
Monitor Unit	MU-201CE	-	1	
Rectifier	PR-62	000-013-484	1	For 100 VAC
		000-013-487	1	For 230 VAC
Accessory	FP03-09820	008-535-560	1	For MU-201CE, hanger
	FP03-09830	008-536-020	1	For MU-231CE, hanger
Hand Grip	FP03-09840	008-535-570	1	
Dust Cover	03-163-1201	100-307-260	1	For MU-201CE
	03-163-2101	100-307-270	1	For MU-231CE
Clamp Plate	OP03-182	008-535-620	1	For RCU-018
Flush Mount Kit	FP03-09870	008-535-630	1	For RCU-018
Coupling Pedestal	OP03-183	008-535-640	1	For RCU-018
	OP03-184	008-535-650	1	For RCU-018 and MU-231CE
Flush Mount Kit	FP03-09870	008-535-630	1	For RCU-015FEA
Switching HUB	HUB-100	000-083-353	1	w/operator's manual
Installation Materials	CP03-28900	000-082-658	1	LAN cable FR-FTPC-CY 10m, CP03-28901
	CP03-28910	000-082-659	1	LAN cable FR-FTPC-CY 20m, CP03-28901
	CP03-28920	000-082-660	1	LAN cable FR-FTPC-CY 30m, CP03-28901
Cable assy	3COX-2P-6C	000-146-501	1	For external monitor (analog), 10 m
	NH8P-DSUB15BNC2-10M	000-151-857	1	For connecting with a radar
	NH8P-DSUB15BNC2-20M	000-151-858	1	
	NH8P-DSUB15BNC2-30M	000-151-859	1	
	XH8P-NH8P-L10M	000-151-855	1	For connecting Radar switch and radar
	XH8P-NH8P-L20M	000-151-933	1	
	XH8P-NH8P-L30M	000-151-934	1	
	DSUB9P-DSUB9P-L10.0M	000-150-676	1	Between Monitor/Processor unit
	P5E-4PTX-BL L=10M	000-147-510	1	LAN cable (cross)
	P5E-4PTX-BL L=2M	000-150-917	1	
	XH10P-DS-5P L=2.3M	000-150-001	1	For Control unit
	XH10P-DS-5P L=20M	000-149-745	1	
	XH10P-DS-5P L=30M	000-149-746	1	
VIDEO PCB	G45FMDVP32DBF	000-165-667-10	1	Conning Board
ROV PCB	301074	000-150-680	1	Radar Overlay Board
Radar Switch	CP03-29501	008-544-940	1	For 12 VDC, for EC-1000C-R/CR
	CP03-29502	008-544-950		For 24 VDC, for EC-1000C-R/CR

SYSTEM CONFIGURATIONS

The ECDIS EC1000 Workstation displays electronic seachart and operates as user interface for the system. The ECDIS processor is connected to various sensors, and performs navigation calculations and route monitoring. Connections to interfaces are typically made with a LAN (Local Area Network) Adapter. The ECDIS processor can be used for both route planning and route monitoring. If required, there can be additional identical ECDIS EC1000C Workstation(s) connected to the same LAN to share the tasks of the ECDIS. If the system incorporates more than one ECDIS EC1000C Workstation, one or more workstation(s) can be used as a user interface (with “full” usage rights) and one or more workstation(s) may be used as planning stations (usage rights as “planning”). If the system has two Workstations connected together as multi-workstations, the system keeps data on the workstations harmonised and also tracks selections and settings made on any workstation.


Typically there can be the following kinds of workstation configuration:

Mode as **Single**, only one workstation is used in the system.

Mode as **Multi**, two or more workstations are used in the system where usage rights and sensor source of workstations can be changed by the user.


For more information, see the operator’s manual.

One workstation



Multi-workstation configuration

In the multiple workstation configuration, there can be two workstations connected together by a Local Area Network (LAN). In this configuration, one workstation is used as the “sensor source” for navigation sensors and the other workstation(s) are using the sensor source workstation to communicate with sensors, receiving and transmitting data from/to workstation via the LAN. In the multi-workstation configuration (two fully redundant navigation workstations), where navigation sensors are connected to two workstations, the sensor source may be changed and still receive and transmit information from/to the system and to/from navigation sensors. User-defined workstation is responsible for sensors.



This page is intentionally left blank.

1. MOUNTING

1.1 Monitor Unit

The monitor unit can be flush mounted in a console panel, or mounted on a desktop using the optional accessories.

Mounting considerations

When selecting a mounting location, keep in mind the following points:

- Select a location where the display unit can be viewed conveniently and where the screen can be viewed while facing towards the bow.
- Locate the unit out of direct sunlight and away from heat sources because of heat that can build up inside the cabinet.
- Locate the equipment away from places subject to water splash and rain.
- Leave sufficient space on the sides and rear of the unit to facilitate maintenance.
- A magnetic compass will be affected if the monitor unit is placed too close to the magnetic compass. Observe the compass safe distances on page ii to prevent deviation of a magnetic compass.

Installation for TCS

- **TCS with separate Conning Display:** To fulfill this requirement, certain installations may require 21" monitor and separate Conning display.
- **TCS without separate Conning Display (Single screen ECDIS):** Require that certain TCS related data is available in main Conning position of the vessel. To fulfill this requirement, certain installations may require large 23" monitor alternative for single screen installation. The viewing distance from main Conning position to installation place of single screen ECDIS are 120 cm (MU-231CE) and 108 cm (MU-201CE). In this mode, TCS related data fields should always be displayed. To prevent this fields obscured by other popular operational dialogs, set dialog box to open next to left of sidebar. See "3.3.3 Activating dialog boxes on the display" in Operator's Manual.


Mounting procedure

Flush mounting


Follow the procedure below to mount the monitor unit in a console panel.

1. Make cutout in mounting location referring to the outline drawing shown on the next page.
2. Insert the monitor unit to the hole and fix it by four self-tapping screws (6x30).
3. Attach panel hooks near the fixing holes. These are used to pull out the monitor unit from a console panel for servicing.
4. Attach four panel covers to the fixing holes.

1. MOUNTING




Monitor unit MU-201CE



Monitor unit MU-231CE

Flush mounting of monitor unit



Attaching panel hook and panel cover

Note: If you need to remove the monitor unit from the panel, remove the four panel covers with your fingernail and use two panel hooks supplied as accessories to lift the monitor unit.

Desktop mounting

Use the optional accessories to mount the monitor unit on a desktop.

- Necessary parts

For MU-201CE: FP03-09820 (Code No.: 008-535-560)


For MU-231CE: FP03-09830 (Code No.: 008-536-020)

Contents of FP03-09820/09830

Name	Type	Code No.	Qty	Remarks
Hanger L	03-163-1111-0	100-305-140	1	
Hanger R	03-163-1112-0	100-305-180	1	
Hanger stay	03-163-1113	100-305-370	1	For MU-201CE
	03-163-2071	100-305-370	1	For MU-231CE
Hole plug	CP-30-HP-13	000-147-143	2	
Plastic rivet	KB-13 Rivet Black	000-570-276	4	
Hex. bolt	M6x25	000-802-771	4	
Hex. bolt	M10x30	000-802-182	2	
Spring washer	M10	000-864-261	2	
Flat washer	M10	000-864-131	2	


1. Assemble two hangers and hanger stay with two hex bolts (M10x30), flat washers and spring washers and cover each hex bolt with hole plug.
2. Fix the above assembly to the mounting location with four hex bolts (M12, dockyard supply).
3. Fasten the monitor unit to the mounting hanger assembly with four hex bolts (M6x25, supplied).
4. Cover each hex bolt with a panel cover.
5. Cover each hole for hand grip with a plastic rivet (4 pcs).

1. MOUNTING



Monitor Unit

The hand grip is optionally available for the desktop mounting.



Monitor unit, attaching hand grip

1.2 Control Unit

The control unit may be mounted on a desktop, with or without the KB fixing metal (supplied), which mounts the control unit at an angle.


Mounting considerations

When selecting a mounting location, keep in mind the following points:

- Select a location where the control unit can be operated conveniently.
- Locate the unit away from heat sources because of heat that can build up inside the cabinet.
- Locate the equipment away from places subject to water splash and rain.
- Determine the mounting location considering the length of the signal cable between the control unit and the processor unit. (The length of the signal cable is 10/20/30 m).
- A magnetic compass will be affected if the control unit is placed too close to the magnetic compass. Observe the compass safe distances on page ii to prevent deviation of a magnetic compass.

Fixing without KB fixing plate

1. Fix the KB fixing plate to the rear panel of the control unit.
2. Attach cushions (three for RCU-018, two for RCU-015FEA) to the bottom of the control unit as shown below.
3. Fix it to a desired location with self-tapping screws.




RCU-018/0RCU-15FEA, side view


1. MOUNTING

Fixing without KB fixing metal

1. Drill four mounting holes of 5 mm diameter referring to the outline drawing at the back of this manual.
2. Fix the control unit with four screws (M4) from under side of the desktop. (The M4 screws with a sufficient length for the thickness of the desktop should be provided locally.)



RCU-018



RCU-015FEA/16

Flush mounting

Use the optional flush mount kit FP03-09870 to mount the control unit RCU-018/015FEA and/or RCU-016 to a console panel.


Name: Flush mount kit

Type: FP03-09870


Code No.: 008-535-630

No.	Name	Type	Code No.	Qty
1	Mount plate	03-163-7531	100-306-260	4
2	Hex. nut	M5	000-863-206	4
3	Wing screw	M5x40	008-047-990	4

1. Prepare a cutout in the mounting location as shown in the figure below.




For RCU-018




For RCU-015FEA/16

2. Set the control unit to the cutout.
3. Screw four wing bolts into hex. nuts.
4. Screw the above wing bolts into mounting plates.
5. Attach the mounting plate to the control unit with four screws (M4x12, supplied with the control unit) from the bottom side.
6. Fasten four wing screws, and then fasten hex. nuts to fix four wing screws.




RCU-018



RCU-015FEA/RCU-16

1. MOUNTING


To connect RCU-016 in series with RCU-018



Inside of RCU-018

To change the cable entry

To change the cable entry from the side (default) to the bottom, modify the unit as shown below.



RCU-015FEA/RCU-016, Changing cable entry

1.3 Processor Unit


Mounting considerations

When selecting a mounting location, keep in mind the following points:

- Locate the processor unit away from heat sources because of heat that can build up inside the cabinet.
- The vibration at the mounting location should be minimum.
- Locate the equipment away from places subject to water splash and rain.
- Leave sufficient space at the sides and rear of the unit to facilitate maintenance.
- A magnetic compass will be affected if the processor unit is placed too close to the magnetic compass. Observe the compass safe distances on page ii to prevent deviation of a magnetic compass.

Mounting procedure

1. Attach two mounting plates to the processor unit with 14 screws (M4X8, supplied).
2. Fix the unit with four M6 bolts, or self-tapping screws (local supply).



Processor unit

1.4 LAN Adapter/B Adapter


Mounting considerations

When selecting a mounting location, keep in mind the following points:

- Locate the adapter away from heat sources because of heat that can build up inside the cabinet.
- The vibration should be minimal.
- Locate the equipment away from places subject to water splash and rain.
- Leave sufficient space at the sides and rear of the unit to facilitate maintenance.
- A magnetic compass will be affected if the adapter is placed too close to the magnetic compass. Observe the compass safe distances on page ii to prevent deviation of a magnetic compass.

LAN adapter


1. Unfasten a pan head screw to remove the cover from the LAN adapter.
2. Fasten four self-tapping screws (M3) to fix the LAN adapter to the mounting location.
3. Reattach the cover.



1. MOUNTING

B adapter


1. Unfasten a pan head screw to remove the cover from the B adapter.
2. Remove six pan head screws to remove the ADAPTER B Board (220615)
3. Fasten three self-tapping screws (M3) to fix the LAN adapter to the mounting location.
4. Reattach the cover.



B adapter


2. WIRING

2.1 Wiring






2. WIRING



NOTE: CABLE TYPES:
PO 2 X 1.5=POWER CABLE,COPPER WIRE ARMOUR,2 CORES,1.5 CROSS SECTIONAL AREA (MM²)
SI 3 X 1.5=SIGNAL CABLE,COPPER WIRE ARMOUR,3 CORES,1.5 CROSS SECTIONAL AREA (MM²)
DA 2 X 2(0.5)=DATA CABLE,COPPER WIRE ARMOUR,2 TWISTED PAIR,0.5 CROSS SECTIONAL AREA (MM²)
CAT 5 STP=LAN CABLE, CATEGORY 5, SHIELDED TWISTED PAIR


Wiring of 1st ECDIS (One LAN adapter)




NOTE: CABLE TYPES:
PO 2 X 1.5=POWER CABLE,COPPER WIRE ARMOUR,2 CORES,1.5 CROSS SECTIONAL AREA (MM²)
SI 3 X 1.5=SIGNAL CABLE,COPPER WIRE ARMOUR,3 CORES,1.5 CROSS SECTIONAL AREA (MM²)
DA 2 X 2(0.5)=DATA CABLE,COPPER WIRE ARMOUR,2 TWISTED PAIR,0.5 CROSS SECTIONAL AREA (MM)
CAT 5 STP=LAN CABLE, CATEGORY 5, SHIELDED TWISTED PAIR

Wiring of 2nd ECDIS (backup ECDIS)

2.2 Processor Unit



Processor unit



1: CONTROL HEAD
 2: RADAR UNIT
 (for chart radar only)
 3: COM 1
 4: PARALLEL

5: USB 1
 6: USB 2 or nothing
 7: DVI 2 (option)
 8: VGA 2 (option)

9: DV1
 10: MOUSE/KEYB.
 11: VGA 1
 12: LAN 2




13: LAN 1
 14: RADAR VIDEO IN (option)
 15: RADAR TRIGGER IN (option)
 16: RADAR ANTENNA IN (option)


Processor unit, rear view

2.3 LAN Adapter


2.3.1 Cables fabrication for the cables connected to the LAN adapter

Use the following JIS (Japanese Industrial Standards) cables or equivalent. When using the TTYCS-4 cable, connect the appropriate cable to it to pass the cable entrance of the adapter.

$\phi = 11.7 \text{ mm}$  Armor Sheath Conductor $S = 1.5 \text{ mm}^2$ $\phi = 1.56 \text{ mm}$	$\phi = 16.3 \text{ mm}$  Armor Sheath Shield Conductor $S = 0.75 \text{ mm}^2$ $\phi = 1.11 \text{ mm}$	$\phi = 10.1 \text{ mm}$  Armor Sheath Shield Conductor $S = 0.75 \text{ mm}^2$ $\phi = 1.11 \text{ mm}$
DPYC-1.5	TTYCS-4 (Four twisted pairs)	TTYCS-1 (Twisted pair cable)




L= Depends on equipment connected. Measure at the processor unit.



LAN Adapter (1st)


2. WIRING



LAN Adapter (2nd)

2-10

2. WIRING



Connectors on LAN-Adapter

2.3.2 Serial data channels in general

An example of serial channel (here channel 1)

RX1+	Input terminals for electrical standards IEC 61162-1, RS-232 and RS-422. “RX+” and “RX-“ may be defined as “RX-A” and “RX-B” in IEC 61162-1.
RX1-	
TX1+	Output terminals for electrical standards IEC 61162-1 and RS-422. “TX+” and “TX-“ may be defined as “TX-A” and “TX-B” in IEC 61162-1.
TX1-	
TX1	Output terminals for electrical standard RS-232C
GND	Ground terminal for RS-232C

2.3.3 Standard serial data channel assignment

First LAN adapter

Channel	Type	bit/s	Default use
1	rx/tx	4800	ARPA2
2	rx	4800	Pos1
3	rx/tx	4800	Track pilot
4	rx/tx	4800	ARPA1
5	rx/tx	38400	AIS
6	rx	4800	Pos2
7	rx	38400	Gyro1
8	rx	4800	Log/Dual-axis log
Relay1	Relay NO		Operator fitness
Relay2	Relay NC		Any ECDIS alarm
Relay3	Relay NC		Backup navigator

Second LAN adapter





Channel	Type	bit/s	Default use
9	rx/tx	4800	Route Backup
10	rx	4800	Engine Control
11	rx/tx	4800	AMWSS
12	rx/tx	4800	Navtex
13	rx/tx	38400	B-Adapter
14	rx	4800	Echo Sounder
15	rx	38400	Wind Sensor
16	rx	4800	Water temp
Relay4	Relay NC		Waypoint approach
Relay5	Relay NC		Outside channel limit
Relay6	Relay NC		Depth below limit


Note: For Relay 2 to 6: Polarities are depending on Relay outputs settings (Normal open or Normal Close) of “Alarm Inputs+Outputs/AMWSS”.


2.4 B Adapter (EC-1000C/EC-1000C-R only)

2.4.1 Cables fabrication for the cables connected to the B adapter

Use the following JIS (Japanese Industrial Standards) cables or equivalent. When using the TTYCS-4 cable, connect the appropriate cable to it to pass the cable entrance of the adapter.

$\phi = 11.7 \text{ mm}$  Armor Sheath Conductor $S = 1.5 \text{ mm}^2$ $\phi = 1.56 \text{ mm}$	$\phi = 16.3 \text{ mm}$  Armor Sheath Shield Conductor $S = 0.75 \text{ mm}^2$ $\phi = 1.11 \text{ mm}$
DPYC-1.5	TTYCS-4 (Four twisted pairs)
$\phi = 13.2 \text{ mm}$  Sheath Armor Sheath Insulator Conductor $S = 1 \text{ mm}^2$ $\phi = 1.29 \text{ mm}$	$\phi = 10.1 \text{ mm}$  Armor Sheath Shield Conductor $S = 0.75 \text{ mm}^2$ $\phi = 1.11 \text{ mm}$
MPYC-7	TTYCS-1 (Twisted pair cable)







B Adapter (1)

No.1 LAN adapter CH4 or
No.2 LAN adapter CH11, CH12 or CH13

2. WIRING





Connectors on B-Adapter

2. WIRING

ALL CONNECTIONS ARE SCREW TERMINALS
0,14 – 1,0mm² AWG 28–16

2. WIRING

2.4.2 Interface

Status output channels in general

Channel	State
1 (STO1)	ACK OUT
2 (STO2)	ROUTE MONITOR: OUTSIDE CHANNEL LIMITS
3 (STO3)	ROUTE MONITOR: WAYPOINT APPROACH
4 (STO4)	ECHO: DEPTH BELOW LIMIT
5 (STO5)	BACKUP NAVIGATOR ALARM
6 (STO6)	NAVIGATION SENSOR ALARM
7 (STO7)	OPERATOR FITNESS
8 (STO8)	ANY ECDIS ALARM

Pitot log

Pitot log input is for 200 pulses/NM log signal with forward/astern flag.

LOG+ input terminals for log signal

LOG-

F/A+ input terminals for forward/astern signal (closed = astern)

F/A1-

Gyro

Gyro input is for stepper (6 steps per degree) of synchro (1:360).

S1 input terminals for gyro phase signals (stepper & synchro)

S2

S3

S0 input terminal for stepper common signal


R1H input terminals for synchro reference signal

R1L R1H & R2 for high synchro voltage reference (135-90 VAC)

R2 R1L & R2 for low synchro voltage reference

Analog interface**Analog channels in general**

An example for analog channel (here, channel 1)



A1IN input terminals for analog signal
SGND

REF1+ reference output terminals
REF1-

STI1 input terminals for status (open = operating, in use, etc.)
GND

Analog channel assignment

channel usage

1 rudder feedback
2 R.O.T. gyro
3 RPM 1
4 PITCH 1
5 RPM 2
6 PITCH 2
7 BOW THRUSTER
8 STERN THRUSTER

alternative usage

second rudder feedback

engine start air pressure
fuel consumption
air pressure

Status input channels assignment

Channel	State
9	ALARM ACK.
10	BUZZER STOP

2.5 Radar Overlay (EC-1000C-R/EC-1000C-CR only)

Radar Overlay has input for one set of radar signals. Radar Overlay can be used to read the picture from three different radar transceivers, because it has two status inputs which change the following characteristics of the Radar Overlay:

- Video gain operating area (low and high voltage)
- FTC adjust operating area (low and high voltage)
- STC adjust operating area (low and high voltage)
- STC curve length and shape
- Number of azimuth pulses per 360°
- Radar antenna headline detector offset
- Radar trigger range offset
- Offset of the radar antenna from the conning position

Following characteristics of the Radar Overlay are common for all radar transceivers:


- Video polarity (positive or negative) and impedance (hi-Z or 75Ω)
- Trigger active edge (positive or negative) and impedance (hi-Z or 75Ω)
- Headline polarity (positive or negative)
- HI and LO video detection level difference

If you want to utilize multiple radar transceivers, then you must have a radar interswitch outside the ECDIS. The inter switch reports to the radar transceiver currently in use to the status inputs of Radar Overlay.

To connect the Radar Overlay (in the processor unit) to the radar, use the cable NH8P—DSUB15BNC cable (option). Note that XH8P-NH8P cable is necessary when the optional radar switch is used.

2.6 Connection of Digitizer and LCD Displays to Processor Unit


The brilliance of ECDIS and Conning Displays (MU-201CE or MU-231CE) can be adjusted at EC-1000C by connecting to COM1 port as below. Also, COM1 port is used for connection of Digitizer (CALCOMP Drawing Board III).



*10 m/30 m: option


2.7 Power Cabling to ECDIS

ECDIS is powered by 100-230 VAC power. See figure below for cabling.




2.8 Ethernet Cable Connection

One ECDIS can be connected to another ECDIS with optional cable P5E-4PT-BL which is 2 m long. If you need a longer cable, use the LAN (Local Area Network) using RJ45 connectors. Cable used between two ECDIS devices should be UTP (Unshielded Twisted Pair). See figures and tables below.



RJ45 Female connector (at the ECDIS)



RJ45 Male connector (at the cable)

Pin out of female connector at ECDIS

Pin	Name	Description
1	TX+	Transmit Data +
2	TX-	Transmit Data -
3	RX+	Receiving Data +
4	N/C	Not connected
5	N/C	Not connected
6	RX-	Receive Data -
7	N/C	Not connected
8	N/C	Not connected

Wiring of the twisted cable

First end Pin	Second end Pin
1	3
2	6
3	1
6	2

This page is intentionally left blank.

3. ADJUSTMENTS

3.1 How to Set IP Address for ECDIS


ECDIS has two local area network interfaces, and Interface IP address for the No.2 ECDIS has to be changed. To set the IP addresses, run WindowsXP as follows.

1. Open the cover on the front panel of the processor and connect the service keyboard there.
2. Turn the power on.
3. While pressing down the Alt key, press the Tab key on the service keyboard several times to show ECAWATCH window.
4. Release the keys and press the “Shutdown the ECDIS” button on the screen immediately.
5. Click x mark to close Control Head window.
6. Press the Alt and F4 keys simultaneously to show the WindowsXP screen.

3.1.1 Local Area Connection for LAN 1 (ARPA Radar Network)

To configure IP Address for Local Area Connection interface, proceed as follows:

1. Open the control panel of the Window.
2. Double click the Network Connection icon.
3. Highlight “Local Area Connection”, and then select **Properties** in File menu.




4. In “Local Area Connection Properties”, highlight **Internet Protocol (TCP/IP)** in general tab, and then press the Properties button.
5. Set IP Address as 172.31.3.29 (for the first ECDIS) or 172.31.3.30 (for the second ECDIS).
6. Set Subnet mask as 255.255.0.0.
7. Press the OK button to close the window.

3. ADJUSTMENTS

3.1.2 Local Area Connection for LAN2 (ECDIS LAN Network)

LAN2 interface is used to connect a LAN Adapter or HUB-100 to ECDIS EC1000C. To configure IP Address for this, proceed as follows:

1. Open Control Panel.
2. Double click Network icon.
3. Highlight **Local Area Connection 2** and then select Properties in File menu.



4. In Local Area Connection 2 Properties, highlight Internet Protocol (TCP/IP), and then press Properties button.
5. Set IP Address as 10.0.0.180 (for the first ECDIS) or 10.0.0.181 (for the second ECDIS).
6. Set Subnet mask as 255.255.0.0.
7. Click the OK button to close the window.


3.2 Parameters

NOTE: Special attention to following topics is required to maintain "Consistent Common Reference System."

- The values of center and conning positions depend on size and geometry of the ship.
- Offsets from Antenna Position to Conning Position of Position Sensors depend on the location of position sensor antennas.
- Offsets from Antenna Position to Conning Position of Radars depend on the location of radar antennas.

Installation parameters have limited access, and are controlled by an Authorizing key disk (supplied). The Authorizing key disk is a floppy which contains the necessary key to allow access into editing of the installation parameters. Do the following to access the installation parameters.

1. Insert the "Authorization key disk" to the processor unit.
Note that the installation parameters have limited access, which is controlled by the Authorization key disk supplied.
2. Press the MENU key on the control unit to open the menu.
3. Roll the wheel to choose Initial Settings, and then push the wheel.
4. Locate the cursor on the ► next to INITIAL SETTINGS to show Initial settings menu.
5. Roll the wheel to choose Installation parameters and push the wheel.



There are several buttons in this dialog box, and they are described below:

Set parameters defaults: This restores Installation parameters which are saved as a backup copy by service personnel. Use this function if you are not sure about Installation parameters values.

Sensor channel usage: The CH and sensors are shown.

Set Single Workstation Mode: This button is used to set Workstation to operate as a single workstation.

Workstations

This button is used to define names, source of sensors and location of Access Server of Workstations if two workstations are installed.

3. ADJUSTMENTS

Activate changes now: The changed settings are activated immediately. When canceling the activation, click the "X" at the top of the screen.

Restart needed to activate: The changed settings are activated when the power is turned off and on again.

Sensor Channel Usage

This shows how the serial channels of A adapters are configured and which analog sensors are connected to the system through the B adapter. Notation x (nnnn) (right is an example of x (GYRO2)) is used to show that some sensor data is collected from the data flow of the main sensor.

The screenshot shows a window titled "SioChannel" with a close button (X) in the top right corner. It is divided into two main sections for configuring serial channels.

Top Section (A Adapter):

Channel	Assignment
Chl 1:	
Chl 2:	POS EQUIP 1
Chl 3:	TRACKPILOT x(GYRO2)
Chl 4:	
Chl 5:	AIS
Chl 6:	POS EQUIP 2
Chl 7:	GYRO1
Chl 8:	DUAL AXIS LOG x(LOG)
Chl 9:	ROUTE TO GP80
Chl 10:	
Chl 11:	AMWSS
Chl 12:	
Chl 13:	B-ADAPTER
Chl 14:	ECHO SOUNDER (BOW)
Chl 15:	WIND
Chl 16:	

Bottom Section (B Adapter):

B-Adapter

Chl 1:	
Chl 2:	
Chl 3:	
Chl 4:	
Chl 5:	
Chl 6:	
Chl 7:	
Chl 8:	

What happens after pressing Activate changes now

After pressing Activate changes now, you may get one of the following alarms.





"700 No Sensor parameters": The Sensor Parameters are corrupted. Use backup of Parameters.

"600 Param change disabled": The ECDIS cannot accept change of parameters if Kalman Filter is ON or ECDIS is currently used for steering. Use manual or autopilot steering and turn Kalman Filter OFF when you change parameters.

"459 Steering parameter error": There are incorrect values in the Track pilot installation parameters. Check values of the Track pilot parameters.

Definition of Workstation

Below is a generic description of how to operate the Workstation parameter page.

1. 
2. 
3. 
4. 

1. In the Installation parameters window, click the **Workstations** button.
2. The workstation names window appears and it shows a list of computer names for workstations connected via LAN, in the list box **Network name**. Click a desired computer name of workstation to set workstation function at Edit Workstation names in the **Network name** field.
3. You can enter an alias for Workstation (PORT ECDIS as EC1000-0001) to better describe a Workstation (for example PORT ECDIS for workstation located port side). You can also set if the Workstation is used as master of sensor data and if it is used as Workstation that run an Access Server.

Note: Check **Sensor source default** for the Workstation where you have sensors connected. One Workstation can be selected to run **Access Server**.

4. When you have defined a Workstation, click the **Save** button.
The EC-1000 Workstation is set as below:
Alias: PORT ECDIS, Sensor source: default setting, Access Server: ON
5. Click EC1000-002 at Network name, and set "STBD ECDIS". Then check "Planning station".

3. ADJUSTMENTS

Examples:

Settings when workstation EC1000-0001 is used as a stand-alone system.

The 'Workstation names' dialog box is shown. It has a title bar with a close button (X). Inside, there's a section titled 'Edit Workstation names' with a text input field containing 'PORT ECDIS' and another containing 'EC1000C-0001'. To the right are 'Save' and 'Remove' buttons. Below this are two checkboxes: 'Sensor source default' (checked) and 'Location of Access Server' (checked), and 'Planning station' (unchecked). Further down, there's a 'Logical name' list box containing 'EC1000' and a 'Network name' list box containing 'EC1000C-0001' and 'EC1000C-0002'. To the right of these list boxes are 'Remove all' and 'OK' buttons. At the bottom right, there's a 'Single Workstation Mode' checkbox, which is checked.

Settings when workstation EC1000-0001 is used as navigation station in a two ECDIS system consisting of one navigation and one planning workstation.

The 'Workstation names' dialog box is shown. It has a title bar with a close button (X). Inside, there's a section titled 'Edit Workstation names' with a text input field containing 'NAVIGATION' and another containing 'EC1000C-0001'. To the right are 'Save' and 'Remove' buttons. Below this are two checkboxes: 'Sensor source default' (checked) and 'Location of Access Server' (checked), and 'Planning station' (unchecked). Further down, there's a 'Logical name' list box containing 'NAVIGATION' and 'PLANNING', and a 'Network name' list box containing 'EC1000C-0001' and 'EC1000C-0002'. To the right of these list boxes are 'Remove all' and 'OK' buttons. At the bottom right, there's a 'Single Workstation Mode' checkbox, which is checked.

Settings when workstation EC1000-0002 is used as planning station in a two ECDIS system consisting of one navigation and one planning workstation.

The 'Workstation names' dialog box is shown. It has a title bar with a close button (X). Inside, there's a section titled 'Edit Workstation names' with a text input field containing 'PLANNING' and another containing 'EC1000C-0002'. To the right are 'Save' and 'Remove' buttons. Below this are two checkboxes: 'Sensor source default' (unchecked), 'Location of Access Server' (unchecked), and 'Planning station' (checked). Further down, there's a 'Logical name' list box containing 'NAVIGATION' and 'PLANNING', and a 'Network name' list box containing 'EC1000C-0001' and 'EC1000C-0002'. To the right of these list boxes are 'Remove all' and 'OK' buttons. At the bottom right, there's a 'Single Workstation Mode' checkbox, which is checked.

Settings when workstation EC1000C-0001 is used as navigation station in a two ECDIS system consisting of two navigation workstations.

Workstation names

Edit Workstation names

PORT

EC1000C-0001

Save

Remove

☒ Sensor source default

☒ Location of Access Server

☐ Planning station

Logical name

PORT

STBD ECDIS

Network name

EC1000C-0001

EC1000C-0002

Remove all

OK

Single Workstation Mode

☐

Settings when workstation EC1000C-0002 is used as navigation station in a two ECDIS system consisting of two navigation workstations.

Workstation names

Edit Workstation names

STBD ECDIS

EC1000C-0002

Save

Remove

☐ Sensor source default

☐ Location of Access Server

☐ Planning station

Logical name

PORT

STBD ECDIS

Network name

EC1000C-0001

EC1000C-0002

Remove all

OK

Single Workstation Mode

☐

3-7

3. ADJUSTMENTS

Opening each parameter dialog box

1. Locate the cursor on the ► mark on the drop-down list.
2. Choose an item you want to set, by scrolling the list.



General

Enter your ship's name and characteristics referring to next page.

If there is no optional B adapter connected, set parameters as such.

Edit parameters - General

Ship's Name:

Sensor Message interval: x 100 ms

B-Adapter SIO Channel:

B-Adapter connected:

Trim Indicator:

Docking Disp. Spd. Vector Max Value: Kt

From Center Position to —

Bow Position: m (+Bow, -Stern) Length: m

Stern Position: m (+Bow, -Stern)

Dual Axis Log Position: m (+Bow, -Stern)

Conning Position: m (+Bow, -Stern)

Side Position: m Breadth: m

Sidewise Conning Position: m (+Stbd, -Port)

Total height from keel to mast: m

If there is an optional B adapter, set the equipment as such.

Edit parameters - General

Ship's Name:

Sensor Message interval: x 100 ms

B-Adapter SIO Channel:

B-Adapter connected:

Trim Indicator:

Docking Disp. Spd. Vector Max Value: Kt

From Center Position to —

Bow Position: m (+Bow, -Stern) Length: m

Stern Position: m (+Bow, -Stern)

Dual Axis Log Position: m (+Bow, -Stern)

Conning Position: m (+Bow, -Stern)

Side Position: m Breadth: m


Sidewise Conning Position: m (+Stbd, -Port)

Total height from keel to mast: m

Notes:

- Center position is geometrical center of the ship.
- Conning Position is the point of observation.
- Select Connected = NO, if optional B adapter is not used.
- Select Connected = YES, if optional B adapter is used.

3. ADJUSTMENTS



Gyro 1

Settings when Gyro is outputting data in IEC-61162-1 format.

Edit parameters - Gyro 1

Connected: YES

Adapter Chl: 7

Gear Box: 1:360

Talker Identifier: HE HE=typical; XX=don't care

Device Interface: IEC-61162-1 (\$xxHDT)

OK Cancel

Settings when Gyro is Stepper or Synchro with 1:360 gearbox and optional B adapter is used.

Edit parameters - Gyro 1

Connected: YES

Adapter Chl: 7

Gear Box: 1:360

Talker Identifier: XX HE=typical; XX=don't care

Device Interface: Stepper/Synchro (uses B-Adapter)

OK Cancel

Settings when Gyro is Synchro with 1:180 gearbox and B adapter is used.

Edit parameters - Gyro 1

Connected: YES

Adapter Chl: 7

Gear Box: 1:180

Talker Identifier: XX HE=typical; XX=don't care

Device Interface: Stepper/Synchro (uses B-Adapter)

OK Cancel


Notes:

- Talker identifier can be defined for IEC 61162-1 (typical talker for gyro is HE). If talker identifier is defined as XX, then it is ignored.
- Analog is either synchro or stepper from optional B adapter.
- IEC-61162-1 uses HDT/THS. IEC-61162-2 uses HDT (CH5, CH7, CH13, CH15)
- For DNV NAUT-AW installations, see the paragraph "Gyro interface only for DNV NAUT-AW rule" on page 3-16 for details.

3. ADJUSTMENTS

Gyro 2


Settings when Gyro 2 is receiving from Trackpilot.
If connected TCS.
(BSH type approved)



The screenshot shows a dialog box titled "Edit parameters - Gyro 2" with a close button (X) in the top right corner. It contains the following fields and controls:

- Connected:** A dropdown menu with "YES" selected.
- Adapter Chl:** A text input field containing "3".
- Gear Box:** A dropdown menu with "1:360" selected.
- Talker Identifier:** A text input field containing "XX". To its right is the text "HE=typical; XX=don't care".
- Device Interface:** A dropdown menu with "Trackpilot" selected.
- Buttons:** "OK" and "Cancel" buttons are located in the top right area.


Settings when Gyro 2 is receiving through Trackpilot.
If connected EMRI TCS.
(DNV NAUT-AW).



The screenshot shows a dialog box titled "Edit parameters - Gyro 2" with a close button (X) in the top right corner. It contains the following fields and controls:

- Connected:** A dropdown menu with "YES" selected.
- Adapter Chl:** A text input field containing "3".
- Gear Box:** A dropdown menu with "1:360" selected.
- Talker Identifier:** A text input field containing "XX". To its right is the text "HE=typical; XX=don't care".
- Device Interface:** A dropdown menu with "Trackpilot (double gyro / Gyro1 & 2)" selected.
- Buttons:** "OK" and "Cancel" buttons are located in the top right area.

Settings when Gyro 2 is not connected.



The screenshot shows a dialog box titled "Edit parameters - Gyro 2" with a close button (X) in the top right corner. It contains the following fields and controls:

- Connected:** A dropdown menu with "NO" selected.
- Adapter Chl:** A text input field containing "3".
- Gear Box:** A dropdown menu with "1:360" selected.
- Talker Identifier:** A text input field containing "XX". To its right is the text "HE=typical; XX=don't care".
- Device Interface:** A dropdown menu with "Trackpilot" selected.
- Buttons:** "OK" and "Cancel" buttons are located in the top right area.

Gyro interface for Track Control System approved by BSH




Figure above shows an example where ECDIS Gyro 1 is received from Common Distribution Unit and ECDIS Gyro 2 is received from trackpilot.

3. ADJUSTMENTS

Gyro interface only for DNV NAUT-AW rule




Figure above shows an example where ECDIS Gyro 1 is received directly form Gyro 1 and ECDIS Gyro 2 is received through Track Pilot.

Notes: For receiving Gyro 2 through Trackpilot:

- Software of AEU511 for the Trackpilot must be "SEM200 Version Aeu2_3 Compiled 13-04-2004 11:39".
- MPI31 must be "MIP2 Version Mip2 Compiled 12-03-2004 16:38".
- ExtendedPessa should be checked.

Log

Settings when log is using Analog Pulses 200 p/nm. Note that log is used for water speed component if the dual-axis log is available.

The screenshot shows the 'Edit parameters - Log' dialog box with the following settings:

- Connected: YES
- Adapter Chl: 4
- Device Interface: Analog Pulse (uses B-Adaptor)
- Measurement Units: NM
- Prefiltering: 0
- Pulses per Unit: 200

Buttons: OK, Cancel

Settings when log is single axis pilot log transmitting IEC-61162-1. Message used is VBW.

The screenshot shows the 'Edit parameters - Log' dialog box with the following settings:

- Connected: YES
- Adapter Chl: 8
- Device Interface: DAX: IEC 61162-1 (\$xVBW)
- Talker Identifier: VD (with note: VD=typical; XX=don't care)

Buttons: OK, Cancel

Settings when log is used to find out water speed component from a dual-axis log using IEC-61162-1. Sensor log uses water tracking values of VBW message.

The screenshot shows the 'Edit parameters - Log' dialog box with the following settings:

- Connected: YES
- Adapter Chl: 8
- Device Interface: DAX: IEC 61162-1 (\$xVBW)
- Talker Identifier: VD (with note: VD=typical; XX=don't care)

Buttons: OK, Cancel

Notes:

- Talker identifier can be defined for IEC 61162-1 (typical talker for log is VD). If talker identifier is defined as XX, then it is ignored.
- Analog pulses are from optional B-Adaptor.

3. ADJUSTMENTS

Dual-axis log

Settings when using
IEC-61162-1.

Edit parameters - Dual Axis Log (DAX)

Connected: YES

Adapter Channel: 8

Device Interface: IEC 61162-1 (\$xVBW)

Sign Positive: for Ahead (longitudinal speed)

Sign Positive: for Port (transversal speed)

Use Sign Positive parameters to change polarity of speed components

Status Flag Check: Check - only "A","B" or "W" accepted

Talker Identifier: VD VD=typical; XX=don't care

OK Cancel

Settings when no dual-axis log
is available.

Edit parameters - Dual Axis Log (DAX)

Connected: NO

Adapter Channel: 8

Device Interface: IEC 61162-1 (\$xVBW)

Sign Positive: for Ahead (longitudinal speed)

Sign Positive: for Port (transversal speed)

Use Sign Positive parameters to change polarity of speed components

Status Flag Check: Check - only "A","B" or "W" accepted

Talker Identifier: VD VD=typical; XX=don't care

OK Cancel

Notes:

- Talker identifier can be defined for IEC 61162-1 (typical talker for dual axis log is VD). If talker identifier is defined as XX, then it is ignored.
- IEC 61162-1 uses VBW or VTG.
- If you selected VBW message, then bottom track is available from dual-axis log and water track could be available from log.

Radar Echo Overlay

Radar Echo Overlay can be received by ECDIS in two ways:

- through Radar Overlay card fitted in ECDIS
- through LAN from FAR-2x07

Radar Echo Overlay (analog) through Radar Overlay card fitted in ECDIS

This menu does not appear if Analog Echo Overlay is set for "No use" during installation.

Configuration for Radar Echo Overlay (analog), when Radar overlay card fitted in ECDIS, is done using "Radar Echo Overlay (Analog)" parameter settings.

Here is an example, when Radar Transceiver is not connected (**Connected as NO**) through Radar overlay card fitted in ECDIS.
NOTE: You have to define all three Radar transceivers whether they are connected through the Radar overlay or not.

Edit parameters - Radar Echo Overlay (Analog)

Connected:

Radar transceiver:

Label:

Bearing pulses: pulses / antenna rev

From Radar antenna to Conning position: m (+Stbd, -Port)

m (+Bow, -Stern)

Bearing offset: °

Range offset: m

Rain clutter filter	Gain	Sea clutter filter
Min: <input type="text" value="5"/> V	Min: <input type="text" value="0"/> V	Min: <input type="text" value="0"/> V
Max: <input type="text" value="1.7"/> V	Max: <input type="text" value="-2.5"/> V	Max: <input type="text" value="-2.5"/> V

Here is an example of a mast-mounted S-band radar, when mast is in about same position as the conning position.

Edit parameters - Radar Echo Overlay (Analog)

Connected:

Radar transceiver:

Label:

Bearing pulses: pulses / antenna rev

From Radar antenna to Conning position: m (+Stbd, -Port)

m (+Bow, -Stern)

Bearing offset: °

Range offset: m

Rain clutter filter	Gain	Sea clutter filter
Min: <input type="text" value="5"/> V	Min: <input type="text" value="0"/> V	Min: <input type="text" value="0"/> V
Max: <input type="text" value="1.7"/> V	Max: <input type="text" value="-2.5"/> V	Max: <input type="text" value="-2.5"/> V

3. ADJUSTMENTS

Here is an example of a bow mounted radar with large distance from the conning position. Bearing and Range offsets are used to align radar and chart displays.

The dialog box is titled "Edit parameters - Radar Echo Overlay (Analog)". It has a "Connected:" dropdown set to "YES" and "OK" and "Cancel" buttons. The parameters are as follows:

Parameter	Value	Unit / Description
Radar transceiver:	2	
Label:	BOW X	
Bearing pulses:	360	pulses / antenna rev
From Radar antenna to Conning position:	5	m (+Stbd, -Port)
	150	m (+Bow, -Stern)
Bearing offset:	0	°
Range offset:	-100	m
Rain clutter filter		
Min:	5	V
Max:	1.7	V
Gain		
Min:	0	V
Max:	-2.5	V
Sea clutter filter		
Min:	0	V
Max:	-2.5	V

Here is an example of a mast-mounted X-band radar, when mast is in about same position as the conning position. Bearing and Range offsets are used to align radar and chart displays.

The dialog box is titled "Edit parameters - Radar Echo Overlay (Analog)". It has a "Connected:" dropdown set to "YES" and "OK" and "Cancel" buttons. The parameters are as follows:

Parameter	Value	Unit / Description
Radar transceiver:	3	
Label:	MAST X	
Bearing pulses:	132	pulses / antenna rev
From Radar antenna to Conning position:	0	m (+Stbd, -Port)
	0	m (+Bow, -Stern)
Bearing offset:	0	°
Range offset:	-100	m
Rain clutter filter		
Min:	5	V
Max:	0	V
Gain		
Min:	0	V
Max:	-5	V
Sea clutter filter		
Min:	0	V
Max:	-5	V

Radar Overlay has status inputs which are used to select between 3 different setups for parameters. This arrangement allows installation of three different radar transceivers and antennas. For example a normal set of one S-band and one X-band radar on a mast and then a third radar at the bow. See examples above.

Each radar can have an antenna with different amount of pulses per revolution. Also operational area of FTC (Rain clutter), STC (Sea clutter) and gain is separately defined for each radar. Offsets defined here are also used indirectly by the ARPA radar display.

Radar Echo Overlay (LAN) from FAR-2xx7 and FCR 2xx7 series radar through LAN

The following settings are for Radar Echo Overlay (LAN) received from FAR-2xx7 and FCR-2xx7 series radar through LAN.

If Radar overlay is not received through LAN, set **Connected** as **NO** for each transceiver (1-4).

Edit parameters - Radar Echo Overlay/Communication (LAN)

Radar transceiver	1		OK
Connected	NO		Cancel
Device interface	IMO Radar		
Label	MASTS		
From Radar antenna to Conning position	2	m {+Stbd, -Port}	
	20	m {+Bow, -Stern}	
IP address	172.31.3.6		
Port numbers	10024 for Radar echo output 10028 for Radar communication		
Radar display number	1		

Radar transceiver 1 is Connected as Yes.

Device Interface defines source of ARPA target (IMO ARPA or Chart Radar). Label defines name for source of video.

From Antenna to Conning position defines offset position of radar antenna.

Note that Radar display number is defined in Radar Display settings in the field at right "LAN Radar". See figure below.

Edit parameters - Radar Echo Overlay/Communication (LAN)

Radar transceiver	1		OK
Connected	YES		Cancel
Device interface	IMO Radar		
Label	MASTS		
From Radar antenna to Conning position	2	m {+Stbd, -Port}	
	20	m {+Bow, -Stern}	
IP address	172.31.3.6		
Port numbers	10024 for Radar echo output 10028 for Radar communication		
Radar display number	1		

Edit parameters - Radar Display

Radar Displays	
Radar Display	Display 1
Connected	YES
Adapter Channel	4
Device Interface	FURUNO FAR-2x07 (LAN)
Rx Talker Identifier	RA
LAN Radar	1
IP address	172.31.3.6

OK Cancel

3. ADJUSTMENTS

Radar transceiver 2 is
Connected as Yes.
Device Interface defines
source of ARPA target (IMO
ARPA or Chart Radar).
Label defines name for
source of video.
From Antenna to Conning
position defines offset
position of radar antenna.

Edit parameters - Radar Echo Overlay/Communication (LAN)

Radar transceiver	2	OK
Connected	YES	Cancel
Device interface	IMO Radar	
Label	MASTS	
From Radar antenna to Conning position	2	m {+Stbd, -Port}
	20	m {+Bow, -Stern}
IP address	172.31.3.7	
Port numbers	10024 for Radar echo output 10028 for Radar communication	
Radar display number	2	

Note that ARPA display
number is defined in ARPA
Radar Display settings in the
field "LAN Radar". See figure
at right.

Edit parameters - Radar Display

Radar Displays		
Radar Display	Display 2	
Connected	YES	
Adapter Channel	1	
Device Interface	FURUNO FAR-2x07 (LAN)	
Rx Talker Identifier	RA	
LAN Radar	2	
IP address	172.31.3.7	

OK Cancel

Radar Echo Overlay received both through Radar overlay card and through LAN

It is possible that Radar Overlay video from one transceiver is received either through Radar Overlay card (analog) or through LAN. You have to make configuration as introduced in previous sections. Pay attention that you set **Connected** as **NO** for transceivers not connected either through Radar overlay card or through LAN.

Connection of ECDIS and Chart Radar

Settings for INS

The ECDIS sends the route information to the Chart Radar in real time. However, the route information cannot be sent to Chart Radar when it stoops during the route monitor.

- Radar transceiver: Enter the radar No. '1 to 4)
- Device Interface: Choose "Chart Radar with INS".
- IP Address: Enter the IP address of FCR-2xx7 which receives the information (33 to 36).

Edit parameters - Radar Echo Overlay/Communication (LAN)

Radar transceiver	1	OK
Connected	YES	Cancel
Device interface	Chart Radar with INS	
Label	1	
From Radar antenna to Conning position	0	m {+Stbd, -Port}
	0	m {+Bow, -Stern}
IP address	172.31.3.6	
Port numbers	10024 for Radar echo output 10028 for Radar communication	
Radar display number	1	
IP Address	172.31.3.	33
Port numbers	15003 for INS communication	

Settings for Chat Radar

Edit parameters - Radar Echo Overlay / Communication (LAN)

Radar transceiver: 1

Connected: YES

Device Interface: Own for Chart Radar with INS

Label: N1

From Radar antenna to Conning position: 0 m (+Stbd, -Port)
0 m (+Bow, -Stern)

IP address: 172.31.3.6

Port numbers: 10024 for Radar echo output
10028 for Radar communication

Radar display number: 1

INS IP Address: 172.31.3.29

Port numbers: 15003 for INS communication

OK Cancel

Settings for CCRS

Note: These settings are available for the chart radar with version 06.01 and after.

The following data are sent from ECDIS to Chart Radar when starting the route monitor.

-Route data

-User chart

-Notes

-Sensor data other than Gyro

(These data are shown on Chart Radar display even if ECDIS is stopped.)

-Radar transceiver: Enter the radar No. (1 to 4)

-Device interface: Choose "Chart Radar with CCRS".

-IP Address: Enter the IP address of FCR-2xx7 which receives the information (33 to 36).

Settings for Chart Radar

Edit parameters - Radar Echo Overlay / Communication (LAN)

Radar transceiver: 1

Connected: YES

Device Interface: Own for Chart Radar with CCRS

Label: N1

From Radar antenna to Conning position: 0 m (+Stbd, -Port)
0 m (+Bow, -Stern)

IP address: 172.31.3.6

Port numbers: 10024 for Radar echo output
10028 for Radar communication

Radar display number: 1

IP Address, CCRS1: 172.31.3.29 CCRS2: 172.31.3.0

Port numbers: 15002, 15003 for CCRS communication

Primary CCRS: CCRS1

Change between CCRS and Standalone: Automatic

OK Cancel

3. ADJUSTMENTS

Radar Displays

There are 6 basic device interface alternatives:

- 1) Device interface **FURUNO: IEC 61162-1** (TX Talker ID = II) includes all standard messages for an ARPA radar target data receive interface. Further it also contains a lot proprietary messages supporting integrated navigation features such as user charts, routes, curved EBL, etc.
- 2) Device interface **FURUNO: IEC 61162-1** (TX Talker ID = EI) includes all standard messages for an ARPA radar target data receive interface. Further it also contains a lot proprietary messages supporting integrated navigation features such as user charts, routes, curved EBL, etc.
- 3) Device interface **FURUNO: IEC 61162-1** (TX Talker ID = EC) includes all standard messages for an ARPA radar target data receive interface. Further it also contains a lot proprietary messages supporting integrated navigation features such as user charts, routes, curved EBL, etc.
- 4) Device interface **IMO IEC 61162-1** (\$xxOSD, \$xxTTM) uses TTM message for ARPA radar target data receive interface and OSD message for ARPA radar speed and course receive. It sends standard ECGLL, ECDPT and ECMVW messages to the ARPA radar.
- 5) Device interface **FURUNO: FAR-2x07 (serial)** includes all standard messages for an ARPA radar target data receive interface. Further it also contains a lot proprietary messages supporting integrated navigation features such as user charts, routes, curved EBL, etc
- 6) Device interface **FURUNO: FAR-2x07 (LAN)** includes all standard messages for an ARPA radar target data receive interface. Further it also contains a lot proprietary messages supporting integrated navigation features such as user charts, routes, curved EBL, etc

In the **Radar Display** field you can select radar displays one by one and define if they are in use, etc.

Edit parameters - Radar Displays

Radar Displays
Radar Display: Display 1
Connected: YES
Adapter Channel: 4
Device Interface: FURUNO IEC 61162-1 (Tx Talker ID = II)
Rx Talker Identifier: RA

If radar id [ID 1] is received, then use antenna to coming position offset for Radar transceiver 1 as defined in Radar Overlay params

OK Cancel

Edit parameters - Radar Displays

Radar Displays
Radar Display: Display 1
Connected: YES
Adapter Channel: 4
Device Interface: FURUNO IEC 61162-1 (Tx Talker ID = EI)
Rx Talker Identifier: RA

If radar id [ID 1] is received, then use antenna to coming position offset for Radar transceiver 1 as defined in Radar Overlay params

OK Cancel

Edit parameters - Radar Displays

Radar Displays
Radar Display: Display 1
Connected: YES
Adapter Channel: 4
Device Interface: FURUNO IEC 61162-1 (Tx Talker ID = EC)
Rx Talker Identifier: RA

If radar id [ID 1] is received, then use antenna to coming position offset for Radar transceiver 1 as defined in Radar Overlay params

OK Cancel

Radar id and **Radar transceiver** -fields are used to select indirectly radar antenna offsets from Conning position, which is defined as **Conning position** in the **General** parameters page.

In the example above there are settings for ARPA radar **display 1**:

- If ARPA Radar display sends **radar id 1**, it is connected to **Radar transceiver 1** and offset is defined in **Radar Echo Overlay (Analog)** parameters page for Transceiver 1.
- If ARPA radar **display 1** sends **radar id 2**, it is connected to **Radar Transceiver 2** defined in **Radar Echo Overlay (Analog)** parameters page.

Example1:

FURUNO IEC 61162-1 device interface with various TX Talker IDs.

Edit parameters - Radar Displays

Radar Displays

Radar Display: Display 1

Connected: YES

Adapter Channel: 4

Device Interface: IMO IEC 61162-1 (\$xOSD, \$xTTM)

Rx Talker Identifier: RA

If radar id ID 1 is received, then use antenna to conning position offset for Radar transceiver 1 as defined in Radar Overlay params

OK Cancel

Edit parameters - Radar Displays

Radar Displays

Radar Display: Display 1

Connected: YES

Adapter Channel: 4

Device Interface: FURUNO FAR-2x07 (serial)

Rx Talker Identifier: RA

If radar id ID 1 is received, then use antenna to conning position offset for Radar transceiver 1 as defined in Radar Overlay params

OK Cancel

3. ADJUSTMENTS

Example 2:

Generic ARPA radar using only IMO standard message.

The screenshot shows a dialog box titled "Edit parameters - Radar Displays". It contains several configuration fields for a radar display. The fields are: "Radar Display" set to "Display 1", "Connected" set to "YES", "Adapter Channel" set to "4", "Device Interface" set to "FURUNO FAR-2x07 (LAN)", "Rx Talker Identifier" set to "RA", "LAN Radar" set to "1", and "IP address" set to "172.31.3.6". At the bottom of the dialog are "OK" and "Cancel" buttons.

Parameter	Value
Radar Display	Display 1
Connected	YES
Adapter Channel	4
Device Interface	FURUNO FAR-2x07 (LAN)
Rx Talker Identifier	RA
LAN Radar	1
IP address	172.31.3.6

Example 3

FAR-28x7 ARPA radar connected with serial line.

The screenshot shows a dialog box titled "Edit parameters - Radar Echo Overlay / Communication (LAN)". It contains several configuration fields for radar communication. The fields are: "Radar transceiver" set to "1", "Connected" set to "YES", "Device Interface" set to "IMO Radar", "Label" set to "MASTX", "From Radar antenna to Conning position" set to "6" m (+Stbd, -Port), "IP address" set to "172.31.3.6", "Port numbers" set to "10024 for Radar echo output" and "10028 for Radar communication", and "Radar display number" set to "1". At the top right of the dialog are "OK" and "Cancel" buttons.

Parameter	Value
Radar transceiver	1
Connected	YES
Device Interface	IMO Radar
Label	MASTX
From Radar antenna to Conning position	6 m (+Stbd, -Port)
IP address	172.31.3.6
Port numbers	10024 for Radar echo output 10028 for Radar communication
Radar display number	1

Example 4

Parameters for one FAR-2xx7 radar and one FCR-28x7 Chart Radar connected with LAN Cable.

First Radar display (FAR-2xx7):

Dialog box: Edit parameters - Radar Displays

Parameters for Radar Display 1:

- Radar Display: Display 1
- Connected: YES
- Adapter Channel: 4
- Device Interface: FURUNO FAR-2x07 (LAN)
- Rx Talker Identifier: RA
- LAN Radar: 1
- IP address: 172.31.3.6

Buttons: OK, Cancel

You can define to which LAN radar it is connected, at the "LAN Radar" field.

Note that the settings above together with the settings below must be done for LAN Radar settings:

Dialog box: Edit parameters - Radar Echo Overlay / Communication (LAN)

Parameters for Radar Echo Overlay / Communication (LAN):

- Radar transceiver: 2
- Connected: YES
- Device Interface: Chart Radar
- Label: MASTS
- From Radar antenna to Conning position: 2 m (+Stbd, -Port)
- Port numbers: 10024 for Radar echo output, 10028 for Radar communication
- Radar display number: 2

Buttons: OK, Cancel

Note 1: "Radar display number" defines IP address for connected ARPA Radar Display.

Note 2: Following values can be tailored: **Radar transceiver, Connected, Device Interface, Label and From Radar Antenna to Conning Position.** Leave other values as is.

3. ADJUSTMENTS

Second Radar display (FCR-28x7):

Edit parameters - Radar Display

Radar Displays	
Radar Display	Display 2 ▾
Connected	YES ▾
Adapter Channel	1 ▾
Device Interface	FURUNO FAR-2x07 (LAN) ▾
Rx Talker Identifier	RA
LAN Radar	2 ▾
IP address	172.31.3.7

OK Cancel

You can define to which LAN radar it is connected at the "LAN Radar" field.


Note that the following settings above together with the settings below must be done for LAN Radar settings:

Edit parameters - Radar Echo Overlay/Communication (LAN)

Radar Display	2 ▾	OK
Connected	YES ▾	Cancel
Device Interface	Chart Radar ▾	
Label	MASTS ▾	
From Radar antenna to Conning position	2 m (+Stbd, -Port)	
	30 m (+Bow, -Stern)	
IP address	172.31.3.7	
Port numbers	10024 for Radar echo output 10028 for ARPA communication	
Radar display number	2	

Note 1: "Radar display number" defines IP address for connected ARPA Radar Display.

Note 2: Following values can be tailored: **Radar transceiver**, **Connected**, **Device Interface**, **Label**, **From Radar Antenna to Conning Position** and **Radar display number**. Leave other values as is.



3. ADJUSTMENTS

Position equipment

An example of DGPS receiver with talker identifier GP defined for both GGA and VTG messages.

Enter values for Weight Factor and Cmg Delay as follows.

-Weight Factor: 0.1

-Cmg Delay: 0

Edit parameters - Positioning Equipment 1

Connected: Device Name:
Adapter Chl: Device Type:
Device Interface: Weight Factor:
Identification: Cmg Delay: s
Talker Identifier: XX=don't care Offsets from: m (+Stbd, -Port)
Speed Talker ID: XX=don't care Antenna position to Conning position: m (+Bow, -Stern)
Device Datum:

Roll and Pitch Receive:
IEC 61162-1 Transmit checksum:
\$ char included in transmit checksum:

Weight Factor	dRMS[m]	4dRMS[m]
0.01	1000	4000
0.05	200	800
0.07	143	571
0.1	100	400
0.2	50	200
0.4	25	100
0.6	17	67
0.8	12	50

An example of DGPS receiver which is able to send IEC 61162-1 Ed. 2 messages (includes information about Datum of output position).

Enter values for Weight Factor and Cmg Delay as follows.

-Weight Factor: 0.1

-Cmg Delay: 0

Edit parameters - Positioning Equipment 1

Connected: Device Name:
Adapter Chl: Device Type:
Device Interface: Weight Factor:
Identification: Cmg Delay: s
Talker Identifier: XX=don't care Offsets from: m (+Stbd, -Port)
Speed Talker ID: XX=don't care Antenna position to Conning position: m (+Bow, -Stern)
Device Datum:

Roll and Pitch Receive:
IEC 61162-1 Transmit checksum:
\$ char included in transmit checksum:

Weight Factor	dRMS[m]	4dRMS[m]
0.01	1000	4000
0.05	200	800
0.07	143	571
0.1	100	400
0.2	50	200
0.4	25	100
0.6	17	67
0.8	12	50

An example of GPS receiver with ignored talker identifiers for both GLL and VTG messages.

Enter values for Weight Factor and Cmg Delay as follows.

-Weight Factor: 0.1

-Cmg Delay: 0

Edit parameters - Positioning Equipment 2

Connected: Device Name:
Adapter Chl: Device Type:
Device Interface: Weight Factor:
Identification: Cmg Delay: s
Talker Identifier: XX=don't care Offsets from: m (+Stbd, -Port)
Speed Talker ID: XX=don't care Antenna position to Conning position: m (+Bow, -Stern)
Device Datum:

Roll and Pitch Receive:
IEC 61162-1 Transmit checksum:
\$ char included in transmit checksum:

Weight Factor	dRMS[m]	4dRMS[m]
0.01	1000	4000
0.05	200	800
0.07	143	571
0.1	100	400
0.2	50	200
0.4	25	100
0.6	17	67
0.8	12	50

An example of setting for DGPS receiver which is able to send IEC 61162-1 Ed. 2 messages.

Enter values for Weight Factor and Cmg Delay as follows.

-Weight Factor: 0.1

-Cmg Delay: 0

Edit parameters - Positioning Equipment 1

Connected: Device Name:

Adapter Chl: Device Type:

Device Interface: Weight Factor:

Identification: Cmg Delay: s

Talker Identifier: XX=don't care Offsets from Antenna position to Conning position: m (+Stbd, -Port)

Speed Talker ID: XX=don't care m (+Bow, -Stern)

Device Datum:

Roll and Pitch Receive:

IEC 61162-1 Transmit checksum:

\$ char included in transmit checksum:

OK Cancel

Weight Factor	dRMS[m]	4dRMS[m]
0.01	1000	4000
0.05	200	800
0.07	143	571
0.1	100	400
0.2	50	200
0.4	25	100
0.6	17	67
0.8	12	50

An example of setting for Syledis receiver.

Enter values for Weight Factor and Cmg Delay as follows.

-Weight Factor: 0.1

-Cmg Delay: 0

Edit parameters - Positioning Equipment 3

Connected: Device Name:

Adapter Chl: Device Type:

Device Interface: Weight Factor:

Identification: Cmg Delay: s

Talker Identifier: XX=don't care Offsets from Antenna position to Conning position: m (+Stbd, -Port)

Speed Talker ID: XX=don't care m (+Bow, -Stern)

Device Datum:

Roll and Pitch Receive:

IEC 61162-1 Transmit checksum:

\$ char included in transmit checksum:

OK Cancel

Weight Factor	dRMS[m]	4dRMS[m]
0.01	1000	4000
0.05	200	800
0.07	143	571
0.1	100	400
0.2	50	200
0.4	25	100
0.6	17	67
0.8	12	50

An example of setting for Loran receiver.

Enter values for Weight Factor and Cmg Delay as follows.

-Weight Factor: 0.1

-Cmg Delay: 0

Edit parameters - Positioning Equipment 5

Connected: Device Name:

Adapter Chl: Device Type:

Device Interface: Weight Factor:

Identification: Cmg Delay: s

Talker Identifier: XX=don't care Offsets from Antenna position to Conning position: m (+Stbd, -Port)

Speed Talker ID: XX=don't care m (+Bow, -Stern)

Device Datum:

Roll and Pitch Receive:

IEC 61162-1 Transmit checksum:

\$ char included in transmit checksum:


OK Cancel

Weight Factor	dRMS[m]	4dRMS[m]
0.01	1000	4000
0.05	200	800
0.07	143	571
0.1	100	400
0.2	50	200
0.4	25	100
0.6	17	67
0.8	12	50

3. ADJUSTMENTS

Notes:

- Talker identifier can be separately defined for speed and course (VTG message) and for position (GLL, GGA or PAT message). If talker identifier is defined as XX, then it is ignored.
- IEC 61162-1 ed1 or ed2: GGA uses messages VTG and GGA. Recommended for DGPS. Correct operation of a DGPS sensor requires that the system also receives VTG (COG/SOG) message. If no VTG message is received, the system thinks that there is something wrong in the DGPS and it downgrades the DGPS to an ordinary GPS sensor.
- IEC 61162-1 ed1: GLL uses messages VTG and GLL. Recommended for non-differential position receivers.
- IEC 61162-1 ed2: GLL uses messages VTG and GLL. Recommended for both differential and non-differential position receivers.
- COG delay is the delay between own ship turning and course made good in the VTG message to detect turning. Typically values are from 0 to 15 seconds.
- Because no message has any datum indication, the user is responsible for reference system used in the position receiver. GGA message is supposed to always be in WGS-84, but unfortunately some manufacturers do not follow this standard.
- Only one of connected sensors is allowed to send ZDA message, which will be used to adjust the system clock. If time difference is larger than 5 seconds and if the system is not a part of steering (i.e., mode is not Goto Wp, Goto Track or Program Track Turn) and if the system has Kalman filter in OFF position.
- Offset from antenna position to Conning position is essential for speed, course, drift and predictor related calculation.
- Roll & pitch data may be enabled only with PAT.
- First two channels can also operate as general purpose outputs. Checksum related parameters are for outputs only. Sent messages are GLL, VTG and HDT.
- There are two alternatives for IEC 61162-1 based interface: **ed1** and **ed2**. Ed1 was published in September 1998 and Ed2 was published in July 2000. The differences are new datum message (DTM) and changed content of GLL position message.
- Ed2 requires that position information (in this case GLL or GGA messages) also contain separate indication of datum used (DTM message). IMO rule states that ECDIS can only accept position in WGS84 datum. In practice only EPFS (for example, GPS or DGPS), which has "IEC 61162-1 Ed 2 (2000-7)" indicated in their type approval certificate can detect Datum.
- Ed2 requires that the GLL message includes a quality indicator i.e., the GLL message can indicate if position is based on standard GPS or differential GPS.

**Note for service engineer:**

If the vessel has main and backup system, then you must yourself set proper antenna offset for both systems. Keep in mind that they are two independent and separate systems, but they should share common antenna offset in case that they are connected to the same position antenna.

3. ADJUSTMENTS

Echo Sounder and Weather

Edit parameters - Echo Sounder and Weather

OK Cancel

	Echosounder (BOW)	Echosounder (AFT)	Water Current
Connected	YES	YES	YES
Device Interface	IEC61162-1 (\$xxDBT)	IEC61162-1 (\$xxDBT)	IEC61162-1 (\$xxCDR)
Adapter Chl	14	16	12
Talker Identifier	SS	SS	SS
Median Filter	NO	NO	
Sensor to keel distance	0 m	0 m	

	Water Temperature	Air Temperature	Air Pressure	Air Humidity
Connected:	YES	NO	NO	NO
Device Interface:	IEC61162-1 (\$xxMTW)	Analog(uses B-Adapter)	Analog(uses B-Adapter)	Analog(uses B-Adapter)
Adapter Chl:	10	8	6	4
Output	0 V (at 0 °C)	0 V (at 0 °C)	0 V (at 800 hPa)	0 V (at 0 %)
Output per Volt:	0 °C / Volt	2 °C / Volt	0 hPa/Volt	0 %/Volt
Prefiltering:	0	0	0	0
B-Adapter Chl:	2	3	7	5

Notes: (air temperature)

- Not used by this system, should have Connected = NO.

Notes: (air pressure)

- Not used by this system, should have Connected = NO.

Wind sensor

Here is an example of a wind sensor which is connected to LAN Adapter channel 15.

Edit parameters - Wind Sensor	
Connected:	YES
Adapter Channel:	15
Device Interface:	IEC 61162-1 (\$xMWV)
Identification	MWV
Interpretation of received angle	wind blows from direction of angle
Source of True Wind	Receive (T)heoretical Wind (HDG) and Calculate True Wind
Style of Display	Display Rel (=Apparent) or True (=North)
Style of send to ARPA	Send T (=True/Theoretical) or R (=Apparent)

Wind modes are defined as: The wind as measured by a wind meter is known as apparent wind. If indicated wind includes speed compensation it is known as relative wind. If indicated wind includes both speed and heading compensation it is known as true wind.

Definitions:

- **APPARENT** Wind as measured by wind meter.
- **RELATIVE** Wind includes speed compensation.
- **TRUE(T)heoretical** Wind includes both speed and heading compensations.
- **TRUE(=North)** Wind includes both speed compensation and North stabilization.

Notes:

- Talker identifier is ignored.
- THIES in the Device Interface is a special case.
- Calculation of true from relative can only be used if wind sensor sends TRUE wind according to definition above.
- **Source of True Wind** to define what kind of wind is transmitted by weather station: Receive (T)heoretical Wind (HDG) and calculate True wind is default.
- **Style of Display** to define what kind of wind is displayed on ECDIS, True wind or Relative wind.
- **Style of output to ARPA** to define what kind of wind is transmitted to ARPA.

3. ADJUSTMENTS

Trackpilot, autopilot

Settings when no Trackpilot is connected:

The screenshot shows the 'Edit parameters - Trackpilot' dialog box. The 'Device Interface' is set to 'ASPO-EMRI'. 'Connected' is set to 'NO'. 'Adapter Channel' is '3'. 'WPT Approach' is 'IEC 62065'. 'Steering Sources' is 'Trackpilot'. 'Steering Style' is 'Program Track'. 'Trackpilot SW type' is 'Uses Turn/Linear bit'. 'Radius Values' is 'No device limitations'. 'Minimum Turning Radius' is '0.1' NM. 'Lower Off Course Alarm Limit' is '15'. 'Higher Off Course Alarm Limit and Drift Compensation Limit' is '45'. 'Minimum Route Speed' is '8.0' kn. 'From Conning position to XTE calculation position (+Bow, -Stern)' is '50' m. 'Turn Endline in Route Steering' is 'WPT+WOP'. 'Received Messages' is 'Enable Check and Alarms'. 'IEC 61162-1 Transmit checksum' is 'Used'. 'Checksum' is '\$ char not included (IEC 61162-1 & EMRI)'. 'Manual Steering Label' is 'HAND'. 'Route Check' is 'IEC 62065 (Not required)'. 'Forwarding Distance Range' is '- 0.5 , 0.6 - 1.1 , 1.2 -'. 'Off Track Style' is 'Arrowheads (<,>)'. 'Auxiliary Steering Mode Info' is 'Not Used'. 'OK' and 'Cancel' buttons are at the top right.

Settings for FURUNO FAP-2000/EMRI SEM200 Trackpilot

The screenshot shows the 'Edit parameters - Trackpilot' dialog box. The 'Device Interface' is set to 'ASPO-EMRI'. 'Connected' is set to 'YES'. 'Adapter Channel' is '3'. 'WPT Approach' is 'IEC 62065'. 'Steering Sources' is 'Trackpilot'. 'Steering Style' is 'Traditional'. 'Trackpilot SW type' is 'Uses Turn/Linear bit'. 'Radius Values' is 'No device limitations'. 'Minimum Turning Radius' is '0.1' NM. 'Lower Off Course Alarm Limit' is '15'. 'Higher Off Course Alarm Limit and Drift Compensation Limit' is '45'. 'Minimum Route Speed' is '8.0' kn. 'From Conning position to XTE calculation position (+Bow, -Stern)' is '20' m. 'Turn Endline in Route Steering' is 'WPT+WOP'. 'Received Messages' is 'Enable Check and Alarms'. 'IEC 61162-1 Transmit checksum' is 'Used'. 'Checksum' is '\$ char not included (IEC 61162-1 & EMRI)'. 'Manual Steering Label' is 'HAND'. 'Route Check' is 'IEC 62065 (Not required)'. 'Forwarding Distance Range' is '- 0.5 , 0.6 - 1.1 , 1.2 -'. 'Off Track Style' is 'Arrowheads (<,>)'. 'Auxiliary Steering Mode Info' is 'Not Used'. 'OK' and 'Cancel' buttons are at the top right.

Notes:

In general all settings above are mandatory for FURUNO FAP-2000/EMRI SEM200 Trackpilot. The following parameters can be used to tailor the system to the vessel:

- Minimum turn radius
- Turn Endline in route steering
- From Conning position to XTE calculation position
- Minimum route speed
- Manual Steering Label
- Forwarding Distance Range
- Route Check (Available when "Connected" is "YES")
 - IEC-62065 (Not required): Route Monitor is available without Route Check.
 - DNV (Required by class note): Route Check is necessary to use Route Monitor.

FURUNO FAP-2000/EMRI SEM200 Trackpilot

FURUNO FAP-2000 Trackpilot is a separate unit. It consists of electronic unit AEU511 and control panel(s) MIP. If it is used with ECDIS some parameters must be as below. For further details, see separate manual for FAP-2000/EMRI SEM 200.

The values of the following remote interface parameters must be checked:

- VMS: 0 (Vector interface)
- VMSTimeout: 0 (Vector interface)
- ctsdef: 2 (cts=hsc when leaving remote (continue turn))
- seldef: 1 (display hsc as cts during remote track turns)
- lindef : 1 (default condition)
- SpeedSource: 3 (ECDIS is main source of speed)
- LogNmeaCh: 0 (ECDIS is connected to serial channel 0)
- FreezeRudder: 0 (Maintain manoeuvre after loss of heading)
- HdtTimeoutLimit 5 (For serial data gyro with high message rate more than 5 HDT messages per second. If message rate is less than this, then use HdtTimeoutLimit = 25).

The following parameter can be used to tailor the system to the vessel. Write down values of following parameters:

- fiondly: xx (Track regulator integrator start delay [sec], 64 is recommended)
- firw: xx (Track regulator integrator start limit [NM], 0.02 is recommended)
- ficimax xx (Max attack angle to track for integral part of cross track error [radians]. 0.2 is recommended, which is about 12 °.)
- fpcimax xx (Max attack angle to track for proportional part of cross track error [radians]. 0.2 is recommended, which is about 12 °.)
- Rrudabs: xx (Rudder limit for Radius and Goto WP mode)
- Grudabs: xx (Rudder limit for Heading Control, Program Track and Goto Track mode)
- sleng xxx (Ships length [m])
- u_norm xx (Max speed of vessel [kt])
- BackupSpeedSource x (Backup speed source if ECDIS fails. If no backup is available then set this as 3.)
- BackupLogNmeaCh x (Serial channel for backup speed source. If no backup is available then set this as 0.)

3. ADJUSTMENTS

- GyroNmeaCh x (Serial channel for gyro)
- PminRadius xx (Minimum available radius. Must be equal to ECDIS parameter.)

For proper track control, software of AEU511 must be "SEM200 Version Aeu2_3 Compiled 6-5-2003 15:37" and MIP31 must be "MIP2 Version Mip2 Compiled 7-5-2003 14:55".

Notes (Emergency instructions for cases when software of AEU511 or MIP31 is older version.)

- Parameter "ctsdef" requires careful special attention.
- When software of AEU511 is older than "SEM200 Version Aeu2_3 Compiled 13-2-2002"
- ctsdef0 cts=hsc when leaving remote (continue turn)
- When software of AEU511 is newer or equal to "SEM200 Version Aeu2_3 Compiled 13-2-2002"
- ctsdef2 turn/linear bit control behaviour. For turn, cts=hsc when leaving remote (continue turn). For linear, cts=hdg; when leaving remote (steady as she goes).

Note also that if software of AEU511 electronic unit is newer or equal to "SEM200 Version Aeu2_3 Compiled 13-2-2002", then software of MIP panel must be newer or equal to "MIP2 Version Mip2 Compiled 7-3-2002 13:33".

Yokogawa PT-500A Autopilot

Below are settings for the Yokogawa PT-500A Autopilot.

The screenshot shows the 'Edit parameters - Trackpilot' dialog box with the following settings:

- Device Interface: IEC 61162-1 (Yokogawa HTC/HTD)
- Connected: YES
- Adapter Channel: 3
- WP Approach Rule: IEC 62065
- Steering Sources: Trackpilot
- Radius Values: No device limitations
- From Conning position to XTE calculation position (+Bow, -Stern): 20 m
- Minimum Turning Radius: 0.1 nm
- Turn Endline in Route Steering: wp+wop
- Lower Off Course Alarm Limit: 15 °
- Received Messages: Enable Check and Alarms
- Higher Off Course Alarm Limit: 30 °
- IEC 61162-1 Transmit checksum: Used
- and Drift Compensation Limit: 25 °
- Checksum: \$ char not included (IEC 61162-1 & EMRI)
- Minimum Route Speed: 5.0 kt
- Route Check: IEC-62065 (Not required)
- Forwarding Distance Range: - 0.5 , 0.6 - 1.1 , 1.2 -

GENERAL NOTES:

- In general all settings above are mandatory for Yokogawa PT-500A Autopilot. The following parameters can be used to tailor the system to the vessel:
- Minimum turn radius
- Turn Endline in route steering
- From Conning position to XTE calculation position
- Minimum route speed

NOTES ABOUT PARAMETERS INSIDE YOKOGAWA PT-500A:

Yokogawa PT-500A Autopilot steering control unit is a separate unit, which can operate together with ECDIS. Some parameters must be as below in Autopilot control unit.

For more information see manual of Yokogawa PT-500A Autopilot.

Confirm that the values of following remote interface parameters are as follows:

- INS/GPS Inp: INS-2 (type B)
- INS/GPS Out: \$AGHDT (INS-2)
- Rudder State Control: BY-PASS

For proper steering, control software of Yokogawa PT-500A Autopilot must be:

- For Main: CPU-CR155K05 or newer
- For Calc: CPU-CR325A09 or newer

3. ADJUSTMENTS

TOKYO KEIKI PR-6000 Autopilot

Settings for TOKYO KEIKI PR 6000 Autopilot in ECDIS:

Edit parameters - Trackpilot

Device Interface: IEC 61162-1 (Tokimec HTC/HTD) OK Cancel

Connected: YES

Adapter Channel: 3

WP Approach Rule: IEC 62065

Steering Sources: Trackpilot

Radius Values: No device limitations

From Conning position to XTE calculation position (+Bow, -Stern): 63 m

Minimum Turning Radius: 0.1 nm

Turn Endline in Route Steering: wp+wop

Lower Off Course Alarm Limit: 4.6 °

Received Messages: Enable Check and Alarms

Higher Off Course Alarm Limit: 45 °

and Drift Compensation Limit: 25 °

IEC 61162-1 Transmit checksum: Used

Minimum Route Speed: 5.0 kt

Checksum: \$ char not included (IEC 61162-1 & EMRI)

Route Check: IEC-62065 (Not required)

Forwarding Distance Range: - 0.5 , 0.6 - 1.1 , 1.2 -

NOTES:

In general all setting above are mandatory for TOKYO KEIKI PR-6000 Autopilot. Following parameter can be used to tailor the system to the vessel

- Minimum turn radius
- Turn End line in route steering
- From Conning position to XTE calculation position
- minimum route speed
- Forwarding Distance Range

Settings for Tokimec PR 6000 Autopilot:

Tokimec PR 6000 Autopilot Autopilot steering control unit is a separate unit, which can operate together with ECDIS. Some parameters must be as below in Autopilot control unit.

1. Data setting

data 5 (speed compensation): 12 or 92
data 15 (rudder speed): bit6 = 0, bit7 = 0
data 30 (XTE Gain): 06
data 40 (drift compensation): 00

2. Auto Steering Control Adjusting(Ref AP manual)

	Adjustment	Auto Mode		RC-NAV Mode	Remarks
		PID	ADPT		
1	Rate of turn (RATE)	(1-9)	----	----	
2	Rudder Ratio (Rudder)	(1-9)	----	-----	
3	Weather adjustment (Weather)	(0-10)	----	-----	
4	ADPT(OPN/CNF)	----	OPN/CNF	OPN or CNF	Note 1
5	Pilot watch setting (Pilot Watch)	(5-15°)	(5-15°)	----	Note 3
6	Rudder limit setting (Rudder Limit)	(5-35°)	(5-35°)	----(Note 2)	

---: No function

Note1 Adaptive function becomes OPN on RC-NAV mode (under ECDIS control) when ADPT/Weather knob selected 0-10.

Note2 During RC-NAV mode (under ECDIS control), the Rudder Limit is ignored.

Note3 During RC-NAV mode (under ECDIS control), Pilot watch alarm is not given.

3. Speed selection

	Ship's speed input signal	Example of ordinary display	Example of display when operating CHANGE switch	Remarks
> 1	Log pulses input	20.5	P-Lc	Ship's speed is used from ECDIS when RC-NAV is selected.
2	Manual input	C 15.0(Manual)	P 0c - P40c	

(1) During RC-NAV mode, Low Speed Alarm on Autopilot is not given but ECDIS generate own Low Speed Alarm setting by installation parameter of Track pilot.

(2) During RC-NAV mode speed selection of Autopilot could not change.
NAV Ready lamp dose not lit when manual speed is selected on other mode than RC-NAV, then Autopilot could not accept to RC-NAV Mode (Track control).

(3) If speed selection of Autopilot is manual "SPD" indicator will be flicker on "AUTO", "HAND" or "NFU" mode.

Autopilot information area indicate as manual speed on ECDIS screen,

4. Software version

For proper track control, software of PR-6000 must be:

MMA: v3.80 ->

PID: v3.80 ->

ADNCT: v1.40 ->

3. ADJUSTMENTS

ROT gyro

No ROT Gyro connected:
The system calculates from
movement of Gyro heading.

Edit parameters - Rate of Turn Gyro

Connected:

NO, Calculated from Gyro source

OK

Cancel

Adapter Channel:

1

Device Type:

Gyro1: IEC 61162-1 (\$xROT)

B-Adapter Channel:

2

Output at 0 °/min:

-5

V

Output per Volt:

-40

(°/min) / V

Use sign of
Output per Volt to
change polarity of
Rate of turn

Prefiltering:

0

Max scale

200

ROT gyro value is received
from Dolog 23 dual-axis log.

Edit parameters - Rate of Turn Gyro

Connected:

YES

OK

Cancel

Adapter Channel:

8

Device Type:

DAX Dolog23: (\$PKDRU)

B-Adapter Channel:

2

Output at 0 °/min:

-5

V

Output per Volt:

-40

(°/min) / V

Use sign of
Output per Volt to
change polarity of
Rate of turn

Prefiltering:

0

Max scale

200

ROT gyro value is received
from gyro connected as
Gyro1.

Edit parameters - Rate of Turn Gyro

Connected:

YES

OK

Cancel

Adapter Channel:

7

Device Type:

Gyro 1: IEC 61162-1 (\$xROT)

B-Adapter Channel:

2

Output at 0 °/min:

-5

V

Output per Volt:

-40

(°/min) / V

Use sign of
Output per Volt to
change polarity of
Rate of turn

Prefiltering:

0

Max scale

200

ROT gyro value is received from Trackpilot.

Edit parameters - Rate of Turn Gyro

Connected: YES

Adapter Channel: 3

Device Type: Trackpilot

B-Adapter Channel: 2

Output at 0 °/min: -5 V

Output per Volt: -40 (°/min) / V

Prefiltering: 0

Max scale 200

OK

Cancel

Use sign of Output per Volt to change polarity of Rate of turn

ROT gyro value is received using analog interface directly from a ROT gyro sensor.

Edit parameters - Rate of Turn Gyro

Connected: YES

Adapter Channel: 4

Device Type: Analog (uses B-Adapter)

B-Adapter Channel: 2

Output at 0 °/min: -5 V

Output per Volt: -40 (°/min) / V

Prefiltering: 0

Max scale 200

OK

Cancel

Use sign of Output per Volt to change polarity of Rate of turn

3. ADJUSTMENTS

Conning display





Figure above shows how the windows are located in Conning Display.



1) Select Conning Mode (Harbour1, Harbour2, Navigate1 or Navigate2).

Note, Stand-alone Conning Mode is used only with Conning Processor CP-01 and sidebar Conning Display.

You can make individual settings for each Conning Mode in the Settings field.

2) Use Default Palette setting to define background of Conning Display. This palette is used when you start Conning Mode in question.

3) Define which windows are displayed in each Conning Mode in the Display field. For more information about content of windows, see the Operator's Manual.

- **Alarm messages** windows are used only if Device Interface of Alarm Inputs is "\$CAALA".
 - **Track pilot extended** window is used only if steering mode of Trackpilot is "Program Track".
 - **Service nnnn** windows are intended for use by a service engineer during sea trials.
- 4) Select Traditional, Double speed, Small size or Small with Double speed.
5) Select Traditional or Detailed.

Rudders

Select Connected **NO** if no rudder is connected to the ECDIS.

Edit parameters - Rudders

Connected:

NO

OK

Cancel

Device Type:

Trackpilot

Number of Rudders:

1

Navigation Display Scale Max:

23

Harbour Display Scale Max:

33

Rudder type:

Conventional (one scale)

Numerical value:

Not used

Not Used

Not Used

Not Used

Not Used

Label

ACT

Display method


Normal

Normal

Normal

Normal

One rudder is connected and value is received using analog interface.



Edit parameters - Rudders

Connected:

YES

OK

Cancel

Device Type:

Analog (uses B-Adapter)

Number of Rudders:

1

Navigation Display Scale Max:

23

Harbour Display Scale Max:

33

Rudder type:

Conventional (one scale)

Numerical value:

Not used

Use sign of Output per Volt to change polarity of Rudder

Rudder 1

Not Used

Not Used

Not Used

ACT

Not Used

Not Used

Not Used

ANALOG

Not Used

Not Used

Not Used

B-Adapter Channel

1

4

3

1

Output at 0 °

4.00 V

0.00 V

0.01 V

0.01 V

Output per Volt

-5.00 *V

0.00 *V

0.01 *V

0.70 *V

Prefiltering

0

0

0

0

Label

ACT

Not Used

Not Used

Not Used

Display method

Normal

Normal

Normal

Normal

Two rudders are connected and one value is received using analog interface and second value is received from Trackpilot.

Edit parameters - Rudders

Connected:

YES

OK

Cancel

Device Type:

Actual analog, Order Trackpilot

Number of Rudders:

2

Navigation Display Scale Max:

23

Harbour Display Scale Max:

33

Rudder type:

Conventional (one scale)

Numerical value:

Only ORD/Comered

Use sign of Output per Volt to change polarity of Rudder

Rudder 1

Rudder 2

Not Used

Not Used

ACT

ORD

Not Used

Not Used

ANALOG

TRACKPILOT

Not Used

Not Used

B-Adapter Channel

1

Output at 0 °

4.00 V

Output per Volt

-5.00 *V

Prefiltering

0

Label

ACT

Display method

Normal

Normal

Normal

Normal

3. ADJUSTMENTS

Two rudders are connected and values are received using analog interfaces.

Edit parameters - Rudders

Connected:

Device Type:

Number of Rudders:

Navigation Display Scale Max: *

Harbour Display Scale Max: *

Rudder type:

Numerical value:

Use sign of Output per Volt to change polarity of Rudder

	Rudder 1	Rudder 2	Not Used	Not Used
	ACT ANALOG	ORD ANALOG		
B-Adapter Channel	<input type="text" value="1"/>	<input type="text" value="4"/>	<input type="text" value="3"/>	<input type="text" value="1"/>
Output at 0°	<input type="text" value="4.00"/> V	<input type="text" value="0.00"/> V	<input type="text" value="0.01"/> V	<input type="text" value="0.01"/> V
Output per Volt	<input type="text" value="-5.00"/> *V	<input type="text" value="0.00"/> *V	<input type="text" value="0.01"/> *V	<input type="text" value="0.70"/> *V
Prefiltering	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>	<input type="text" value="0"/>
Label	<input type="text" value="ACT"/>			
Display method	<input type="text" value="Normal"/>	<input type="text" value="Normal"/>	<input type="text" value="Normal"/>	<input type="text" value="Normal"/>

Two rudders are connected and values are received from Trackpilot.

Edit parameters - Rudders

Connected:

Device Type:

Number of Rudders: *

Navigation Display Scale Max: *

Harbour Display Scale Max: *

Rudder type:

Numerical value:

Rudder 1	Rudder 2	Not Used	Not Used
ACT TRACKPILOT	ORD TRACKPILOT		
Label: <input type="text" value="ACT"/>			
Display method: <input type="text" value="Normal"/>	<input type="text" value="Normal"/>	<input type="text" value="Normal"/>	<input type="text" value="Normal"/>

Note: You can give "name" for rudder in the Label field. This "name" is displayed in the Rudder window of the Conning Display.

One rudder is connected and value is received from Engine Control.

Edit parameters - Rudders

Connected:

Device Type:

Number of Rudders:

Navigation Display Scale Max: *

Harbour Display Scale Max: *

Rudder type:

Numerical value:

Use sign of Output per Volt to change polarity of Rudder

	Rudder 1	Not Used	Not Used	Not Used
Output per Volt	<input type="text" value="-5.00"/> *V	<input type="text" value="0.00"/> *V	<input type="text" value="0.01"/> *V	<input type="text" value="0.70"/> *V
Label	<input type="text" value="ACT"/>			
Display method	<input type="text" value="Normal"/>	<input type="text" value="Normal"/>	<input type="text" value="Normal"/>	<input type="text" value="Normal"/>

Two rudders are connected and values are received from Engine Control.

Edit parameters - Rudders

Connected:

YES

Device Type:

Engine Control

Number of Rudders:

2

Navigation Display Scale Max:

23

Harbour Display Scale Max:

33

Rudder type:

Conventional (one scale)

Numerical value:

Only ORD/Comered

OK

Cancel

Use sign of Output per Volt to change polarity of Rudder

	Rudder 1	Rudder 2	Not Used	Not Used
	ACT ENGINE CTRL	ORD ENGINE CTRL		
Output per Volt	<div>-5.00</div> °V	<div>0.00</div> °V	<div>0.01</div> °V	<div>0.70</div> °V
Label	<div>ACT</div>			
Display method	<div>Normal</div>	<div>Normal</div>	<div>Normal</div>	<div>Normal</div>

Rudder-type Azimuth Propulsion
Display method = Azimuth 0° up and Display method = Azimuth 0° down are used to select between alternative scale for Azimuth propulsion window.

Rudder-type-Azimuth Propulsion and values, are received as SIN/COS values using analog interface.

Note: For each rudder required, two analog channels are required to receive both SIN and COS values.

Edit parameters - Rudders

Connected:

YES

Device Type:

Analog SIN/COS (uses B-Adapter)

Number of Rudders:

2

Navigation Display Scale Max:

23

Harbour Display Scale Max:

33

Rudder type:

Azimuth Propulsion (no scale)

Numerical value:

Not used

OK

Cancel

Use sign of Polarity to change turning direction of Azimuth

	Azimuth 1	Azimuth 2	Azimuth 1	Azimuth 2
	ANALOG Sin	ANALOG Sin	ANALOG Cos	ANALOG Cos
B-Adapter Channel	<div>1</div> SIN	<div>4</div> SIN	<div>3</div> COS	<div>1</div> COS
Output at 0 unit	<div>4.00</div> V	<div>0.00</div> V	<div>0.01</div> Offset °	<div>0.01</div> Offset °
Output per Volt	<div>-5.00</div> unit/V	<div>0.00</div> unit/V	<div>0.01</div> Polarity	<div>0.70</div> Polarity
Prefiltering	<div>0</div>	<div>0</div>	<div>0</div>	<div>0</div>
Label	<div>ACT</div>			
Display method	<div>Azimuth 0° up</div>	<div>Azimuth 0° up</div>		

3. ADJUSTMENTS

Two rudders are connected and values are received as IEC 61162-1 (\$xxRSA) formatl.

Edit parameters - Rudders

Connected: YES

Device Type: IEC 61162-1 (\$xxRSA)

Number of Rudders: 2

Navigation Display Scale Max: 37 °

Harbour Display Scale Max: 37 °

Rudder type: Conventional (one scale)

Numerical value: Cornered

Use scaling factor to generate real Rudder angle from the proportional value in message

	Rudder 1 PORT RSA (single value)	Rudder 2 STBD RSA (single value)	Not Used	Not Used
Adapter Channel	0	16	16	16
Talker Identifier	II			SD
Scaling factor	1.00	1.00	2.00	2.00
Label	ACT	ORD		
Display method	Normal	Normal	Normal	Normal

Propellers

Select Connected **NO** if propeller is not connected to the ECDIS.

Edit parameters - Propellers 1 (stern)

General

Connected: NO

OK

Cancel

Device Type: Analog (uses B-Adapter)

Label:

In use

B-Adapter channel

Output at 0

B-Adapter output per Volt

Prefiltering

Minimum

Maximum

RPM

3

0

-26.45

0

0

100

Pitch

NO

4

9.7

-28.94

0

-99.96

100

Power

NO

2

0

0

0

30000

Torque

NO

2

0.01

0.01

0

70

M/E Rpm

YES

0

0.00

0.00

0

0

0

Ship has one fixed propeller connected as Propeller 1 (stern).

Edit parameters - Propellers 1 (stern)

General

Connected: YES

OK

Cancel

Device Type: Analog (uses B-Adapter)

Label:

In use

B-Adapter channel

Output at 0

B-Adapter output per Volt

Prefiltering

Minimum

Maximum

RPM

3

0

-26.46

0

0

100

Pitch

NO

4

9.7

-28.95

0

-99.97

100

Power

NO

2

0

0

0

30000

Torque

NO

1

0.01

0.01

0

70

M/E Rpm

YES

0

0.00

0.00

0

0

0

Ship has one pitch propeller connected as Propeller1 (stern).

Edit parameters - Propellers 1 (stern)

General

Connected: YES

OK

Cancel

Device Type: Analog (uses B-Adapter)

Label:

In use

B-Adapter channel

Output at 0

B-Adapter output per Volt

Prefiltering

Minimum

Maximum

RPM

3

0

-26.47

0

0

100

Pitch

YES

4

9.7

-28.96

0

-99.98

100

Power

NO

2

0

0

0

30000

Torque

NO

2

0.01

0.01

0

70

M/E Rpm

YES

0

0.00

0.00

0

0

0

Ship has two pitch propellers and the second propeller is connected as Propeller2 (stern).

Edit parameters - Propellers 2 (stern)

General

Connected: YES

OK

Cancel

Device Type: Analog (uses B-Adapter)

Label: STBD

In use

B-Adapter channel

Output at 0

Output per Volt

Prefiltering

Minimum

Maximum

RPM

5

0

-26.47

0

0

100

Pitch

YES

6

0

-31.96

0

-99.96

100

Power

NO

7

0

0

0

30000

Torque

NO

8

0.01

0.01

0

70

M/E Rpm

YES

0

0.00

0.00

0

0

0

Note: You can give "name" for propeller in Label field. This "name" is displayed in the Propeller window of the Conning Display.

3. ADJUSTMENTS

Ship has one pitch propeller connected as Propeller 1 (stern) using Engine Control Device Type “IEC 61162-1 (MAN B+W, \$xxXDR, \$xxRPM)”.

Edit parameters - Engine Control

Connected: YES

OK

Adapter Channel: 15

Cancel

Device Type: IEC 61162-1 (MAN B+W, \$xxXDR, \$xxRPM)

Propulsion Control Position Available: YES

Ship has one pitch propeller connected as Propeller1 (stern) using Engine Control “NCDAT”, “PNAV” or proprietary message used by Sindel simulators.

Edit parameters - Propeller 1 (stern)

General

Connected: YES

OK

Device Type: Engine Control

Cancel

Label: PB

In use

RPM

Pitch

M/E Rpm

ID

6

5

NO

B-Adapter channel

Minimum

0

RPM

-100.0

unit

30000

kW

70

Nm

-500

RPM

Maximum

100

RPM

100.0

unit

500

RPM

Edit parameters - Engine Control

Connected: YES

OK

Adapter Channel: 15

Cancel

Device Type: \$NCDAT,\$PNAV,Sindel (timeout 30 s)

Switch Input

In Use

Open is OFF

Fixed Use For

1

☐

☐

Propeller 1

2

☐

☐

Propeller 1

3

☐

☐

Propeller 2

4

☐

☐

Propeller 2

5

☐

☐

Not Used

6

☐

☐

Not Used

7

☐

☐

Not Used

8

☐

☐

Not Used

9

☐

☐

Not Used

10

☐

☐

Not Used

11

☐

☐

Not Used

12

☐

☐

Not Used

13

☐

☐

Not Used

14

☐

☐

Not Used

15

☐

☐

Not Used

16

☐

☐

Not Used

Edit parameters - Propeller 1 (stern)

General

Connected: YES

OK

Device Type: Engine Control

Cancel

Label: PB

In use

RPM

Pitch

Power

Torque

M/E Rpm

B-Adapter channel

Minimum

0

RPM

-100.0

unit

30000

kW

70

Nm

-500

RPM

Maximum

100

RPM

100.0

unit

500

RPM

Ship has two pitch propellers and the first propeller is connected as Propeller 1 (stern) using Engine Control “NCDAT”, “PNAV” or proprietary message used by Sindel simulators.

Edit parameters - Engine Control

Connected: YES

OK

Adapter Channel: 15

Cancel

Device Type: \$NCDAT,\$PNAV,Sindel (timeout 30 s)

Switch Input	In Use	Open is OFF	Fixed Use For
1	<input checked="" type="checkbox"/>	<input type="checkbox"/>	Propeller 1
2	<input type="checkbox"/>	<input type="checkbox"/>	Propeller 1
3	<input type="checkbox"/>	<input type="checkbox"/>	Propeller 2
4	<input type="checkbox"/>	<input type="checkbox"/>	Propeller 2
5	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
6	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
7	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
8	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
9	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
10	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
11	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
12	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
13	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
14	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
15	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
16	<input type="checkbox"/>	<input type="checkbox"/>	Not Used

Ship has two pitch propellers and the second propeller is connected as Propeller 2 (stern) using Engine Control “NCDAT”, “PNAV” or proprietary message used by Sindel simulators.

Edit parameters - Propeller 1 (stern)

General

Connected: YES

OK

Device Type: Engine Control

Cancel

Label: PB

In use

RPM

Pitch: YES

Power: NO

Torque: NO

M/E Rpm: NO

B-Adapter channel

Minimum

0 RPM

-100.0 unit

30000 kW

70 Nm

-500 RPM

Maximum

100 RPM

100.0 unit

500 RPM

Ship has one pitch propeller. You can connect and scale Main Engine RPM to be displayed on Conning Display.

Edit parameters - Propeller 2 (stern)

General

Connected: YES

OK

Device Type: Engine Control

Cancel

Label: STBD

In use

RPM

Pitch: YES

Power:

Torque: NO

M/E Rpm: NO

B-Adapter channel

Minimum

0 RPM

-100.0 unit

30000 kW

70 Nm

-500 RPM

Maximum

100 RPM

100.0 unit

500 RPM

Edit parameters - Propeller 1 (stern)

General

Connected: YES

OK

Device Type: Engine Control

Cancel

Label: PB

In use

RPM

Pitch: YES

Power: NO

Torque: NO

M/E Rpm: YES

B-Adapter channel

Minimum

0 RPM

-100.0 unit

30000 kW

70 Nm

-500 RPM

Maximum

100 RPM

100.0 unit

500 RPM

3. ADJUSTMENTS

Ship has two pitch propellers and the second propeller is connected as Propeller2 (stern) using Engine Control.

Edit parameters - Propellers 2 (stern)

General

Connected: YES

Device Type: Engine Control

Label: STBD

OK

Cancel

In use

B-Adapter channel 5

Output at 0 0 V

Output per Volt -26.45 RPM/V

Pitch YES

6

0 V

-31.94 unit/V

0

-99.94 unit

100 unit

Power NO

7

0 V

0 kW/V

0

30000 kW

Torque NO

8

0.01 V

0.01 Nm/V

0

70 Nm

M/E Rpm YES

0

0.00 V

0.00 RPM/V

0

0 RPM

0 RPM

Ship has azimuth propulsion: **Maximum RPM = 800** and **Minimum RPM = 0** creates bar scale from 0 to 800.

Label = PORT is used as label for azimuth propulsion.

Edit parameters - Propellers 2 (stern)

General

Connected: YES

Device Type: Analog (uses B-Adapter)

Label: PORT

OK

Cancel

In use

B-Adapter channel 3

Output at 0 0 V

Output per Volt -26.41 RPM/V

Pitch NO

4

9.7 V

-28.9 unit/V

0

-99.92 unit

100 unit

Power NO

2

0 V

0 kW/V

0

30000 kW

Torque NO

1

0.01 V

0.01 Nm/V

0

70 Nm

M/E Rpm YES

0

0.00 V

0.00 RPM/V

0

0 RPM

0 RPM

Ship has azimuth propulsion: **Maximum RPM = 800** and **Minimum RPM = 0** creates bar scale from 0 to 800.

Label = STBD is used as label for azimuth propulsion.

Edit parameters - Propellers 2 (stern)

General

Connected: YES

Device Type: Engine Control

Label: STBD

OK

Cancel

In use

B-Adapter channel 5

Output at 0 0 V

Output per Volt -26.45 RPM/V

Pitch NO

6

0 V

-31.94 unit/V

0

-99.94 unit

100 unit

Power NO

7

0 V

0 kW/V

0

30000 kW

Torque NO

8

0.01 V

0.01 Nm/V

0

70 Nm

M/E Rpm YES

0

0.00 V

0.00 RPM/V

0

0 RPM

0 RPM

Ship has azimuth propulsion: **Maximum RPM = 350** and **Minimum RPM = -350** creates bar scale:-350 .. 0 .. 350.

Label = SWNG is used as label for azimuth propulsion.

Edit parameters - Propellers 2 (stern)

General

Connected: YES

Device Type: Analog (uses B-Adapter)

Label: SWNG

OK

Cancel

In use

B-Adapter channel 4

Output at 0 -4.99 V

Output per Volt 20 RPM/V

Pitch NO

5

0 V

0 unit/V

0

-99.99 unit

100 unit

Power NO

1

0 V

0 kW/V

0

10000 kW

Torque NO

1

0.01 V

0.01 Nm/V

0

70 Nm

M/E Rpm YES

0

0.00 V

0.00 RPM/V

0

0 RPM

0 RPM

Thrusters

Select Connected **NO** if thruster is not connected to the ECDIS.

Edit parameters - Thrusters 1 (stern)

Connected:

NO

OK

Device Type:

Analog (uses B-Adapter)

Cancel

B-Adapter Channel:

5

Output at 0 rpm:

100

V

Use sign of Output per Volt to change polarity of bar presentation

Output per Volt:

85

rpm/V

Prefiltering:

0

Maximum Power:

100

Maximum rpm:

100

Thruster 1 (stern) is connected to the ECDIS.

Edit parameters - Thrusters 1 (stern)

Connected:

YES

OK

Device Type:

Analog (uses B-Adapter)

Cancel

B-Adapter Channel:

7

Output at 0 rpm:

0

V

Use sign of Output per Volt to change polarity of bar presentation

Output per Volt:

30

rpm/V

Prefiltering:

0

Maximum Power:

100

Maximum rpm:

100

Thruster 3 (bow) is connected to the ECDIS.

Edit parameters - Thrusters 3 (bow)

Connected:

YES

OK

Device Type:

Analog (uses B-Adapter)

Cancel

B-Adapter Channel:

8

Output at 0 rpm:

0

V

Use sign of Output per Volt to change polarity of bar presentation

Output per Volt:

-25

rpm/V

Prefiltering:

0

Maximum Power:

100

Maximum rpm:

100

3. ADJUSTMENTS

Thruster 1 (stern) is connected to the ECDIS using Engine Control.

Edit parameters - Thrusters 1 (stern)

Connected:

YES

OK

Device Type:

Engine Control

Cancel

B-Adapter Channel:

8

Output at 0 rpm:

100

V

Output per Volt:

85

rpm/V

Prefiltering:

0

Maximum Power:

10000

Maximum rpm:

10000

Use sign of Output per Volt to change polarity of bar presentation

Thruster 3 (bow) is connected to the ECDIS using Engine Control.

Edit parameters - Thrusters 3 (bow)

Connected:

YES

OK

Device Type:

Engine Control

Cancel

B-Adapter Channel:

7

Output at 0 rpm:

100

V

Output per Volt:

10

rpm/V

Prefiltering:

0

Maximum Power:

10000

Maximum rpm:

10000

Use sign of Output per Volt to change polarity of bar presentation

Main engine start air pressure

Select Connected **NO** if Main Engine Start Air Pressure is not connected to the ECDIS.

Edit parameters - Main Engine Start Air Pressure

Connected:

NO

Device Type:

Analog (uses B-Adapter)

B-Adapter Channel:

4

Output at 0 kg/cm2:

0

V

Output per Volt:

5

kg/cm2 / V

Prefiltering:

0

Alarm

20

kg/cm2

Maximum Value:

50

kg/cm2

OK

Cancel

Main Engine Start Air Pressure connected to the ECDIS.

Edit parameters - Main Engine Start Air Pressure

Connected:

YES

Device Type:

Analog (uses B-Adapter)

B-Adapter Channel:

2

Output at 0 kg/cm2:

0

V

Output per Volt:

-5

kg/cm2 / V

Prefiltering:

0

Alarm

20

kg/cm2

Maximum Value:

50

kg/cm2

OK

Cancel

Main Engine Start Air Pressure connected to the ECDIS using Engine Control.

Edit parameters - Main Engine Start Air Pressure

Connected:

YES

Device Type:

Engine Control

B-Adapter Channel:

1

Output at 0 kg/cm2:

0.07

V

Output per Volt:

0

kg/cm2 / V

Prefiltering:

0

Alarm

20

kg/cm2

Maximum Value:

50

kg/cm2

OK

Cancel

3. ADJUSTMENTS

Fuel consumption

Select Connected **NO** if Fuel Consumption is not connected to the ECDIS.

The screenshot shows the 'Edit parameters - Fuel Consumption' dialog box. The 'Connected' dropdown is set to 'NO'. The 'Device Type' is 'Analog (uses B-Adapter)'. The 'Main Flow' section has 'In Use' checked, 'B-Adapter Channel' set to 5, 'Output at 0 Position' at 0.00 V, 'Output per Volt' at 200.00 units/V, and 'Prefiltering' at 0. The 'Ret Flow' section has 'In Use' checked, 'B-Adapter Channel' set to 8, 'Output at 0 Position' at 0.00 V, 'Output per Volt' at 0.00 units/V, and 'Prefiltering' at 0. The 'Temperature' section has 'In Use' checked, 'B-Adapter Channel' set to 8, 'Output at 0 Position' at 0.00 °/V, 'Output per Volt' at 0.00 °/V, and 'Prefiltering' at 0. The 'Units' dropdown is set to 'kg' and 'HFO Used' is 'YES'. The 'Cancel' and 'OK' buttons are at the bottom right.

Fuel consumption connected to the ECDIS.

The screenshot shows the 'Edit parameters - Fuel Consumption' dialog box. The 'Connected' dropdown is set to 'YES'. The 'Device Type' is 'Analog (uses B-Adapter)'. The 'Main Flow' section has 'In Use' checked, 'B-Adapter Channel' set to 5, 'Output at 0 Position' at 0.00 V, 'Output per Volt' at 200.00 units/V, and 'Prefiltering' at 0. The 'Ret Flow' section has 'In Use' checked, 'B-Adapter Channel' set to 8, 'Output at 0 Position' at 0.00 V, 'Output per Volt' at 0.00 units/V, and 'Prefiltering' at 0. The 'Temperature' section has 'In Use' checked, 'B-Adapter Channel' set to 8, 'Output at 0 Position' at 0.00 °/V, 'Output per Volt' at 0.00 °/V, and 'Prefiltering' at 0. The 'Units' dropdown is set to 'kg' and 'HFO Used' is 'YES'. The 'Cancel' and 'OK' buttons are at the bottom right.

Fuel consumption connected to the ECDIS using Engine Control.

The screenshot shows the 'Edit parameters - Fuel Consumption' dialog box. The 'Connected' dropdown is set to 'YES'. The 'Device Type' is 'Engine Control'. The 'Main Flow' section has 'In Use' checked, 'B-Adapter Channel' set to 5, 'Output at 0 Position' at 0.00 V, 'Output per Volt' at 200.00 units/V, and 'Prefiltering' at 0. The 'Ret Flow' section has 'In Use' checked, 'B-Adapter Channel' set to 8, 'Output at 0 Position' at 0.00 V, 'Output per Volt' at 0.00 units/V, and 'Prefiltering' at 0. The 'Temperature' section has 'In Use' checked, 'B-Adapter Channel' set to 8, 'Output at 0 Position' at 0.00 °/V, 'Output per Volt' at 0.00 °/V, and 'Prefiltering' at 0. The 'Units' dropdown is set to 'kg' and 'HFO Used' is 'YES'. The 'Cancel' and 'OK' buttons are at the bottom right.

Alarm inputs+Outputs/AMWSS

Settings for closed contact external alarm inputs required in the past to fulfil OMBO class notation of RINA. If this feature is activated it generates alarms 4201...4208 "Ext. navigation eq. Error".

Settings when the ECDIS is connected to Alarm Monitoring and Watch Safety System (AMWSS). ECDIS alarms are transferred to AMWSS.

Local ECDIS alarm acknowledge and EMRI trackpilot acknowledge operate only as buzzer stop.

ECDIS and EMRI trackpilot alarms can only be acknowledged from AMWSS.

Alarm 9997 transferred to ECDIS is used to acknowledged first alarm (topmost).

Settings when the ECDIS is connected to Alarm Monitoring and Watch Safety System (AMWSS).

ECDIS alarms are transferred to AMWSS.

ECDIS and EMRI trackpilot alarms can be acknowledged locally or from AMWSS.

Local acknowledge of an alarm removes the alarm also from AMWSS.

Cursor position of ECDIS is transmitted.

3. ADJUSTMENTS

Sensor Source of ECDIS is transmitted

Settings when the ECDIS is connected to a Central Alarm System which uses only closed contacts. Input channels 9 and 10 of B-Adapter are used for Alarm Ack. and Buzzer Stop.

*:

(Relays energized when no alarm)
Relay outputs: close (no Alarm),
open (Alarm active)

(Relays energized when alarm)
Relay outputs; close (Alarm active),
open (no Alarm)

Connected: YES

Adapter Channel: 12

Device Interface: IEC 61162-1 (AMWSS + SensorSource)

Relay outputs

LAN-adapters: Relays energized when no alarm

B-adapter: Relays energized when no alarm

IEC 61162-1 (AMWSS)

Message type: With pending flag and history support

Local alarm ack.: Normal acknowledge

Alarm system type: All state alarm has pending state

Remove from steering alarm group

<input checked="" type="checkbox"/> 451	<input type="checkbox"/> 485	<input type="checkbox"/> 494
<input checked="" type="checkbox"/> 458	<input type="checkbox"/> 489	<input type="checkbox"/> 495
<input type="checkbox"/> 475	<input type="checkbox"/> 492	<input type="checkbox"/> 396
<input type="checkbox"/> 476	<input type="checkbox"/> 493	<input type="checkbox"/> 497

Remove from nav. alarm group

<input checked="" type="checkbox"/> 320	<input checked="" type="checkbox"/> 457
<input checked="" type="checkbox"/> 400	
<input checked="" type="checkbox"/> 401	
<input checked="" type="checkbox"/> 402	

Connected: YES

Device Interface: Relays with Central Alarm (use B-Adapter)

Relay outputs

LAN-adapters: Relays energized when no alarm

B-adapter: Relays energized when no alarm

Relays with Central Alarm

Ignore pending state for

<input checked="" type="checkbox"/> 451	<input type="checkbox"/> 485
<input checked="" type="checkbox"/> 458	

Connected: YES

Device Interface: Relays with Central Alarm including state + pending (use B-Adapter)

Relay outputs

LAN-adapters: Relays energized when no alarm

B-adapter: Relays energized when no alarm

Relays with Central Alarm

Ignore pending state for

<input checked="" type="checkbox"/> 451	<input type="checkbox"/> 485
<input checked="" type="checkbox"/> 458	

Edit parameters - Alarm Inputs + Outputs / AMWSS

Connected: YES

OK

Cancel

Device Interface: Relays with Central Alarm including pending (use B-Adapter)

Relay outputs

LAN-adapters

Relays energized when no alarm

B-adapter

Relays energized when no alarm

Relays with Central Alarm

Ignore pending state for

☒ 451

☐ 485

☒ 458

Edit parameters - Alarm Inputs + Outputs / AMWSS

Connected: YES

OK

Cancel

Device Interface: Relays with Central Alarm + SensorSource (use B-Adapter)

Relay outputs

LAN-adapters

Relays energized when no alarm

B-adapter

Relays energized when no alarm

Relays with Central Alarm

Ignore pending state for

☒ 451

☐ 485

☒ 458

Settings when the ECDIS is connected to Engine Control System.

Edit parameters - Alarm Inputs + Outputs / AMWSS

Connected: YES

OK

Cancel

Device Interface: Engine control

Relay outputs

LAN-adapters


Relays energized when no alarm

B-adapter

Relays energized when no alarm

3. ADJUSTMENTS

Alarm system and Alarm ACK



NAVTEX Receiver

Check alphabets to receive corresponding data. For details, see the operator's manual for NAVTE receiver connected.

The screenshot shows the 'Edit parameters - NAVTEX Receiver' dialog box. It contains the following fields and options:

- Connected:** YES (dropdown menu)
- Adapter Channel:** 12 (text input)
- Device Type:** IEC 61162-1 (4800bit/s) (dropdown menu)
- INS Masks:** A grid of checkboxes for letters A through Z, with 'Type' and 'Area' labels.

The 'Type' and 'Area' labels are followed by checkboxes for each letter. The 'Type' checkboxes are all checked, and the 'Area' checkboxes are also all checked.

SatCom/External Computer/Sindel repeaters

- Settings for Route backup to Furuno GP-80 GPS navigator.

- Setting for Ropute Restore from Furuno GP-80 GPS navigator.

-Wiring of ECDIS and GP-80/90

EC-1010	GP-80/90
(CH1, 3, 4, 9, 11 to 13)	(DATA4)
RXD+	TD-B
RXD-	TD-A
TXD+	RD-B
TXD-	RD-A

Settings for route backup to external equipment which can receive IEC 61162-1 message.

AIS

Settings for AIS Transponder.

ETA display:

“Type approved (adjusted for time zone)”; Displays the local time changed from ETA reported at the ship.

“Custom (ignore time zone)”; Display ETA reported at the ship as is.

3. ADJUSTMENTS

Engine control

Settings for receiving Fuel Consumption, Propeller and Main Engine Air Pressure data from engine control system manufactured by NORCONTROL (used message is \$NCDAT).

Note that full use of this feature requires that you also activate Fuel Consumption, Propeller and Main Engine Air Pressure parameters, set as Engine Control.

Edit parameters - Engine Control [X]

Connected: YES [v]
Adapter Channel: 10
Device Type: IEC 61162-1 (timeout 30 s) [v]

OK
Cancel

Switch Input	In Use	Open is OFF	Fixed Use For
1	<input type="checkbox"/>	<input type="checkbox"/>	Propeller 1
2	<input type="checkbox"/>	<input type="checkbox"/>	Propeller 1
3	<input type="checkbox"/>	<input type="checkbox"/>	Propeller 2
4	<input type="checkbox"/>	<input type="checkbox"/>	Propeller 2
5	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
6	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
7	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
8	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
9	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
10	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
11	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
12	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
13	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
14	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
15	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
16	<input type="checkbox"/>	<input type="checkbox"/>	Not Used

Settings for receiving Propeller, Thruster and Rudder data from simulated engine control system manufactured by SINDEL (used message are \$PLPRO, \$PLTHR and \$PLRAN). Note that full use of this feature requires that you also activate Propeller, Thruster and Rudder parameters, set as Engine Control.

Edit parameters - Engine Control [X]

Connected: YES [v]
Adapter Channel: 10
Device Type: IEC 61162-1 (timeout 4 min) [v]

OK
Cancel

Switch Input	In Use	Open is OFF	Fixed Use For
1	<input type="checkbox"/>	<input type="checkbox"/>	Propeller 1
2	<input type="checkbox"/>	<input type="checkbox"/>	Propeller 1
3	<input type="checkbox"/>	<input type="checkbox"/>	Propeller 2
4	<input type="checkbox"/>	<input type="checkbox"/>	Propeller 2
5	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
6	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
7	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
8	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
9	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
10	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
11	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
12	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
13	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
14	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
15	<input type="checkbox"/>	<input type="checkbox"/>	Not Used
16	<input type="checkbox"/>	<input type="checkbox"/>	Not Used

Speed pilot

Settings when speedpilot is **not** connected.

Dialog box titled "Edit parameters - Speedpilot". Fields include: Connected: NO, Adapter Chl: 9, Device Interface: Speedpilot (EMRI), Device mode: Normal, IEC 61162-1 Transmit checksum: Not used, Checksum: \$ char not included (IEC 61162-1 & EMRI). Buttons: OK, Cancel.

Settings when speedpilot is connected.

Dialog box titled "Edit parameters - Speedpilot". Fields include: Connected: YES, Adapter Chl: 9, Device Interface: Speedpilot (EMRI), Device mode: Normal, IEC 61162-1 Transmit checksum: Not used, Checksum: \$ char not included (IEC 61162-1 & EMRI). Buttons: OK, Cancel.

Alarm Inputs External

You can define which sensors report alarms to ECDIS.

- Check "Conn" for sensor reporting to ECDIS.
- Check "Bi-dis" option, if acknowledge message will be sent to alarm transmitting sensor
- Check "Retry ack" option, if acknowledge message to alarm transmitting sensor fails to respond (retry three times)

Dialog box titled "Edit parameters - Alarm Inputs/External". It contains a table with columns: Ch, Conn, Bi-dir, Retry, ack, Alarm, source name. The table lists 16 sensors with checkboxes for Conn, Bi-dir, and Retry. Buttons: OK, Cancel.

Ch	Conn	Bi-dir	Retry	ack	Alarm	source name
1	<input type="checkbox"/>					EXT1
	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			POS1
3	<input type="checkbox"/>					RUDR2
4	<input type="checkbox"/>					EXT4
5	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>			AIS
6	<input type="checkbox"/>					POS2
7	<input type="checkbox"/>					GYRO1
8	<input type="checkbox"/>					LOG
9	<input type="checkbox"/>					EXT9
10	<input type="checkbox"/>					EXT10
11	<input type="checkbox"/>					BADAP
12	<input type="checkbox"/>					AMWSS
13	<input type="checkbox"/>					ROUTE
14	<input type="checkbox"/>					ECHO
15	<input type="checkbox"/>					WIND
16	<input type="checkbox"/>					EXT16

In this example Position equipment 1 connected to channel 2 of LAN Adapter can report alarm in Position equipment 1.

AIS in channel 5 of LAN Adapter reports alarm in AIS and they can be also acknowledged in ECDIS or Central Alarm System.

Central Alarm Output

You can define channel for Central Alarm System to where report sensor alarms.

- “Bi-directional” as YES, in case that if alarms can be acknowledged from Central Alarm System.
- “Propagate RX alarms” used to define if alarm from alarms transmitting sensor are sent further to Central Alarm System.

Dialog box titled "Edit parameters - Central Alarm Output". Fields include: Connected: YES, Adapter Chl: 13, Bi-directional: YES, Propagate RX alarms: YES, Device Type: IEC 61162-1 (4800 bit/s). Buttons: OK, Cancel.

3. ADJUSTMENTS

Sensors which are not connected

In installation parameters there are several sensors in a list which are not used with ECDIS and their status should be **Connected = NO**.


The list of sensors which are not connected:

(Electronic Chart, VDR, Position Equipment, Heel and Trim, Steering Info)

Storing default parameters

After installing the equipment, store the default parameters of the ECDIS as follows:

1. Connect service (for PC) keyboard.
2. Press Windows key.
3. Click **Start, Programs, Accessories** and **Windows Explore** in order.
4. Choose **My Computer, Local Disk [C:], ANTS_SYSTEM** and **params** in order to open the params folder.



5. Click **sensor.prm**, **ship.prm** and **wstation.prm** while pressing the Shift key.
6. Choose **Copy** from the Edit menu.
7. Open **default** folder, and choose **Paste** from Edit menu. If overwriting them, confirm replacement of existing file by pressing **OK**.
8. Go back to normal ECDIS operation mode.

Note: The above steps allow you to return parameters by clicking “Set parameter defaults” on Installation parameters when changing Sensor parameter settings.

3.3 Adjustments for the LAN Adapter EC-1010

3.3.1 Setup for the LAN adapter EC-1010 program

The following tools are needed for programming LAN adapter:

- Ordinary serial RS-232C line cable to make connection from COM1 port to Connector J13 of LAN Adapter.

You need to set the jumpers of the LAN adapter to enable connector J13 and programming mode.

To change J1 (CH 1) connector to J13 Connector for programming, set as below.

J17	CTS1-GND
J14	TXP
J15	RXP

To enable manual startup and programming, set as below.

J16	INIT-GND
-----	----------

3.3.2 IP address agreement for LAN Adapter EC-1010

The table below shows IP addresses for each device.


Device	IP Address	Function
First ECDIS	10.0.0.180	MAIN
Second ECDIS	10.0.0.181	BACKUP
First LAN adapter	10.0.0.190	MAIN 1 st LAN adapter
Second LAN adapter	10.0.0.191	MAIN 2 nd LAN adapter
First LAN adapter	10.0.0.192	BACKUP 1 st LAN adapter
Second LAN adapter	10.0.0.193	BACKUP 2 nd LAN adapter

3.3.3 How to load programs for LAN adapter EC-1010

The following is an example of how to program the first LAN adapter for the first ECDIS.


Note: The program version for LAN adapter should be same with ECDIS's.

1. Click **Start, Programs, Accessories** and **Windows Explore** in order.
2. Click **My Computer, Local Disk [C], LAN Adapter** in order to open the LAN Adapter folder.
3. Double click **Shortcut to 7188xw.exe**.



7188XW program will start in MS DOS window.


3. ADJUSTMENTS



```
7188XW 1.14 [COM1:115200,N,8,1] DIR=C:\LANAdapter
7188x for WIN32 version 1.14 (03/08/2002)[By ICPDAS. Tim.]
Current set: Use COM1 115200,N,8,1
AutoRun:
Autodownload files: None
Current work directory="C:\LANAdapter"
original baudrate = 9600!
now baudrate = 115200!

i7188E>_
```

4. Type IP, and then press the ENTER key to confirm the IP address. For the first LAN adapter of MAIN ECDIS, Type SETIP 10.0.0.190, and press the ENTER key.



```
7188XW 1.14 [COM1:115200,N,8,1] DIR=C:\LANAdapter

Current set: Use COM1 115200,N,8,1
AutoRun:
Autodownload files: None
Current work directory="C:\LANAdapter"

Command not supported !

i7188E>setip 10.0.0.190
Set IP=10.0.0.190
[ReadBack]IP=10.0.0.190
i7188E>_
```

5. Type SETMASK 255.255.0.0 and then press the ENTER key. To confirm the netmask, type MASK, and press the ENTER key.
6. Remove old files from LAN adapter; type del *.* , and then press the ENTER key.

```

7188XW 1.14 [COM1:115200,N,8,1] DIR=C:\LANadapter

Current set: Use COM1 115200,N,8,1
AutoRun:
Autodownload files: None
Current work directory="C:\LANadapter"

Command not supported !

i7188E>setip 10.0.0.190
Set IP=10.0.0.190
[ReadBack]IP=10.0.0.190
i7188E>del *.*
Total File number is 2, do you really want to delete(y/n)?

i7188E>

```

7. Load autoexec.bat and sercotr.exe as shown below.
 - a) Type "Load".
 - b) Press the Alt key and E key at the same time.
 - c) Type the file name to load.

```

7188XW 1.14 [COM1:115200,N,8,1] DIR=C:\LANadapter

i7188E>load
File will save to 8000:0000
StartAddr-->7000:FFFF
Press ALT_E to download file!
Input filename:autoexec.bat
Load file:autoexec.bat
Send file info. total 1 blocks
Block 1
Transfer time is: 0.051000 seconds

i7188E>load
File will save to 8002:0009
StartAddr-->8000:0028
Press ALT_E to download file!
Input filename:sercotr.exe
Load file:sercotr.exe
Send file info. total 837 blocks
Block 837
Transfer time is: 43.002000 seconds

i7188E>_

```


3. ADJUSTMENTS

8. Set parameters for LAN adapter as follows:

a) Type command.


Status	Command
First LAN adapter (MAIN)	sercotr /d=2 /p=15001 /r=15000 /f=1 /n=8 /m=0 /e0=10.0.0.180
Second LAN adapter (MAIN)	sercotr /d=3 /p=15001 /r=15000 /f=9 /n=8 /m=0 /e0=10.0.0.180
First LAN adapter (BACKUP)	sercotr /d=4 /p=15001 /r=15000 /f=1 /n=8 /m=0 /e0=10.0.0.181
Second LAN adapter (BACKUP)	sercotr /d=5 /p=15001 /r=15000 /f=9 /n=8 /m=0 /e0=10.0.0.181

For example, type the command for First LAN adapter (MAIN).



```
7188XW 1.14 [COM1:115200,N,8,1] DIR=c:\LANadapter
i7188E>
i7188E>sercotr /d=2 /p=15001 /r=15000 /f=1 /n=8 /m=0 /e0=10.0.0.180 /e1=0.0.0.0
```

b) Type the command: **sercotr /e2=0.0.0.0 /e3=0.0.0.0 e4=0.0.0.0**




```
7188XW 1.14 [COM1:115200,N,8,1] DIR=c:\LANadapter
Conf d=2 p=15001 r=15000 f=1 n=8 m=0
Hosts e0=10.0.0.180 e1=0.0.0.0 e2=0.0.0.0 e3=0.0.0.0 e4=0.0.0.0
01.01.2000 00:00:01 Waiting watchdog reset

ICP_DAS MiniOS7 for I-7188E Ver. 2.00 build 001,Aug 22 2003 15:29:32
SRAM:512K, FLASH MEMORY:512K
[CPU=RDC 8820-D]
Serial number= 01 8c 9A A0 09 00 00 87

i7188E> sercotr /e2=0.0.0.0 /e3=0.0.0.0 /e4=0.0.0.0
```

9. Type **sercotr**, and press the ENTER key.



```
7188XW 1.14 [COM1:115200,N,8,1] DIR=C:\LANadapter
Channel reset: 7
Blks 50 ffffffff
Alive timer reload (CSerMain::Receive)
Set baudrates
Blks 50 ffffffff
Alive timer reload (CSerMain::Receive)
Blks 50 ffffffff
Alive timer reload (CSerMain::Receive)
Blks 50 ffffffff
Alive timer reload (CSerMain::Receive)
Blks 50 ffffffff
19.08.2004 15:04:45 laninsCount 3086 (3973 3867 106)
19.08.2004 15:04:45 ** Panic (reason: 37) **
LAN Adapter d5.00
Own IP: 10.0.0.190
Conf d=2 p=15001 r=15000 f=1 n=8 m=0
Hosts e0=10.0.0.180 e1=0.0.0.0 e2=0.0.0.0 e3=0.0.0.0 e4=0.0.0.0
19.08.2004 15:04:45 Waiting watchdog reset

ICP_DAS MiniOS7 for I-7188E Ver. 2.00 build 001,Aug 22 2003 15:29:32
SRAM:512K, FLASH MEMORY:512K
[CPU=RDC 8820-D]
Serial number= 01 0F 97 9F 09 00 00 0A

i7188E>
```

10. Confirm that the setting is correct.

11. Set jumpers to the default position.


12. Turn the power of LAN adapter off, and on again.

3.3.6 Installation of Network Connections


You can install network connections between the Navigation ECDIS and second (for planning/back-up) ECDIS. To install, proceed as follows:

1. Turn the power on.
2. If you already have ECDIS installed, then you have to shut down the ECDIS program before you install network connections.

To shut down the ECDIS program, use the ECAWATCH window to do it. This window can be shown by pressing the Tab key on the service keyboard several times while pressing down the Alt key.




3. Click the **Shutdown the ECDIS** button.
4. Press the Windows key, and choose **Start, Programs, Accessories** and **Windows Explorer** in order.
5. Choose Map Network Drive from the Tools menu.




3. ADJUSTMENTS

6. Select drive I: for the hard disk of the other ECDIS computer.
Browse the other ECDIS computer from ECDIS work group.
7. Select **Ec1000C-0001\ANTS_SYSTEM** and press OK.




7. Select Tools and Map Network Drive again.
8. Select drive J: for the CD-ROM drive of the other ECDIS computer.
Browse the other ECDIS computer from ECDIS work group.
9. Select **Ec1000C-0001\CD drive** and press OK. (Note that EC1000C-0001 should be replaced with the name of the other computer.)



3.4 DIP Switches and Jumper Wires


3.4.1 LAN adapter EC-1010



Jumper	Position	Function
J14	TXP	Programming
	TXD1	Normal operation (Default)
J15	RXP	Programming
	RXD1	Normal operation (Default)
J17	CTS1 H-CTS1	Programming
	CTS1-GND	Normal operation (Default)
J16	GND-INIT	Programming
	INIT H-INIT	Normal operation (Default)

3. ADJUSTMENTS

3.4.2 Radar overlay (EC-1000-C-R-S/1000C-CR-S only)



Potentiometer	Function
R53	Difference between HI and LO video
R11	Video gain

Radar 1	Radar 2	Radar 3	Function
R12	R13	R14	STC length
R87	R88	R89	STC shape

Note: When connecting to the FAR-2xx7 radar, remove the jumper J13 (for trigger).

Jumper	Position	Furuno	Function
J6	1-2 2-3	1-2	Factory default
J7	1-2 2-3	2-3	Positive Video Polarity Negative Video Polarity Factory default
J8	1-2 2-3	1-2	Positive Video Polarity Factory default Negative Video Polarity
J10	1-2 2-3	2-3	Positive HL Polarity Negative HL Polarity Factory default
J11	1-2 2-3	1-2	Trigger Polarity Positive Edge Factory default Trigger Polarity Negative Edge
J12	ON		Video 75Ω terminator in use Factory default
J13	ON		Trigger 75Ω terminator in use Factory default


To set card address, use DIP switch **SW1** according to the following table:

SW1/1	SW1/2	SW1/3	SW1/4	Address
ON	ON	ON	ON	200h
OFF	ON	ON	ON	220h
ON	OFF	ON	ON	240h
OFF	OFF	ON	ON	260h
ON	ON	OFF	ON	280h
OFF	ON	OFF	ON	2A0h
ON	OFF	OFF	ON	2C0h
OFF	OFF	OFF	ON	2E0h
ON	ON	ON	OFF	300h
OFF	ON	ON	OFF	320h
ON	OFF	ON	OFF	340h
OFF	OFF	ON	OFF	360h Factory default
ON	ON	OFF	OFF	380h
OFF	ON	OFF	OFF	3A0h
ON	OFF	OFF	OFF	3C0h
OFF	OFF	OFF	OFF	36Eh


3. ADJUSTMENTS

3.4.3 B adapter EC-1020


All settings of B adapter are for gyro compass.



Jumper	Position	Function
400	open	50/60 Hz Synchro
	1-2	400 Hz Synchro
ST SY	1-2	Stepper
	2-3	Synchro



SYNCHRO 90-135VAC STEPPER 20-48VDC

	R17	2K2	22 ohms (1W)
	R18	10K	2K7 (1W)
	R19	10K	2K7 (1W)
	R20	10K	2K7 (1W)

Factory default is SYNCHRO 90-135 VAC. If you have a STEPPER 20-48 VDC, you need to replace resistors R17, R18, R19 and R20 with values given in the figure above.

Connector J38 pin	Stepper	Synchro
S0	Common	Not used
S1	Phase 1	Phase 1
S2	Phase 2	Phase 2
S3	Phase 3	Phase 3
R1H	Not used	If peak voltage is more than 60V.
R1L	Not used	If peak voltage is less than 60V.
R2	Not used	Common

3.5 Installation of optional Furuno PP-510 printer


Furuno PP-510 printer can be connected to ECDIS using USB, not directly to LPT1: port. You have to use "**USB to parallel adapter**" to connect Furuno PP-510 printer to the USB port. If printer is shared then it is possible to print from all workstations in the network.

Installation of printer

1. Connect "USB to parallel adapter" between printer and ECDIS.
2. Turn on printer and ECDIS.
3. Select first "**Settings**" from Start menu and then "**Printers and Faxes**".
4. Double-click the Add Printer icon to show the following window.



5. Press the **Next** button.
6. Select "Local printer attached to this computer".



7. Press the **Next** button.
8. Select "Use the following port: USB001". (Virtual printer port for USB)

Add Printer Wizard

Select a Printer Port
Computers communicate with printers through ports.

Select the port you want your printer to use. If the port is not listed, you can create a new port.

☒ Use the following port: USB001 (Virtual printer port for USB)

Note: Most computers use the LPT1: port to communicate with a local printer. The connector for this port should look something like this:

☐ Create a new port:
Type of port:

< Back Next > Cancel

9. Press the **Next** button.

10. Select printer Manufacturer as IBM and Printer as **"IBM Proprinter II"** and press the **Next** button.

Add Printer Wizard

Install Printer Software
The manufacturer and model determine which printer software to use.

Select the manufacturer and model of your printer. If your printer came with an installation disk, click Have Disk. If your printer is not listed, consult your printer documentation for compatible printer software.

Manufacturer	Printers
Generic	IBM Proprinter
Gestetner	IBM Proprinter II
HP	IBM Proprinter III
IBM	IBM Proprinter X24
Infotec	
Lexmark	

This driver is digitally signed. Windows Update Have Disk...

< Back Next > Cancel

11. Enter name for printer and press the **Next** button.

Add Printer Wizard

Name Your Printer
You must assign a name to this printer.

Type a name for this printer. Because some programs do not support printer and server name combinations of more than 31 characters, it is best to keep the name as short as possible.

Printer name:
IBM Proprinter II


Do you want to use this printer as the default printer?

☒ Yes
☐ No

< Back Next > Cancel

12. To use a network printer, select **"Share name:"** and press the **Next** button.

3. ADJUSTMENTS



Add Printer Wizard

Printer Sharing
You can share this printer with other network users.


If you want to share this printer, you must provide a share name. You can use the suggested name or type a new one. The share name will be visible to other network users.

☐ Do not share this printer

☒ Share name:

< Back Next > Cancel

13. These fields can be left blank. Press the **Next** button.



Add Printer Wizard

Location and Comment
You have the option of supplying a location and description of this printer.


You can describe the location and capabilities of this printer. This information may be helpful to users.

Location:

Comment:

< Back Next > Cancel

14. To print test pages after installation, select "Yes" and press the **Next** button.



Add Printer Wizard

Print Test Page
To confirm that the printer is installed properly, you can print a test page.

Do you want to print a test page?

☒ Yes

☐ No

< Back Next > Cancel

15. When installation is ready completed, the following window appears.



16. Press the **Finish** button.

Installation of shared printer

If you want to print from a workstation other than the one to which the printer is directly connected, you have to install Printer software to the workstation in following way:

1. Select first "**Settings**" from Start menu and then "**Printers and Faxes**"
2. Double Click Add Printer icon.
3. Following window appears, and then press the **Next** button.



4. Select "**A network printer, or a printer attached to another computer**", and then press the **Next** button.

3. ADJUSTMENTS

Add Printer Wizard

Local or Network Printer
The wizard needs to know which type of printer to set up.

Select the option that describes the printer you want to use:

☐ Local printer attached to this computer

☐ Automatically detect and install my Plug and Play printer

☒ A network printer, or a printer attached to another computer

To set up a network printer that is not attached to a print server, use the "Local printer" option.

< Back Next > Cancel

5. Select **"Connect to this printer (or to browse for a printer, select this option and click next)"**.

Add Printer Wizard

Specify a Printer
If you don't know the name or address of the printer, you can search for a printer that meets your needs.

What printer do you want to connect to?

☐ Browse for a printer

☒ Connect to this printer (or to browse for a printer, select this option and click Next):

Name:

Example: \\server\printer

☐ Connect to a printer on the Internet or on a home or office network:

URL:

Example: http://server/printers/myprinter/.printer

< Back Next > Cancel

6. Press the **Next** button.
7. Click printer name, and then press the **Next** button.

Add Printer Wizard

Browse for Printer
When the list of printers appears, select the one you want to use.

Printer:

Shared printers:

	ECDIS
	\\EC1000C-0001\IBM Proprinter II IBM Proprinter II


Printer information

Comment:


Status: Ready Documents waiting: 0

< Back Next > Cancel

8. Press the **Yes** button.



9. Select **Yes**.



10. Press **Next** button.

11. When installation is completed successfully, the following window appears.




12. Press the **Finish** button.


3.6 Activation of CM-93/3

Before CM-93/3 charts can be used, you have to activate eToken (the dongle for system ID) of CM-93/3 as follows:

1. Start ECDIS.
2. Select "C-Map Ed3 installation" from Menu -> Initial settings.



3. C-Map Installation dialog box appears. Press the **Install** button.



4. The eTInstall dialog box appears.




5. Insert eToken to USB port.



6. Press **Cancel** button. Then press the **Yes** button.



7. Remove eToken from USB-port and then press **OK** button.




8. Insert eToken into USB port and then press **OK** button.




9. Confirm re-initialization.

3. ADJUSTMENTS




10. Press the **Yes** button

11. You have to remove licenses stored on ECDIS.




12. Press the **Yes** button.

Note: Press the **No** button to escape from the installation of C-MAP 93/3 to start.




13. Press the **Next** button to start the Product Catalogue Setup Wizard.

14. Make selections as below.




15. Press the **Next** button to start installation.




3. ADJUSTMENTS

16. Press the **Next** button. Installation starts. This may take a while.




17. When installation is completed the following window appears.




18. Press the **Close** button.

If the following window appears, you have not removed all licenses stored on ECDIS (see step 17). You have to remove eToken from USB-port and restart ECDIS computer and then start Installation of Product Catalogue in step 14.



19. Then following window appears.



20. Click "X". Chart drawing software restarts automatically.

3.7 Reinstall of ECDIS software

Important things to do before reinstall


When you upgrade ECDIS system some information will be removed permanently from the hard disk. Some of the information you may need later, therefore if it is necessary make a paper copy of Voyage Log files and ship parameters (ship.prm). Make also notes of manual reinstalls which you have to make manually again after reinstalling.

Loading of ECDIS software


You can reinstall ECDIS software by using ECDIS installation CD-ROM. Connect the service keyboard and mouse, then reinstall ECDIS software as follows:

3. ADJUSTMENTS


1. You already have ECDIS installed and you have to shut down ECDIS program before you can make a new installation. To shut down ECDIS program, press the **Shutdown the ECDIS** button.



2. Then you will get an empty screen which prevents normal user from entering the operating system. You close the empty screen by pressing Alt and F4 keys of the service keyboard together.




3. Close Control Head program. Use Alt+Tab keys to activate Control Head program on display. Use X in upper right corner to close Control Head.




4. Insert the CD-ROM for installation to the processor unit, and then select **Run** from the **Start** menu. Type the name as shown here to run ECDIS software installation.




5. A **System Information** window appears, press **Yes** button to continue the installation.



6. If the Windows Classic style is not in use a following window appears. Follow the instructions to enable the Classic style.




7. Press the **Next** button.




3. ADJUSTMENTS

8. Select desired Setup Type.


Note: This example is full ECDIS installation without Conning Display.



9. Enter password "ecdis" for ecdis user and press the **Next** button.




10. Select destination location for ECDIS and press the **Next** button.




11. Select Components to be installed and press the **Next** button.


Note: Check “Analog Radar Overlay” when the processor unit contains the optional Analog Radar Overlay board.



12. Check selection box if C-Map ed. 3 is used.




13. Enter HASP PIN Number “2371” and press the **Next** button.




3. ADJUSTMENTS

14. Sharing information can be entered here and then press **Next** button.




The 'ECDIS Setup' dialog box, 'Share Info' tab, is shown. It contains instructions to enter a share name for 'C:\ANTS_SYSTEM' and the CD-ROM drive 'E:'. A note states: 'NOTE! To skip sharing, enter blank share name(s)'. The 'AntsSystem' field is filled with 'ANTS_SYSTEM' and the 'CD-ROM' field is filled with 'cd_drive'. At the bottom, there are buttons for '< Back', 'Next >', and 'Cancel'.

15. Select a COM Port for the Control Head, set other parameters as appropriate, and press the **Next** button.
COM Port: "COM2" only
Alarm Tone: "7" only




The 'ECDIS Setup' dialog box, 'Set Control Head parameters' tab, is shown. It contains four settings: 'COM Port' set to 'COM2', 'Brilliance (0 - 255)' set to '255', 'Alarm Tone' set to '7', and 'Alarm Volume' set to '7'. At the bottom, there are buttons for '< Back', 'Next >', and 'Cancel'.

16. Select Monitor type, calibration and Control Port for display, and press the **Next** button.



The 'ECDIS / ChartRadar Setup' dialog box, 'Monitor Parameters' tab, is shown. It contains instructions to 'Set Monitor Type and Serial Port for communicating to Monitor.' The 'Default Color Calibration' is set to 'Leave unchanged (upgrade)' and the 'Monitor Port' is set to 'COM1'. At the bottom, there are buttons for '< Back', 'Next >', and 'Cancel'.

17. Set ECDIS and IP Address for ARPA. Set I/O base port for Radar Overlay, and press the **Next** button.



The 'ECDIS / ChartRadar Setup' dialog box, 'Radar Overlay and LAN Serial' tab, is shown. It contains instructions to 'Select IP Address for LAN ARPA (Radar Overlay and LAN Serial)'. The 'Interface address type' is set to 'Default For First ECDIS' and the 'IP Address' is set to '172.31.3.29'. Below, it says 'Select I/O Base Port for Analog Radar Overlay card.' and the 'Analog Radar Overlay Board I/O Port' is set to a default value. At the bottom, there are buttons for '< Back', 'Next >', and 'Cancel'.

18. Set LAN Adapter parameters and press the **Next** button.
Example of first ECDIS default settings with two LAN Adapters.

ECDIS Setup

LAN Adapter parameters

Set IP addresses and check if this ECDIS is sensor source for LAN Adapter (Sensor source both initializes and sends output to device).

Default For First ECDIS

Interface addresses

10.0.0.180

ECDIS IP for LAN Adapters

LAN Adapter IP

This ECDIS is

10.0.0.190

☒ Install 1

☒ Sensor Source for 1

10.0.0.191

☒ Install 2

☒ Sensor Source for 2

For Future Use

☐ Install 3

☐ Sensor Source for 3

For Future Use

☐ Install 4

☐ Sensor Source for 4

InstallShield

< Back

Next >

Cancel

Example of second ECDIS default settings with one LAN Adapter.

ECDIS / ChartRadar Setup

LAN Adapter parameters

Set IP addresses and check if this ECDIS is sensor source for LAN Adapter (Sensor source both initializes and sends output to device).

Default For Second ECDIS

Interface addresses

10.0.0.181

ECDIS IP for LAN Adapters

LAN Adapter IP

This ECDIS is

10.0.0.192

☒ Install 1

☒ Sensor Source for 1

10.0.0.193

☐ Install 2

☐ Sensor Source for 2

For Future Use

☐ Install 3

☐ Sensor Source for 3

For Future Use

☐ Install 4

☐ Sensor Source for 4

InstallShield

< Back


Next >

Cancel


3. ADJUSTMENTS

19. Select files to be deleted from ECDIS, and press the **Next** button.


Note: When upgrading from version 05.xx software, check all boxes to erase corresponding items.




20. Press the **Next** button.



21. Setup progress is shown with a progress book.



22. Press the **Finish** button to restart ECDIS.



3. ADJUSTMENTS

Important things to do after reinstall

After you have reinstall ECDIS program, you will need to initialize ECDIS to restore previous state.


Automatic erase of the old situation memory and internal files has removed the following setups and files from the hard disk.

- Chart details has been set as initial default values. For information about how to set desired values, see "Control of visible chart features" in the Operator's Manual.
- Select Navigation sensors from the Sensor page.
- SENC format of S57 charts has been removed.
- Manual Reinstall has been removed. Make Manual Updates based on the Notes you made before Upgrade.


How to convert already loaded S57 charts into SENC format

You can reconvert hard disk stored charts S57 into SENC format by doing the following:


1. Open the Chart Menu.
2. Choose "Chart Catalogue" .




3. Push the **New** button.
4. Create a group named "ALL", and press **OK** button.




5. Click “Group” in the View filters, and then choose “ALL”.




6. Choose all available charts in the Outside window at the bottom of the window.



7. Press << button to set group “ALL” as active.



8. Open SENC Convert window from the Chart Menu and activate conversion for group “ALL”, press **Convert** button to start conversion for Group “ALL”.



You will get a list of charts to be converted to SENC format. (Content of **Conversion List** depends on charts loaded into ECDIS.)

When conversion is completed, the **Conversion List** will be empty again.

For details, see chapter “How to use SENC Convert window to initiate SENC conversion” in Operator’s Manual.

3. ADJUSTMENTS

This page is intentionally left blank.

4. INPUT/OUTPUT SIGNALS

Introduction

The main method for transferring data between a sensor and the ECDIS is IEC 61162-1 Ed.1 or IEC 61162-1 Ed.2 Standard serial communication link.

In the standard configuration, the system has one serial communication channel interface, LAN adapter type EC-1010, to communicate with up to eight external devices in serial format. As an option, second LAN adapter can be connected for max. 16 serial channels in total.

Optionally the ECDIS can be interface to analog signals through a B adapter type EC-1020. For communication with ECDIS this analog adapter use, one serial channel from the LAN adapter.

Standard interfaces

Gyro compass

- One serial input type of gyro compass (IEC 61162-1 Ed.1 or Ed.2 message \$XXHDT..., min 1 message per second. With radar overlay the recommendation is 5 messages per second.)

Speed log

- One serial input type of dual-axis speed log (IEC 61162-1 Ed.1 or Ed.2 message \$XXVBW.... or NMEA V1.5 message \$PKVBW... or NMEA V1.5 message \$PSALL, min 1 message per 2 seconds).

Positioning equipment

- Two positioning equipment can be connected using one of the following communication protocols:
 - IEC 61162-1 Ed.1 messages \$XXGLL, \$XXVTG and \$XXZDA
 - IEC 61162-1 Ed.1 messages \$XXGGA, \$XXVTG and \$XXZDA
 - IEC 61162-1 Ed.2 messages \$XXDTM, \$XXGLL, \$XXVTG and \$XXZDA
 - IEC 61162-1 Ed.2 messages \$XXDTM, \$XXGGA, \$XXVTG and \$XXZDA
- **Notes:**
 - Min message rate is 1 message per 5 seconds
 - Recommended rate is 1 message per second
 - Alternatives 1, 2 and 3 has separate talker identifier selection for VTG and GLL/GGA/PAT.
 - Message \$XXZDA should only be used with one of the position equipment.
 - Only alternatives 2 and 3 have Differential-flag for DGPS use.
 - Only equipment, which has fixed datum (like WGS-84) in their position message should be used. Alternatives 6 and 7 check that the used datum is WGS84.

4. INPUT/OUTPUT SIGNALS

ARPA Radar

- Two ARPA radars can be connected using one of the following communication protocols.
 - IEC 61162-1 Ed.1 or Ed.2 standard messages \$XXOSD and \$XXTTM for input and messages \$ECGLL, \$ECDTM, \$ECDPT and \$ECMWV for output. Targets numbered from 1 to 100 are accepted in TTM message. The datum of GLL message is fixed and it is WGS84 (for serial interface only).
 - FURUNO interface with IEC 61162-1 Ed.1 standard messages \$XXOSD and \$XXTTM for input and messages \$IIGLL, \$IIOSD for output + proprietary messages for user charts, routes, curved ebl, etc (for serial interface and LAN).

AIS transponder equipment

- One serial input interface (IEC 61993-2 Ed.1 message !XXVDM, message types 1,2,3 and 5, min 1 message per 10 seconds)
- **Notes:**
 - Max. 1500 simultaneous AIS targets can stored for display purposes.
 - Max. 200 simultaneous AIS targets out of 1500 stored can be displayed.

Trackpilot

- Serial data interface based on NMEA V1.5 messages for EMRI SEM-200 or FURUNO FAP-2000 Trackpilot (IEC 62065 category B and C for TCS)
- Or serial data interface based on NMEA messages for YOKOGAWA autopilot (NOTE: IEC 62065 type approval of category B for TCS)
- Or serial data interface based on NMEA messages for TOKYO KEIKI autopilot (NOTE:IEC 62065 type approval category C for TCS)

External interfaces

Echo Sounder

- One serial input type echo sounder (IEC 61162-1 Ed.1 or Ed.2 message \$XXDBT... , min 1 message per 5 seconds)

Wind measuring device

- One serial input type wind sensor (IEC 61162-1 Ed.1 or Ed.2 message \$XXMWV..., min 1 message per 10 seconds)

Water temperature measuring device

- One serial input type wind sensor (IEC 61162-1 Ed.1 or Ed.2 message \$XXMTW..., min 1 message per 10 seconds)

Positioning equipment

- One additional positioning equipment

Gyro compass

- One analog type of gyro compass (90-135VAC Synchro 1:360 or 20-48 VDC Stepper 1/6°)

Speed log

- One analog pitot log (200 pulses/nm)

Rate of Turn Gyro compass

- ROT information has following alternative sources:
- ROT can be calculated from the ordinary gyro system heading.
- ROT can be received from a serial type Gyro compass (\$XXROT...).
- ROT can be received from a ROT gyro with analogic voltage output (+/- 10 V).
- ROT can be received from a serial type dual-axis speed log, if it is equipped with a ROT gyro and if it sends message \$PKDRU....

Main propeller

- One or two propellers having RPM and pitch with analog interface.
- 2-kohm potentiometers installed in all propellers.
- Reference voltage to potentiometers (+/-12v), supplied from the ECDIS.
- Each analog input is associated with a status signal (closed contact) which indicates the availability of the analog signal.

4. INPUT/OUTPUT SIGNALS

Thrusters

- One bow and one stern thruster with analog interface.
- 2-kohm potentiometers installed in all thrusters.
- Reference voltage to potentiometers (+/-12v) supplied from the ECDIS.
- Each analog input is associated with a status signal (closed contact) which indicates the availability of the analog signal.

Rudder

- One or two rudder indicators
- Rudder indicators have the following sources:
 - Both actual and order can be received from a track pilot with serial data.
 - Actual can be received from analog interface and order can be received from a track pilot in serial data.
 - Both actual and order can be received from analog interface.
 - Or alternatively port and starboard rudder feedback can be received from analog interface.
 - Both actual and other can be received from IEC 61162-1 (\$xxRSA).
- Analog interface for rudder has following specification.
 - 2-kohm potentiometers installed in the steering gear system.
 - Reference voltage to potentiometers (+/-12v) supplied from the ECDIS.
 - Typically the same rudder feed back unit can be used also for track Pilot system. (A dual-potentiometer in the feed back unit is then required)
 - Each analog input is associated with a status signal (closed contact) which indicates the availability of the analog signal.

Engine start air pressure

- One engine start air pressure analog interface.
- 2-kohm potentiometers installed in engine start air pressure.
- Reference voltage to potentiometer (+/-12v) supplied from the ECDIS.
- Analog input is associated with a status signal (closed contact) which indicates the availability of the analog signal.

Air pressure

- One air pressure analog interface.
- typical instrument is a VAISALA pressure sensor having current output.

Fuel consumption

- One fuel pump with analog interface
- Analog input is associated with a status signal (closed contact) which indicates the availability of the analog signal.

Route backup to external devices

- One serial output type Furuno DGPS receiver GP-80 (IEC 61162-1 Ed.1 based proprietary messages)
- Or one serial output interface (IEC 61162-1 Ed.1 message \$EIRTE, \$EIWPL)

Route restore from external devices

- One serial input type Furuno DGPS receiver GP-80 (IEC 61162-1 Ed.1 based proprietary messages)

Speed Pilot

- One serial data interface (IEC 61162-1 Ed.1 based proprietary messages)
- Alarm Management and Watch Safety System (AMWSS)
- One serial data interface (IEC 61162-1 Ed.1 based proprietary messages)

Alarm outputs

- ROUTE MONITOR: OUTSIDE CHANNEL LIMITS alarm as open contact (Contact closed is No Alarm)
- ROUTE MONITOR: WAYPOINT APPROACH alarm as open contact (Contact closed is No Alarm)
- ECHO: DEPTH BELOW LIMIT alarm as open contact (Contact closed is No Alarm)
- NAVIGATION SENSOR ALARM as open contact (Contact closed is No Alarm) from B adapter

Alarm inputs

- Alarm inputs has following sources:
 - Serial messages from EMRI Central Alarm Management
 - Closed/Open contact inputs (max 8 pieces) from B adapter

4. INPUT/OUTPUT SIGNALS

Radar Overlay

- Video: min 2 Vpp, max 5 Vpp, positive or negative polarity
- Trigger: min 5 V, max 30 V, positive or negative polarity, zero distance
- Headline: min 5 V, max 30 V, positive or negative polarity
- Azimuth: min 5 V, max 30 V, positive polarity, 128...1024 pulses / 360°
- Selection: 2 pieces of selection inputs to define parameter set selection for Radar Overlay. The inputs are coded and give a possibility to define three alternative radars. Selection input: min 5 V, max 24 V.

5. RADAR SWITCH (OPTION)

To connect two radars excepting FAR-21x7/28x7 series, use the optional radar switch.

Type	Code No.	Remarks
CP03-29501	008-544-940	For 12 VDC
CP03-29502	008-544-950	For 24 VDC


Contents

See the packing lists attached at the back of this manual

Mounting

Radar switch

Mount the switch at the mounting position with four tapping screws (M4, local supply).




Radar switch

5. RADAR SWITCH (OPTION)

Radar selector


Make five holes (one for toggle switch) to mount the switch on the desktop or bulkhead as below.









Radar selector

Connection

Connect cables as below.









NAME		OUTLINE	DESCRIPTION/CODE No.		Q'TY
ユニット					
表示部			MU-2010E		1
DISPLAY UNIT			000-083-404-00		
予備品					
予備品			SP03-14700		1
SPARE PARTS			008-549-730-00		
付属品					
付属品			FP03-09810		1
ACCESSORIES			008-536-010-00		
工事材料					
INSTALLATION MATERIALS					
DVIケーブル			CABLE DIGITAL DVI 5M		1
DVI CABLE			999-999-137-00		(*)
ケーブル組品			00619-001		1
CABLE ASSEMBLY			000-171-765-10		
図書					
DOCUMENT					
取扱説明書			OMC-41222-*		1
OPERATOR'S MANUAL			000-159-669-1*		

(*)1は、がミコードに付き、注文できません。
(*)1) THIS CODE CANNOT BE ORDERED.

型式・コード番号が2段の場合、下段より上段に代わる過渡期品であり、どちらかが入っています。なお、品質は変わりません。
TWO TYPES AND CODES MAY BE LISTED FOR AN ITEM. THE LOWER PRODUCT MAY BE SHIPPED IN PLACE OF THE UPPER PRODUCT. QUALITY IS THE SAME.
(略図の寸法は、参考値です。DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

03GR-X-9851

NAME		OUTLINE	DESCRIPTION/CODE No.	Q'TY
ユニット				
表示部	DISPLAY UNIT		MU-231CE 000-083-405-00	1
予備品				
予備品	SPARE PARTS		SPO3-14700 008-549-730-00	1
付属品				
付属品	ACCESSORIES		FP03-09810 008-536-010-00	1
工事材料				
INSTALLATION MATERIALS				
DVIケーブル		CABLE DIGITAL DVI 5M 999-999-137-00	1 (*)	
ケーブル組品		00619-001 000-171-765-10	1	
図書				
DOCUMENT				
取扱説明書		OMC-41222-* 000-159-669-1*	1	
OPERATOR'S MANUAL				

(*)1は、がミコードに付き、注文できません。
(*)1) THIS CODE CANNOT BE ORDERED.











型式・コード番号が2段の場合、下段より上段に代わる過渡期品であり、どちらかが入っています。なお、品質は変わりません。
TWO TYPES AND CODES MAY BE LISTED FOR AN ITEM. THE LOWER PRODUCT MAY BE SHIPPED IN PLACE OF THE UPPER PRODUCT. QUALITY IS THE SAME.
(略図の寸法は、参考値です。DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

03GR-X-9852

PACKING LIST EC-1000C-21/28、EC-1000C-R-21/28







03GR-X-9853-10

1/1

NAME	OUTLINE	DESCRIPTION/CODE	Q'TY
ユニット			
制御部 PROCESSOR UNIT		EC-1000C-*	1
		000-083-574-00	
ECDIS LANアダプタ ECDIS LAN ADAPTER		EC-1010	1
		000-082-657-00	
予備品			
予備品 SPARE PARTS		SP03-14800	1
		000-083-570-00	
付属品			
PS/2分配ケーブル PS/2 KEYBOARD/MOUSE Y CABLE		0C501P0104151000	1
マウス MOUSE		LYNX M9 MOUSE	1
キーボード KEY BOARD		KB-6869US	1
CD-ROM CD-ROM		2450036-	1
		001-007-880-00	
FD-ROM FD-ROM		2450037-	1
		001-007-890-00	
CD-ROM CD-ROM		2450023-	1
		001-008-690-00	
工事材料			
ナットとワッシャー WASHER HEAD SCREW(B)		M4X8 C2700W MBN12	14
		000-163-200-10	
		CP03-29100	

1.コード番号末尾の[**]は、選択品の代表型式/コードを表します。
CODE NUMBER ENDING WITH "***" INDICATES THE CODE NUMBER OF REPRESENTATIVE MATERIAL
2.(*)印は、タミコードに付き、注文できません。
"1" INDICATES THE CODE NUMBER OF REPRESENTATIVE MATERIAL

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

NAME	OUTLINE	DESCRIPTION/CODE	Q'TY
取付板 MOUNTING PLATE		14-058-2081-2	2
		100-321-552-10	
		その他工材	
電源ケーブル POWER CABLE		K15031H5183BR	1
		000-164-998-00	
図書			
取扱説明書 OPERATOR'S MANUAL		0M*-41220-*	1
		000-149-774-1*	
操作要領書 OPERATOR'S GUIDE		0S*-41220-*	1
		000-149-787-1*	
装備要領書 INSTALLATION MANUAL		1M*-41220-*	1
		000-149-775-1*	
ドングルインフォメーションシート DONGLE INFORMATION SHEET		999-999-085-0*	1
		999-999-085-0*	(*1)

型式/コード番号が2段の場合、下段より上段に代わる過渡期品であり、どちらが入っています。 なお、品質は変わりません。
TWO TYPES AND CODES MAY BE LISTED FOR AN ITEM. THE LOWER PRODUCT MAY BE SHIPPED IN PLACE OF THE UPPER PRODUCT. QUALITY IS THE SAME.
03GR-X-9853











PACKING LIST

EC-1000C-C-21/28、

EC-1000C-CR-21/28

03GR-X-9856-11

1/1

NAME	OUTLINE	DESCRIPTION/CODE	Q'TY
ユニット			
制御部 PROCESSOR UNIT		EC-1000C-CR-21/28	1
		000-083-517-00	
ECDIS LANアダプタ ECDIS LAN ADAPTER		EC-1010	1
		000-010-106-00	
ECDIS B7アダプタ ECDIS B ADAPTER		EC-1020	1
		000-010-107-00	
予備品			
予備品 SPARE PARTS		SP03-14800	1
		000-083-570-00	
付属品			
キーボード KEY BOARD		KB-6869US	1
		000-165-065-00	
マウス MOUSE		LYNX M9 MOUSE	1
		000-165-011-00	
PS/2分配ケーブル PS/2 KEYBOARD/MOUSE Y CABLE		OC501P0104151000	1
		000-164-999-00	
CD-ROM		2450036-	1
		001-007-880-00	
CD-ROM		2450023-	1
		001-008-690-00	
FD-ROM		2450037-	1
		001-007-890-00	

1.ユニット番号末尾の[*]は、タミコードに付き、注文できません。

"*1" INDICATES THE CODE NUMBER OF REPRESENTATIVE MATERIAL

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

NAME	OUTLINE	DESCRIPTION/CODE	Q'TY
工事材料			
INSTALLATION MATERIALS			
ワイヤアセンブリ WIRE ASSEMBLY		KPW-SB0.3-2PL2000A	1
		NFKV-SB0.3-2PL2000A	
ワッシャー WASHER HEAD SCREW(B)		000-152-257-11	
		000-152-257-10	
取付板 MOUNTING PLATE		MAX8 C2700W MBN12	14
		000-163-200-10	
		14-058-2081-2	2
		100-321-552-10	

その他工材

OTHER INSTALLATION MATERIALS

電源ケーブル POWER CABLE		K15031H5183BR	1
		000-164-998-00	

図書

DOCUMENT

装備要領書 INSTALLATION MANUAL		IM*-41220-*	1
		000-149-775-1*	
取扱説明書 OPERATOR'S MANUAL		OM*-41220-*	1
		000-149-774-1*	
操作要領書 OPERATOR'S GUIDE		OS*-41220-*	1
		000-149-787-1*	
ドングルインフォメーションシート DONGLE INFORMATION SHEET			1
		999-999-085-0*	(*1)




型式/コード番号が2段の場合、下段より上段に代わる過渡期品であり、どちらかが入っています。なお、品質は変わりません。

TWO TYPES AND CODES MAY BE LISTED FOR AN ITEM. THE LOWER PRODUCT MAY BE SHIPPED IN PLACE OF THE UPPER PRODUCT. QUALITY IS THE SAME.

PACKING LIST

RCU-018-E

03GR-X-9854 -1 1/1

N A M E	O U T L I N E	D E S C R I P T I O N / C O D E N o.	Q ' T Y
ユ ニ ッ ト UNIT			
操作部 CONTROL UNIT		RCU-018-E	1
		000-082-662	
付 属 品 ACCESSORIES			
付属品 ACCESSORIES		FP03-09850	1
		008-535-610	
工 事 材 料 INSTALLATION MATERIALS			
工事材料 INSTALLATION MATERIALS		CP03-25604	1
		008-539-850	




(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

03GR-X-9854

PACKING LIST

RCU-015FEA-E




03GR-X-9855 -0 1/1

N A M E	O U T L I N E	D E S C R I P T I O N / C O D E N o.	Q ' T Y
ユ ニ ッ ト U N I T			
操作部 CONTROL UNIT		RCU-015FEA-E	1
		000-082-663	
付 属 品 A C C E S S O R I E S			
付属品 ACCESSORIES		FP03-09860	1
		008-535-690	
工 事 材 料 I N S T A L L A T I O N M A T E R I A L S			
工事材料 INSTALLATION MATERIALS		CP03-25604	1
		008-539-850	

(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)





03GR-X-9855

CODE NO.	000-083-501-00	03GR-X-9405 -4
TYPE	CP03-29500	1/1

工事材料表 INSTALLATION MATERIALS					
番号 NO.	名 称 NAME	略 図 OUTLINE	型名／規格 DESCRIPTIONS	数量 Q'TY	用途／備考 REMARKS
1	コネクタ組品 CONNECTOR ASSY.		DSUB9P3-A DSUB9P3-A CODE NO. 000-150-677-11 000-150-677-00	1	
2	コネクタ組品 CONNECTOR ASSY.		DSUB9P-DSUB9P-L5.0M DSUB9P-DSUB9P-L5.0M CODE NO. 000-150-675-11 000-150-675-00	1	
3	ケーブル組品 CABLE ASSY.		PSE-4PTX-BL CODE NO. 000-164-634-10	1	




型式／コード番号が2段の場合、下段より上段に代わる通称製品であり、どちらかが入っています。なお、品質は変わりません。
TWO TYPES AND CODES MAY BE LISTED FOR AN ITEM. THE LOWER PRODUCT MAY BE SHIPPED IN PLACE OF THE UPPER PRODUCT. QUALITY IS THE SAME.
(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

CODE NO.	000-083-507-00	03GR-X-9406 -4
TYPE	CP03-29600	1/1

工事材料表 INSTALLATION MATERIALS					
番号 NO.	名 称 NAME	略 図 OUTLINE	型名／規格 DESCRIPTIONS	数量 Q'TY	用途／備考 REMARKS
1	コネクタ組品 CONNECTOR ASSY.		DSUB9P3-A DSUB9P3-A CODE NO. 000-150-677-11 000-150-677-00	1	
2	コネクタ組品 CONNECTOR ASSY.		DSUB9P3-B DSUB9P3-B CODE NO. 000-150-678-11 000-150-678-00	1	
3	コネクタ組品 CONNECTOR ASSY.		DSUB9P-DSUB9P-L5.0M DSUB9P-DSUB9P-L5.0M CODE NO. 000-150-675-11 000-150-675-00	2	
4	ケーブル組品 CABLE ASSY.		PSE-4PTX-BL CODE NO. 000-164-634-10	1	





型式／コード番号が2段の場合、下段より上段に代わる通称製品であり、どちらかが入っています。なお、品質は変わりません。
TWO TYPES AND CODES MAY BE LISTED FOR AN ITEM. THE LOWER PRODUCT MAY BE SHIPPED IN PLACE OF THE UPPER PRODUCT. QUALITY IS THE SAME.
(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)

CODE NO.	000-083-502-00	03GR-X-9408 -2
TYPE	CP03-29510	1/1

工事材料表					
INSTALLATION MATERIALS					
番号 NO.	名 称 NAME	略 図 OUTLINE	型名／規格 DESCRIPTIONS	数量 Q'TY	用途／備考 REMARKS
1	コネクタ組品 CONNECTOR ASSY.		DSUB9P3-A DSUB9P3-A CODE NO. 000-150-677-11 000-150-677-00	1	
2	コネクタ組品 CONNECTOR ASSY.		DSUB9P-DSUB9P-L10.0M DSUB9P-DSUB9P-L10.0M CODE NO. 000-150-676-11 000-150-676-00	1	
3	ケーブル組品 CABLE ASSY.		PSE-4PTX-BL CODE NO. 000-164-634-10	1	

型式／コード番号が2段の場合、下段より上段に代わる通称製品であり、どちらかが入っています。なお、品質は変わりません。
TWO TYPES AND CODES MAY BE LISTED FOR AN ITEM. THE LOWER PRODUCT MAY BE SHIPPED IN PLACE OF THE UPPER PRODUCT. QUALITY IS THE SAME.
(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)


CODE NO.	000-083-508-00	03GR-X-9409 -2
TYPE	CP03-29610	1/1

工事材料表					
INSTALLATION MATERIALS					
番号 NO.	名 称 NAME	略 図 OUTLINE	型名／規格 DESCRIPTIONS	数量 Q'TY	用途／備考 REMARKS
1	コネクタ組品 CONNECTOR ASSY.		DSUB9P3-A DSUB9P3-A CODE NO. 000-150-677-11 000-150-677-00	1	
2	コネクタ組品 CONNECTOR ASSY.		DSUB9P3-B DSUB9P3-B CODE NO. 000-150-678-11 000-150-678-00	1	
3	コネクタ組品 CONNECTOR ASSY.		DSUB9P-DSUB9P-L10.0M DSUB9P-DSUB9P-L10.0M CODE NO. 000-150-676-11 000-150-676-00	2	
4	ケーブル組品 CABLE ASSY.		PSE-4PTX-BL CODE NO. 000-164-634-10	1	

型式／コード番号が2段の場合、下段より上段に代わる通称製品であり、どちらかが入っています。なお、品質は変わりません。
TWO TYPES AND CODES MAY BE LISTED FOR AN ITEM. THE LOWER PRODUCT MAY BE SHIPPED IN PLACE OF THE UPPER PRODUCT. QUALITY IS THE SAME.
(略図の寸法は、参考値です。 DIMENSIONS IN DRAWING FOR REFERENCE ONLY.)


表 1 TABLE 1

寸法区分 (mm) DIMENSIONS	公差 (mm) TOLERANCE
L ≤ 50	± 1.5
50 < L ≤ 100	± 2.5
100 < L ≤ 500	± 3
500 < L ≤ 1000	± 4





型式銘板
NAMEPLATE

矢視 A VIEW A




4-φ8 (取付穴)
FIXING HOLES



下穴位置 (4箇所)
PILOT HOLES (4 PLACES)

取付穴寸法図
CUTOUT DIMENSIONS



電源コネクタ
POWER CONNECTOR

- 注 記 1) 指定外の寸法公差は表 1 による。
2) 取付用ネジはプラスタックピンネジ 6×30 を使用のこと。
- NOTE 1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
2. USE SELF-TAPPING SCREWS 6x30 FOR FIXING THE UNIT.

DRAWN	Jun 17, '05	E. MIYOSHI	TITLE	MU-201CE
CHECKED	TAKAHASHI, T	FCR-2107 series	名称	表示部 (埋込装備)
APPROVED	Y. Hatai	FEA-2107	外寸図	
SCALE	1/8	WSS 10 ±0.4 kg	NAME	MONITOR UNIT (FLUSH MOUNT)
DWG.No.	C4122-G08-B	24-005-200G-0	OUTLINE DRAWING	




表 1 TABLE 1

寸法区分 (mm) DIMENSIONS	公差 (mm) TOLERANCE
L ≤ 50	± 1.5
50 < L ≤ 100	± 2.5
100 < L ≤ 500	± 3
500 < L ≤ 1000	± 4

型式銘板
NAMEPLATE

矢視 B
VIEW B

矢視 A
VIEW A



電源コネクタ
POWER CONNECTOR

- 注 記 1) # 印寸法は最小サービス空間寸法とする。
 2) 指定外の寸法公差は表 1 による。
 3) 取付用ネジは M10 ボルトまたはコーチボルト呼び径 9 を使用のこと。
- NOTE 1. # MINIMUM SERVICE CLEARANCE.
 2. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
 3. USE M10 BOLTS OR COACH SCREWS φ9 FOR FIXING THE UNIT.

DRAWN	Jun 17, '05	E. MIYOSHI	TITLE	MU-201CE
CHECKED	TAKAHASHI, T	FCR-2107 series	名称	表示部 (卓上装備)
APPROVED	Y. Hatai	FEA-2107	外寸図	
SCALE	1/8	WSS 16	NAME	MONITOR UNIT (TABLETOP MOUNT)
DWG.No.	C4122-G09-A			OUTLINE DRAWING
				24-005-220G-0

表 1 TABLE 1

寸法区分 (mm) DIMENSIONS	公差 (mm) TOLERANCE
$L \leq 50$	± 1.5
$50 < L \leq 100$	± 2.5
$100 < L \leq 500$	± 3
$500 < L \leq 1000$	± 4



矢視 A
VIEW A

下穴位置 (4箇所)
PILOT HOLES (4 PLACES)

570±1

(96)

313±1

505

75

30

570±1


598

469

313±1

70

取付穴寸法図
CUTOUT DIMENSIONS



注 記 1) 指定外の寸法公差は表 1 による。

2) 取付用ネジはプラスタツピンネジ 6×30 を使用のこと。



NOTE 1. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.

2. USE SELF-TAPPING SCREWS 6x30 FOR FIXING THE UNIT.

DRAWN	Jun 17, '05	E. MIYOSHI	TITLE	MU-231CE
CHECKED	TAKAHASHI, T	FQR-2807 series	名称	表示部 (埋込装備)
APPROVED	Y. Hatai	FEA-2807	外寸図	
SCALE	1/8	WASS 15 ±10%	NAME	MONITOR UNIT (FLUSH MOUNT)
DWG.No.	C4123-G02-B	24-005-210G-0	OUTLINE DRAWING	

表 1 TABLE 1

寸法区分 (mm) DIMENSIONS	公差 (mm) TOLERANCE
$L \leq 50$	± 1.5
$50 < L \leq 100$	± 2.5
$100 < L \leq 500$	± 3



- 注 記 1) # 印寸法は最小サービス空間寸法とする。
 2) 指定外の寸法公差は表 1 による。
 3) 取付にはセムスネジ B (M4x12) を使用のこと。取付板厚 (t) は $2 \leq t \leq 4$ とする。
 それ以外はネジ長さを $(t + 7.8) \pm 2$ とする。

NOTE 1. # MINIMUM SERVICE CLEARANCE.

2. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.

3. USE SEMS-B SCREWS (M4x12) FOR FIXING THE UNIT.

THICKNESS (t): $2 \leq t \leq 4$ OR SCREW LENGTH: $t + 7.8 \pm 2$.

トラックパイロット部用ケーブル (オプション)



TRACKPILOT CABLE (OPTION)

制御部用ケーブル

CONTROL CABLE

リモート操作部用ケーブル (オプション)

REMOTE CONTROL CABLE (OPTION)



DRAWN	Sep. 29 '06 E. MIYOSHI	TITLE	RCU-018
CHECKED	TAKAHASHI, T	名称	操作部 (卓上装備)
APPROVED	Y. Hotai	外寸図	
SCALE	1/4	質量はケーブル (10m) を含む MASS W/10m CABLE	NAME CONTROL UNIT (TABLETOP MOUNT)
DWG.No.	C4122-G03-B	24-005-750G-1	OUTLINE DRAWING

取付穴
6-φ8

FIXING HOLES

150±1

150±1

52

440±1

470

#100

404

#100

173

CDドライブ
CD DRIVE

(122)

532

410

399

#100

表1 TABLE 1

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
L ≤ 50	±1.5
50 < L ≤ 100	±2.5
100 < L ≤ 500	±3
500 < L ≤ 1000	±4

信号コネクタ
SIGNAL CONNECTOR

ファン
FAN

アース端子
GND TERMINAL

電源コネクタ
POWER CONNECTOR

背面図
REAR VIEW

型式銘板
NAMEPLATE

注 記

- 1) #印寸法は最小サービスクリアランスとする。
- 2) 指定外の寸法公差は表1による。
- 3) 取付用ネジはM6ボルトまたはコーチボルト呼び径6を使用のこと。
- 4) 装備ケーブルはサービスタワー時、本体を前方に十分引き出せるよう余裕を持たせること。


NOTE

1. # MINIMUM SERVICE CLEARANCE.
2. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
3. USE M6 BOLTS OR COARCH SCREWS φ6 FOR FIXING THE UNIT.
4. KEEP SUFFICIENT CABLE LENGTH BEHIND THE UNIT FOR MAINTENANCE.

DRAWN	24/Apr/08 T.YAMASAKI	TITLE	EC-1000C
CHECKED	25/Apr/08 I.TAKENO	名称	制御部 (床置装備)
APPROVED	28/Apr/08 R.Esumi	外寸図	
SCALE	1/6 MASS 17 kg	NAME	PROCESSOR UNIT (FLOOR MOUNT)
DWG.No.	C4122-G01-D	REF.No.	24-005-500G-2
			OUTLINE DRAWING

表1 TABLE 1

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
$L \leq 50$	± 1.5
$50 < L \leq 100$	± 2.5
$100 < L \leq 500$	± 3




- 注 記 1) #印寸法は最小サービス空間寸法とする。
 2) 指定外の寸法公差は表 1 による。
 3) 取付用ネジはトラスタッピンネジ呼び径4×20を使用のこと。

- NOTE 1. #: MINIMUM SERVICE CLEARANCE.
 2. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
 3. USE SELF-TAPPING SCREWS $\phi 4 \times 20$ FOR FIXING THE UNIT.

DRAWN	Mar. 26 '07	T.YAMASAKI	TITLE	EC-1010
CHECKED	Mar. 26 '07	T.TAKENO	名称	ECDIS LANアダプタ
APPROVED	Mar. 28 '07	R.Esumi	外寸図	
SCALE	1/3	MASS 1.8 ±10% kg	NAME	ECDIS LAN ADAPTER
DWG No.	C4122-G02- C	REF. No.	24-005-300G-2	OUTLINE DRAWING

表1 TABLE 1

寸法区分 (mm) DIMENSION	公差 (mm) TOLERANCE
$L \leq 50$	± 1.5
$50 < L \leq 100$	± 2.5
$100 < L \leq 500$	± 3





- 注 記 1) #印寸法は最小サービス空間寸法とする。
2) 指定外の寸法公差は表1による。
3) 取付用ネジはトラスタッピンネジ呼び径4×20を使用のこと。

- NOTE 1. #: MINIMUM SERVICE CLEARANCE.
2. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
3. USE SELF-TAPPING SCREWS $\phi 4 \times 20$ FOR FIXING THE UNIT.

DRAWN	Mar. 26 '07 T.YAMASAKI	TITLE	EC-1020
CHECKED	Mar. 26 '07 T.TAKENO	名称	ECDIS Bアダプタ
APPROVED	Mar. 28 '07 R.Esumi	外寸図	
SCALE	1/3	NAME	ECDIS B-ADAPTER
DWG.No.	C4120-G06- C	OUTLINE DRAWING	

表 1 TABLE 1

寸法区分 (mm) DIMENSIONS	公差 (mm) TOLERANCE
$L \leq 50$	± 1.5
$50 < L \leq 100$	± 2.5
$100 < L \leq 500$	± 3



- 注 記 1) #印寸法は最小サービス空間寸法とする。
 2) 指定外の寸法公差は表 1 による。
 3) 取付にはセムスネジB (M4x12) を使用のこと。取付板厚 (t) は $2 \leq t \leq 4$ とする。
 それ以外はネジ長さを $(t + 7.8) \pm 2$ とする。

NOTE 1. # MINIMUM SERVICE CLEARANCE.

2. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.

3. USE SEMS-B SCREWS (M4x12) FOR FIXING THE UNIT.

THICKNESS (t): $2 \leq t \leq 4$ OR SCREW LENGTH: $t + 7.8 \pm 2$.

トラックパイロット部用ケーブル (オプション)



TRACKPILOT CABLE (OPTION)

制御部用ケーブル

CONTROL CABLE

リモート操作部用ケーブル (オプション)

REMOTE CONTROL CABLE (OPTION)





DRAWN	Sep. 29 '06 E. MIYOSHI	TITLE	RCU-018
CHECKED	TAKAHASHI, T	名称	操作部 (卓上装備)
APPROVED	Y. Hotai	外寸図	
SCALE	1/4	質量はケーブル (10m) を含む MASS W/ 10m CABLE	NAME CONTROL UNIT (TABLETOP MOUNT)
DWG.No.	C4122-G03-B		OUTLINE DRAWING

24-005-750G-1

FURUNO ELECTRIC CO., LTD.

表 1 TABLE 1

寸法区分 (mm) DIMENSIONS	公差 (mm) TOLERANCE
L ≤ 50	± 1.5
50 < L ≤ 100	± 2.5
100 < L ≤ 500	± 3



注 記 1) # 印寸法は最小サービス空間寸法とする。

2) 指定外の寸法公差は表 1 による。

3) 取付用ネジはトラスタップピンネジ呼び径6、またはM6 ボルトを使用のこと。

NOTE 1. # MINIMUM SERVICE CLEARANCE.

2. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.



3. USE SELF-TAPPING SCREWS #6 OR M6 BOLTS FOR FIXING THE UNIT.

制御部ケーブル
TO PROCESSOR UNIT

トラックパイロット部ケーブル (オプション)
TO TRACK PILOT (OPTION)



リモート操作部ケーブル (オプション)
TO REMOTE CONTROL UNIT (OPTION)

2-φ6.5取付穴
FIXING HOLES



DRAWN	Sep 29 '06	E. MIYOSHI			TITLE	RCU-018
CHECKED		TAKAHASHI, T			名称	操作部 (取付金具装備)
APPROVED		Y. Hatoh			外寸図	
SCALE	1/4	MASS 4.0 ±10% kg			NAME	CONTROL UNIT (TABLETOP MOUNT W/ FIXTURE)
DWG No.	C4122-G05-B	24-005-752G-1			OUTLINE DRAWING	

寸法区分 (mm) DIMENSIONS	公差 (mm) TOLERANCE
L ≤ 50	± 1.5
50 < L ≤ 100	± 2.5
100 < L ≤ 500	+3



NOTE

1. #: MINIMUM SERVICE CLEARANCE.
2. TABLE 1 INDICATES TOLERANCE OF DIMENSIONS WHICH IS NOT SPECIFIED.
3. THICKNESS (P) IS 20 MM MAX.


DRAWN	Sep. 29, '06	E. MIYOSHI			TITLE	RCU-018
CHECKED		TAKAHASHI, T			名称	操作部 (埋込装備)
APPROVED		Y. Hatai				外寸図
SCALE	1/4	MASS 3.8 ±10% kg	FEA-2107 基準はケーブル (10m) を含む MASS W/ 10m CABLE		NAME	CONTROL UNIT (FLASH MOUNT)
DMG.No.	C4122-G07-B		24-005-751C-1			OUTLINE DRAWING

A

B

C

D




注記

- * 1) 造船所手配。
- * 2) オプション。
- * 3) LAN1ポートを他のECDIS/レーダーのLANポートと直接つなぐ場合は、クロスケーブルを使用すること。
- * 4) ロータ電圧により切替。R1H:90-135V、R1L:90V以下。

NOTE

- *1: SHIPYARD SUPPLY.
- *2: OPTION.
- *3: USE A CROSS LAN CABLE WHEN LAN1 PORT IS CONNECTED TO ANOTHER ECDIS/RADAR LAN PORT DIRECTLY.
- *4: EXCHANGE AS ROTOR VOLTAGE: R1H:90-135V, R1L: WITHIN 90V.

DRAWN	18/Aug/09 T. YAMASAKI	TITLE	FEA-2107/2807
CHECKED	18/Aug/09 T. TAKENO	名称	電子海図システム
APPROVED	21/Aug/09 R.Esumi		相互結線図
SCALE	MASS	NAME	ECDIS
DWG. No.	C4122-C01- H	REF. No.	24-005-6001-0
INTERCONNECTION DIAGRAM			



NOTE

*1) 12/24V仕様を選択。

*2) オプション。

*1. CHOOSE SPECIFICATION FOR 12 OR 24VDC.

*2. OPTION.

DRAWN MAR. '05	E. MIYOSHI	TITLE FEA-2107/2807 (CP03-29501/29502)
CHECKED	TAKAHASHI, T	名称 レーダー切換器
APPROVED	Y. Hatai	相互結線図
		NAME RADAR SWITCH
DWG. No.	C4122-003- B	INTERCONNECTION DIAGRAM