

To change contrast on the FM8800, do the following:



Press shift



Then while shift is active, (shown in upper right of LCD) press down arrow and up arrow to increase and decrease contrast.

Backlighting adjustment is done by pressing shift again, then pressing the 2 button (picture of light bulb) until desired backlight is achieved.