



Updating Jeppesen C-Map Professional+ on the FMD3200 / FCR2829


This procedure explains the steps required to update your C-Map Professional+ charts. A USB jump drive and an e-mail capable PC are required.




From the primary ECDIS screen, click on the CHARTS tab at the top of the screen.

Then click on the LICENSE tab on the left. Then select C-MAP on the license dialogue box.





Insert a USB jump drive into the USB receptacle on the keyboard / controller. **Click on ORDER UPDATE FILE.** This will initiate a check of all of the C-Map charts on your system. Once completed, a small file will be created that has all of the details about your system, the license, and all of the updates that are needed. You will need to save this file onto a USB jump drive when prompted.




Once this file is saved to the USB jump drive, you can take it to any e-mail capable PC with a USB port. This file is normally very small, (20KB) and ends with the file extension “.ord”


This file needs to be attached to an e-mail and sent to

updates@c-map.no


In a few minutes, (normally less than one minute) you will receive an automatic reply e-mail (with attachment) from C-map. It will have a file attachment with all of your updates embedded in it.




Copy the attachment from your e-mail back to the USB jump drive and insert it back into the ECDIS USB jack on the keyboard.



On the ECDIS, click UPDATE FROM FILE.



Select the update file that was copied from the E-mail. Your update will be applied, and all corrections / notices to mariners will automatically applied.



You can then click on MANAGE CHARTS and the chart status will be shown both visually, and in the chart log.