


Helpful Tip on Setting the MMSI and boat name in your FA70 via a TZT2/3/XL MFD

The alpha-numeric space bar is located by selecting the number pad
(there is no space bar on the lettered keypad)

The number pad contains the actual “SP” key for spacing of letters/numbers

To add space to your entry, hit number key, then add the needed space by hitting the SP key.



Hit the “abc” key to go to the alpha keyboard again, if needed.